



Instruction No. **GF-109LN**


---

AERCO INTERNATIONAL, Inc., Northvale, New Jersey, 07647 USA

---

## Installation, Operation & Maintenance Instructions

# KC Series Gas Fired Low NOx Boiler System



*Natural Gas and Propane Fired,  
Condensing and Forced Draft Hot Water Boiler  
970,000 BTU/HR Input (Natural Gas)  
1,000,000 BTU/HR Input (Propane)*

Applicable to Serial Numbers G-03-807 and above

Patent No. 4,852,524

REVISED JANUARY, 2009

## **Telephone Support**

Direct to AERCO Technical Support  
(8am to 5 pm EST, Monday - Friday):

1-800-526-0288



AERCO International, Inc.  
159 Paris Avenue  
Northvale, NJ 07647-0128

[www.aerco.com](http://www.aerco.com)

© AERCO International, Inc., 2009

The information contained in this operation and maintenance manual is subject to change without notice from AERCO International, Inc.

AERCO makes no warranty of any kind with respect to this material, including but not limited to implied warranties of merchantability and fitness for a particular application. AERCO International is not liable for errors appearing in this manual. Nor for incidental or consequential damages occurring in connection with the furnishing, performance, or use of this material.

**GF-109LN - AERCO KC1000 GAS FIRED LOW NO<sub>x</sub> BOILER  
Operating & Maintenance Instructions**

---

**FOREWORD A**

**SECTION 1 – SAFETY PRECAUTIONS 1-1**

| <b>Para.</b> | <b>Subject</b>      | <b>Page</b> | <b>Para.</b> | <b>Subject</b>     | <b>Page</b> |
|--------------|---------------------|-------------|--------------|--------------------|-------------|
| 1.1          | Warnings & Cautions | 1-1         | 1.3          | Prolonged Shutdown | 1-2         |
| 1.2          | Emergency Shutdown  | 1-2         |              |                    |             |

**SECTION 2 – INSTALLATION PROCEDURES 2-1**

| <b>Para.</b> | <b>Subject</b>                             | <b>Page</b> | <b>Para.</b> | <b>Subject</b>             | <b>Page</b> |
|--------------|--|-------------|--------------|----------------------------|-------------|
| 2.1          | Receiving the Unit                         | 2-1         | 2.7          | I/O Box Connections        | 2-8         |
| 2.2          | Unpacking                                  | 2-1         | 2.8          | Auxiliary Relay Contacts   | 2-10        |
| 2.3          | Installation                               | 2-2         | 2.9          | Flue Gas Vent Installation | 2-10        |
| 2.4          | Gas Supply Piping                          | 2-4         | 2.10         | Combustion Air             | 2-10        |
| 2.5          | Electrical Supply                          | 2-6         |              |                            |             |
| 2.6          | Mode of Operation and Field Control Wiring | 2-6         |              |                            |             |

**SECTION 3 – CONTROL PANEL OPERATING PROCEDURES 3-1**

| <b>Para.</b> | <b>Subject</b>            | <b>Page</b> | <b>Para.</b> | <b>Subject</b>     | <b>Page</b> |
|--------------|---------------------------|-------------|--------------|--------------------|-------------|
| 3.1          | Introduction              | 3-1         | 3.6          | Configuration Menu | 3-5         |
| 3.2          | Control Panel Description | 3-1         | 3.7          | Tuning Menu        | 3-7         |
| 3.3          | Control Panel Menus       | 3-3         | 3.8          | Start Sequence     | 3-7         |
| 3.4          | Operating Menu            | 3-4         | 3.9          | Start/Stop Levels  | 3-9         |
| 3.5          | Setup Menu                | 3-4         |              |                    |             |

**SECTION 4 – INITIAL START-UP 4-1**

| <b>Para.</b> | <b>Subject</b>                                       | <b>Page</b> | <b>Para.</b> | <b>Subject</b>                            | <b>Page</b> |
|--------------|--|-------------|--------------|---|-------------|
| 4.1          | Initial Startup Requirements                         | 4-1         | 4.4          | Propane Combustion Calibration            | 4-5         |
| 4.2          | Tools and Instrumentation for Combustion Calibration | 4-1         | 4.5          | Unit Reassembly                           | 4-7         |
| 4.3          | Natural Gas Combustion Calibration                   | 4-2         | 4.6          | Over-Temperature Limit Switch Adjustments | 4-8         |

**Section 5 – MODE OF OPERATION 5-1**

| <b>Para.</b> | <b>Subject</b>            | <b>Page</b> | <b>Para.</b> | <b>Subject</b>                   | <b>Page</b> |
|--------------|---------------------------|-------------|--------------|----------------------------------|-------------|
| 5.1          | Introduction              | 5-1         | 5.6          | Boiler Management System (BMS)   | 5-4         |
| 5.2          | Indoor/Outdoor Reset Mode | 5-1         | 5.7          | Combination Control System (CCS) | 5-5         |
| 5.3          | Constant Setpoint Mode    | 5-2         |              |                                  |             |
| 5.4          | Remote Setpoint Modes     | 5-2         |              |                                  |             |
| 5.5          | Direct Drive Modes        | 5-3         |              |                                  |             |

## CONTENTS

### SECTION 6 – SAFETY DEVICE TESTING PROCEDURES 6-1

| Para. | Subject                      | Page | Para. | Subject                              | Page |
|-------|------------------------------|------|-------|--------------------------------------|------|
| 6.1   | Testing of Safety Devices    | 6-1  | 6.8   | Air Flow Fault Test                  | 6-4  |
| 6.2   | Low Gas Pressure Fault Test  | 6-1  | 6.9   | SSOV Proof of Closure Switch         | 6-4  |
| 6.3   | High Gas Pressure Fault Test | 6-1  | 6.10  | Purge Switch Open During Purge       | 6-5  |
| 6.4   | Low Water Level Fault Test   | 6-2  | 6.11  | Ignition Switch Open During Ignition | 6-5  |
| 6.5   | Water Temperature Fault Test | 6-2  | 6.12  | Safety Pressure Relief Valve Test    | 6-6  |
| 6.6   | Interlock Fault Tests        | 6-3  |       |                                      |      |
| 6.7   | Flame Fault Test             | 6-3  |       |                                      |      |

### SECTION 7 – MAINTENANCE 7-1

| Para. | Subject                | Page | Para. | Subject                              | Page |
|-------|------------------------|------|-------|--------------------------------------|------|
| 7.1   | Maintenance Schedule   | 7-1  | 7.5   | Safety Device Testing                | 7-2  |
| 7.2   | Spark Igniter          | 7-1  | 7.6   | Manifold and Exhaust Tubes           | 7-2  |
| 7.3   | Flame Detector         | 7-2  | 7.7   | Heat Exchanger Water Side Inspection | 7-4  |
| 7.4   | Combustion Calibration | 7-2  | 7.8   | Condensate Drain Assembly            | 7-5  |
| 7.5   | Safety Device Testing  | 7-2  |       |                                      |      |

### SECTION 8 – TROUBLESHOOTING 8-1

| Para. | Subject      | Page | Para. | Subject | Page |
|-------|--------------|------|-------|---------|------|
| 8.1   | Introduction | 8-1  |       |         |      |

## APPENDICES

| App | Subject                             | Page | App | Subject   | Page |
|-----|-------------------------------------|------|-----|---|------|
| A   | Boiler Menu Item Descriptions       | A-1  | E   | Boiler Default Settings                           | E-1  |
| B   | Startup, Status and Fault Messages  | B-1  | F   | Dimensional and Part Drawings                     | F-1  |
| C   | Temperature Sensor Resistance Chart | C-1  | G   | Piping Drawings                                   | G-1  |
| D   | Indoor/Outdoor Reset Ratio Charts   | D-1  | H   | Wiring Schematics                                 | H-1  |
|     |                                     |      | I   | KC1000 Control Panel Views                        | I-1  |
|     |                                     |      | J   | KC1000 Low NOx Dual-Fuel Switch-Over Instructions | J-1  |

### WARRANTIES W-1

***Foreword***

This system can be operated using natural gas or propane fuel. A simple spring change in the differential regulator and combustion calibration is all that is needed to switch fuels.

The AERCO KC Low NOx Boiler is a true industry advance that meets the needs of today's energy and environmental concerns. Designed for application in any closed loop hydronic system, the load tracking capability relates energy input directly to fluctuating system loads through a 11:1 modulating turndown ratio. The boiler's condensing capability offers extremely high efficiencies and makes the KC Boiler ideally suited for modern low temperature, as well as, conventional heating systems.

When installed and operated on natural gas in accordance with this Instruction Manual, the KC Boiler complies with the NOx emission standards outlined in:

- South Coast Air Quality Management District (SCAQMD), Rule 1146.2
- Texas Commission on Environmental Quality (TCEQ), Title 30, Chapter 117, Rule 117.465.

In addition, when operated using propane fuel, the KC Boiler is certified by AERCO to provide NOx emissions of less than 30 ppm at full rated input.

The KC Boiler can be used singular or in modular arrangements for inherent standby with minimum space requirements. Venting capabilities offer maximum flexibility and allow installation without normal restrictions. The advanced electronics of each KC Boiler control system offer selectable modes of operation and interface capabilities.

After prolonged shutdown, it is recommended that the startup procedures in Section 4 and the safety device test procedures in Section 6 of this manual be performed, to verify system operating parameters. If there is an emergency, turn off the electrical power supply to the KC Boiler or close the manual gas valve located before the unit. The installer is to identify the emergency shut-off device. FOR SERVICE OR PARTS, contact your local sales representative or AERCO INTERNATIONAL.

NAME: \_\_\_\_\_

ORGANIZATION: \_\_\_\_\_

ADDRESS: \_\_\_\_\_

TELEPHONE: \_\_\_\_\_

INSTALLATION DATE: \_\_\_\_\_



# SAFETY PRECAUTIONS

## SECTION 1 -- SAFETY PRECAUTIONS

### 1.1 WARNINGS & CAUTIONS

Installers and operating personnel MUST, at all times, observe all safety regulations. The following warnings and cautions are general and must be given the same attention as specific precautions included in these instructions. In addition to all the requirements included in this AERCO Instruction Manual, the installation of units MUST conform with local building codes, or, in the absence of local codes, ANSI Z223.1 (National Fuel Gas Code Publication No. NFPA-54) for gas-fired boilers and ANSI/NFPA58 for LP gas-fired boilers. Where applicable, the equipment shall be installed in accordance with the current Installation Code for Gas Burning Appliances and Equipment, CGA B149, and applicable Provincial regulations for the class; which should be carefully followed in all cases. Authorities having jurisdiction should be consulted before installations are made.

#### **IMPORTANT**

This Instruction Manual is an integral part of the product and must be maintained in legible condition. It must be given to the user by the installer and kept in a safe place for future reference.

#### **WARNINGS!**

MUST BE OBSERVED TO PREVENT SERIOUS INJURY.

#### **WARNING!**

BEFORE ATTEMPTING TO PERFORM ANY MAINTENANCE ON THE UNIT, SHUT OFF ALL GAS AND ELECTRICAL INPUTS TO THE UNIT.

#### **WARNING!**

THE EXHAUST VENT PIPE OF THE UNIT OPERATES UNDER A POSITIVE PRESSURE AND THEREFORE MUST BE COMPLETELY SEALED TO PREVENT LEAKAGE OF COMBUSTION PRODUCTS INTO LIVING SPACES.

#### **WARNING!**

DO NOT USE MATCHES, CANDLES, FLAMES, OR OTHER SOURCES OF IGNITION TO CHECK FOR GAS LEAKS.

#### **WARNING!**

FLUIDS UNDER PRESSURE MAY CAUSE INJURY TO PERSONNEL OR DAMAGE TO EQUIPMENT WHEN RELEASED. BE SURE TO SHUT OFF ALL INCOMING AND OUTGOING WATER SHUTOFF VALVES. CAREFULLY DECREASE ALL TRAPPED PRESSURES TO ZERO BEFORE PERFORMING MAINTENANCE.

#### **WARNING!**

ELECTRICAL VOLTAGES OF 120 VAC ARE USED IN THIS EQUIPMENT. THEREFORE THE COVER ON THE UNIT'S POWER BOX (LOCATED ON THE FRONT RIGHT SIDE OF THE UNIT UNDER THE HOOD AND SHEET METAL SIDE PANEL) MUST BE INSTALLED AT ALL TIMES, EXCEPT DURING MAINTENANCE AND SERVICING.

#### **CAUTIONS!**

Must be observed to prevent equipment damage or loss of operating effectiveness.

#### **CAUTION!**

Many soaps used for gas pipe leak testing are corrosive to metals. The piping must be rinsed thoroughly with clean water after leak checks have been completed.

#### **CAUTION!**

DO NOT use this boiler if any part has been under water. Call a qualified service technician to inspect and replace any part that has been under water.

# SAFETY PRECAUTIONS

## 1.2 EMERGENCY SHUTDOWN


If overheating occurs or the gas supply fails to shut off, close the manual gas shutoff valve (Figure 1-1) located external to the unit.

### IMPORTANT


The Installer must identify and indicate the location of the emergency shutdown manual gas valve to operating personnel.

## 1.3 PROLONGED SHUTDOWN

After prolonged shutdown, it is recommended that the startup procedures in Chapter 4 and the safety device test procedures in Chapter 6 of this manual be performed, to verify all system-operating parameters. If there is an emergency, turn off the electrical power supply to the AERCO boiler and close the manual gas valve located upstream the unit. The installer must identify the emergency shut-off device.



MANUAL GAS SHUTOFF VALVE



**Figure 1-1**

**Manual Gas Shutoff Valve**



# INSTALLATION

## SECTION 2 - INSTALLATION PROCEDURES

### 2.1. RECEIVING THE UNIT

Each KC1000 Boiler is shipped as a single crated unit. The crated shipping weight of the unit is approximately 1500 pounds, and must be moved with the proper rigging equipment for safety and to avoid damages. The unit should be completely inspected for shipping damage and completeness at the time of receipt from the carrier and before the bill of lading is signed. Each unit has Tip-N-Tell indicator on the outside of the crate that indicates if the unit has been turned on its side. If the Tip-N-Tell indicator is tripped, do not sign for the shipment. Request a freight claim and inspection by a claims adjuster before proceeding or refuse delivery of the equipment.


### 2.2. UNPACKING

Carefully unpack the unit. Take care not to damage the unit jacket when cutting away packaging materials. An inspection of the unit should be made to determine if damage during shipment occurred that was not indicated by the Tip-N-Tell. The freight carrier should be notified immediately if any damage is detected. The following accessories come standard with each

unit and are packed separately within the unit's packing container

- Spare Spark Ignitor
- Spare Flame Detector
- Manual 1-1/4" Gas Shutoff Valve
- Drain Valve Assembly
- ASME Pressure Relief Valve
- Differential Regulator Spring:  
P/N 122548 (Propane) or  
P/N 124803 (Natural Gas)
- Ignitor Removal Tool (One per Site)
- Regulator Adjustment Tool (One per site)
- Temperature/Pressure Gauge and Fittings
- 2 Lifting Lugs
- Stainless Steel Condensate Cup
- Shell Cap
- Wing Nut for Shell Cap

Optional accessories are also separately packed within the unit's packing container. Standard and optional accessories shipped with the unit should be identified and put in a safe place until installation or use.



BOILER CLEARANCES

Figure 2.1. Boiler Clearances

## 2.3 INSTALLATION

The unit must be installed with the prescribed clearances for service as shown in Figure 2.1. The minimum clearance dimensions, required by AERCO, are listed below. Local building codes may require additional clearance and take precedence

Minimum clearances required:

|       |     |
|-------|-----|
| Sides | 24" |
| Front | 18" |
| Rear  | 18" |
| Top   | 18" |

All gas piping, water piping, and electrical conduit or cable must be arranged so that they do not interfere with the removal of any cover, or inhibit service or maintenance of the unit.

**WARNING!**  
*KEEP UNIT AREA CLEAR AND FREE FROM COMBUSTIBLE MATERIALS AND FLAMMABLE VAPORS AND LIQUIDS.*

### 2.3.1. SETTING THE UNIT


Remove the unit from the wooden skid and place in position using a block and tackle or hoist attached to the lifting lugs, (see Fig. 2.2). USE ONLY THE LIFTING LUGS TO MOVE THE UNIT.

The KC-1000 is U/L approved for installation on combustible flooring. A 4 to 6 inch high house-keeping concrete pad is recommended and allows for sufficient drainage of the condensate.

It is suggested that units be secured using the holes provided in the frame base. Piping must not be used to secure the unit in place. See drawing AP-A-816 in Appendix F for the base frame dimensions.

In multiple unit installations, it is important to plan the position of each unit. Sufficient space for piping connections and future maintenance requirements must be given. All piping must include ample provision for expansion.

If installing a Combination Control (CCP) system, it is important to identify and place the Combination Mode units in the proper physical location.



**Figure 2.2**  
**Lifting Lug Location**

### 2.3.2 SUPPLY AND RETURN PIPING

The locations of the 4" flanged system supply, and return piping connections, to the unit are shown in figure 2.3. The return connection is located on the left side near the base of the unit's shell. The supply connection is located on the left side near the top of the unit's shell.

Whether installing single or multiple units, install the piping and accessories as shown in the appropriate piping diagram located in Appendix G. For applications other than standard space heating, consult the AERCO Boiler Application Guide, GF-1070, or AERCO for the appropriate piping schematics.


The minimum flow rate through the unit is 25 GPM and the maximum flow rate is 150 GPM. Each unit is fitted with 4" flanges for high flow application and the system velocity at the unit return should not exceed 5 feet per second. Each unit must have individual valves on the supply, and return, for maintenance. In multiple unit installations, the flow through each unit must be balanced.

Every boiler plant must have a source of make-up water to it. As with any closed loop hydronic system, air elimination and expansion equipment must be provided as part of the overall installation. All piping MUST include ample provision for expansion.

# INSTALLATION

## 2.3.4 TEMPERATURE/PRESSURE INDICATOR

The unit is supplied with one of two styles of Temperature/Pressure Indicators that must be installed in the tapping on the supply flange of the unit (see Figs. 2.5a and 2.5b). A suitable pipe compound should be used sparingly to the threaded connection.




**Figure 2.3**  
Supply and Return Location


## 2.3.3 PRESSURE RELIEF AND DRAIN VALVE INSTALLATION

An ASME rated Relief Valve is supplied with each unit. The supplied pressure relief valve setpoint will be 30, 50, 75, 100, or 150 psig as ordered from the factory. Install the pressure relief valve in the tapping provided opposite the system supply connection, (see figure 2.4). The pressure relief valve should be piped in the vertical position using the fittings supplied. A suitable pipe compound should be used on the threaded connections, and excess should be wiped off to avoid getting any into the valve body. The discharge from the relief valve should be piped to within 12 inches of the floor to prevent injury in the event of a discharge.


The relief piping must be full size without reduction. No valves, restrictions, or other blockages should be allowed in the discharge line. In multiple unit installations the relief valve discharge lines must not be manifolded, (connected), together. Each must be individually run to a suitable discharge location. The drain valve provided should be installed on the right hand side of the unit towards the bottom of the shell. The valve should be pointed in the down position, (see Fig. 2.4).




**Figure 2.4**  
Relief and Drain Valve Location



**Figure 2.5a**  
Pressure /Temperature Gauge Installation



**Figure 2.5b**  
**Pressure/Temperature Gauge Installation**



**Figure 2.6**  
**Condensate Drain System Location**

### 2.3.5 CONDENSATE PIPING

The KC Boiler is designed to condense. Therefore, the installation site must include suitable provisions for condensate drainage or collection. A stainless steel condensate cup is separately packed within the unit's shipping container. To install the condensate cup, proceed as follows:

1. Remove the left side panel and only the left half of the rear cover to provide access to the exhaust manifold and burner (Figure 2.6).
2. Insert the 1-3/4 inch manifold drain hose into the condensate cup. Allow the cup to rest on the floor directly beneath the manifold drain hole (Figure 2.6).
3. Attach a length of 3/4 inch I.D. polypropylene tubing to the condensate cup drain tube and route it to a floor drain. If a floor drain is not available, a condensate pump can be used to remove the condensate to drain. The condensate drain line must be removable for routine maintenance. Therefore, DO NOT hard-pipe.
4. Replace the rear cover and side panel on the unit.

### 2.4. GAS SUPPLY PIPING

The AERCO Gas Fired Equipment Gas Components and Supply Design Guide (GF-1030) must be consulted before any gas piping is designed or started.

**WARNING!**  
*DO NOT USE MATCHES, CANDLES, FLAMES OR OTHER SOURCES OF IGNITION TO CHECK FOR GAS LEAKS.*

**CAUTION!**  
Soaps used for gas pipe leak testing can be corrosive to metals. Piping must be rinsed thoroughly with clean water after leak checks have been completed.

**NOTE:**  
All gas piping must be arranged so that it does not interfere with removal of any cover, inhibit service or maintenance, or prevent access between the unit and walls, or another unit.


# INSTALLATION

The location of the 1-1/4" inlet gas connection is on the right side of the unit as shown in Figure 2.7.

All pipe should be de-burred and internally cleared of any scale or iron chips before installation. No flexible connectors or non-approved gas fittings should be installed. Piping should be supported from floor or walls only and must not be secured to the unit.

A suitable piping compound, approved for use with gas, should be used sparingly. Any excess must be wiped off to prevent clogging of components.

To avoid damage to the unit, when pressure testing gas piping, isolate the unit from the supply gas piping. At no time should there be more than 14" W.C. the unit. Bubble test all external piping thoroughly for leaks using a soap and water solution or suitable equivalent. The gas piping must meet all applicable codes.



**Figure 2.7**  
**Gas Supply Regulator and Manual Shut-Off Valve Location**

## 2.4.1 GAS SUPPLY PRESSURE REGULATOR

A mandatory external, in-line, supply gas regulator (supplied by others) must be installed upstream of each KC1000 and positioned as shown in Figure 2.7. Union connections should be placed in the proper locations to allow maintenance of the regulator if required. The regulator must be capable of providing the required gas pressures for natural gas and propane units as described in the paragraphs which follow.

### Natural Gas:

The maximum static inlet pressure to the unit must be no more than 14" W.C. Minimum gas pressure is 8.8" W.C. for FM gas trains and 9.2" W.C. for IRI gas trains when the unit is firing at maximum input. Gas pressure should not exceed 11.5" W.C. at any time when firing. Proper sizing of the gas supply regulator in delivering the correct gas flow and outlet pressure is mandatory. The gas supply pressure regulator must maintain the gas pressure at a regulated 8.8" W.C. minimum for FM gas trains and 9.2" W.C. for IRI gas trains at maximum BTU input (970,000 BTU/HR) for natural gas installations. The supply gas regulator must be of sufficient capacity volume, (1000 cfh), for the unit and should have no more than 1" droop from minimum to full fire.

### Propane:

The maximum static inlet pressure to the unit must be no more than 14" W.C. Minimum gas pressure is 7.7" W.C. for FM gas trains and 8.1" W.C. for IRI gas trains when the unit is firing at maximum input. Gas pressure should not exceed 11.5" W.C. at any time when firing. Proper sizing of the gas supply regulator in delivering the correct gas flow and outlet pressure is mandatory. The gas supply pressure regulator must maintain the gas pressure at a regulated 7.7" W.C. minimum for FM gas trains and 8.1" W.C. for IRI gas trains at maximum BTU input (1,000,000 BTU/HR) for propane installations. The supply gas regulator must be of sufficient capacity volume, (400 cfh), for the unit and should have no more than 1" droop from minimum to full fire.

The supply gas regulator must be rated to handle the maximum incoming supply gas pressure. When the gas supply pressure will not exceed 14" W.C. a non-lock up or flow through style regulator may be used. When supply gas pressure will exceed 14" W.C., a lock up style regulator must be used. The gas supply regulator must be properly vented to outdoors. Consult the local gas utility for exact requirements concerning venting of supply gas regulators.

### CAUTION!

A lockup style regulator must be used when gas supply pressure exceeds 14" W.C.

### 2.4.2 MANUAL GAS SHUTOFF VALVE


A 1-1/4" manual gas shut-off valve is furnished with each unit. The valve should be positioned as shown in Figure 2.7. The manual gas shut-off valve must be installed upstream of the supply regulator in a readily accessible location.

### 2.4.3 IRI GAS TRAIN KIT

The IRI gas train is an optional gas train required in some areas by code or for insurance purposes. The IRI gas train is factory pre-piped and wired. (See Appendix F, Drawing No. SD-A-660).

### 2.5 ELECTRICAL SUPPLY

The AERCO Gas Fired Equipment Electrical Power Wiring Guide, (GF-1060), must be consulted in addition to the following material before wiring to the unit is started. AC power connection to the unit are made at the Power Box. This box is located on the front right side of the unit as shown in Figure 2.8. Conduit should be run from the knockouts in the side of the box in such a manner that it does not interfere with the removal of any sheet metal covers. A flexible electrical connection may be utilized to allow the covers to be easily removed.



**Figure 2.8**  
**AC Power Box Location**


### NOTE:

All electrical conduit and hardware should be installed so that it does not interfere with the removal of any cover, inhibit service or maintenance, or prevent access between the unit and walls or another unit.

### 2.5.1 ELECTRICAL REQUIREMENTS

Electrical requirements for each unit are 120 VAC, Single Phase, 60 Hz, 20 Amps from a dedicated electrical circuit. No other devices should be on the same electrical circuit as the KC1000 unit. A means for disconnecting AC power from the unit (such as a service switch) must be installed near the unit for normal operation and maintenance. All electrical connections should be made in accordance with the National Electrical Code and/or with any applicable local codes.

The AC power wiring diagram is shown in Figure 2.9.



**Figure 2.9**  
**AC Power Wiring Diagram**

### 2.6 MODE OF OPERATION and FIELD CONTROL WIRING

The KC Boiler is available in several different modes of operation. While each unit is factory configured and wired for the mode specified on the equipment order, some field wiring may be required to complete the installation. This wiring is typically routed to the Input/Output (I/O) Box located on the left side of the unit beneath the removable side panel (see Fig. 2.10). Field wiring for each particular mode of operation is described in the following paragraphs. For additional information concerning modes of operations, refer to Section 5.


# INSTALLATION

## 2.6.1 CONSTANT SETPOINT MODE


The Constant Setpoint Mode is used when it is desired to have a fixed setpoint that does not deviate. No wiring connections other than electrical supply connections are required for this mode. However, if desired, fault monitoring or enable/disable interlock wiring can be utilized (see paragraphs 2.7.9 and 2.7.10).

## 2.6.2 INDOOR/OUTDOOR RESET MODE

This mode of operation increases supply water temperature as outdoor temperatures decrease. An outside air temperature sensor (AERCO PN 122790) is required. The sensor **MUST BE** wired to the I/O Box wiring terminals (see Fig. 2.11). For more information concerning the outside air sensor installation, refer to paragraph 2.7.1. For programming and setup instructions concerning the indoor/outdoor-reset mode of operation, refer to Section 5, paragraph 5.1.



**Figure 2.10**  
Input/Output (I/O) Box Location



**Figure 2.11**  
I/O Box Terminal Strip

### 2.6.3 BOILER MANAGEMENT SYSTEM (BMS) MODE

#### NOTE

BMS Model 168 can utilize either pulse width modulation (PWM) or RS485 Modbus signaling to the Boiler. BMS II Model 5R5-384 can utilize only RS485 signaling to the Boiler.

When using an AERCO Boiler Management System (BMS), the field wiring is connected between the BMS Panel and each Boiler's I/O Box terminal strip (Figure 2-11). Twisted shielded pair wire from 18 to 22 AWG must be utilized for the connections. The BMS Mode can utilize either pulse width modulation (PWM) signaling, or RS485 Modbus signaling. For PWM signaling, connections are made from the AERCO Boiler Management System to the B.M.S. (PWM) IN terminals on the I/O Box terminal strip. For RS485 Modbus signaling, connections are made from the BMS to the RS485 COMM terminals on the I/O Box terminal strip. Polarity must be maintained and the shield must be connected only at the AERCO BMS. The boiler end of the shield must be left floating. For additional instructions, refer to Chapter 5, paragraph 5.6 in this manual. Also, refer to GF-108M (BMS Model 168) and GF-124 (BMS II Model 5R5-184), BMS -Operations Guides.

### 2.6.4 REMOTE SETPOINT and DIRECT DRIVE MODES

The KC1000 Boiler can accept several types of signal formats from an Energy Management System or other source to control either the setpoint (Remote Setpoint Mode) or firing rate (Direct Drive Mode) of the Boiler. These formats are:

4 to 20 mA/1 to 5 Vdc

0 to 20 mA/0 to 5 Vdc

PWM – (Pulse Width Modulated signal. See paragraph 2.7.4)

Network – (RS485 Modbus. See para. 2.7.7)

While it is possible to control one or more boilers using one of the above modes of operation, it may not be the method best suited for the application. Prior to selecting one of the above modes of operation, it is recommended that you consult with your local AERCO representative or the factory for the mode of operation that will work best with your application. For more

information on wiring the 4 to 20 mA / 1 to 5VDC or the 0 to 20 mA / 0 to 5 VDC, see paragraph 2.7.3.

### 2.6.5 COMBINATION MODE

#### NOTE

Only BMS Model 168 can be utilized for the Combination Mode, not the BMS II (Model 5R5-384).

With a Combination Mode unit, field wiring is between the unit's I/O Box, the CCP (Combination Control Panel), and the BMS Model 168 (Boiler Management System). The wiring must be done using a shielded twisted pair of 22 AWG wire. Polarity must be maintained between the unit, the CCP, and the BMS. For further instructions and wiring diagrams, refer to the GF-108 Boiler Management System Operations Guide and the CCP-1 data sheet.

### 2.7 I/O BOX CONNECTIONS

The types of input and output/signals and devices to be connected to the I/O Box terminals shown in Figure 2.11 are described in the following paragraphs.

#### CAUTION!

DO NOT make any connections to the I/O Box terminals labeled "NOT USED". Attempting to do so may cause equipment damage.

#### 2.7.1 OUTDOOR SENSOR IN

An outdoor air temperature sensor (AERCO Part No. 122790) will be required mainly for the Indoor/Outdoor Reset mode of operation. It can also be used with another mode if it is desired to use the outdoor sensor enable/disable feature. This feature allows the boiler to be enabled or disabled based on the outdoor air temperature. The factory default for the outdoor sensor is DISABLED. To enable the sensor and or choose an enable/disable outdoor temperature, see the Configuration menu in Section 3 and Appendix A.

The outdoor sensor may be wired up to 200 feet from the boiler and is connected to the OUTDOOR SENSOR IN and SENSOR COMMON terminals in the I/O box (see Figs. 2.10 and 2.11). Wire the sensor using a twisted shielded pair cable of 18-22 AWG wire. There is no polarity when terminating the wires. The



# INSTALLATION

shield is to be connected only to the terminals labeled SHEILD in the I/O Box. The sensor end of the shield must be left free and ungrounded.

When mounting the sensor, it must be located on the North side of the building where an average outside air temperature is expected. The sensor must be shielded from direct sunlight as well as impingement by the elements. If a shield is used, it must allow for free air circulation.

## 2.7.2 AUX SENSOR IN

The AUX SENSOR IN terminals can be used to add an additional temperature sensor for monitoring purposes. This input is always enabled and is a view only input that can be seen in the operating menu. The sensor must be wired to the AUX SENSOR IN and SENSOR COMMON and must be similar to AERCO BALCO wire sensor P/N 12449. A resistance chart for this sensor is provided in Appendix C.

## 2.7.3 ANALOG IN

The ANALOG IN + and – terminals are used when an external signal is used to drive the firing rate (Direct Drive Mode) or change the setpoint (Remote Setpoint Mode) of the Boiler. Either a 4 to 20 mA / 1 to 5 VDC or a 0 to 20 mA / 0 to 5 VDC signal may be used to vary the setpoint or firing rate. The factory default setting is 4 to 20 mA / 1 to 5 VDC, however this may be changed to 0 to 20 mA / 0 to 5 VDC using the Configuration Menu described in Section 3. If voltage rather than current is selected as the drive signal, a DIP switch must be set on the PMC Board located inside the Control Box. Contact the AERCO factory for information on setting DIP switches.

All of the supplied signals must be floating (ungrounded) signals. Connections between the source and the Boiler's I/O Box must be made using twisted shielded pair of 18 –22 AWG wire such as Belden 9841(see Fig. 211). Polarity must be maintained and the shield must be connected only at the source end and must be left floating (not connected) at the Boiler's I/O Box.

Whether using voltage or current for the drive signal, they are linearly mapped to a 40°F to 240°F setpoint or a 0% to 100% firing rate. No scaling for these signals is provided.

## 2.7.4 B.M.S. (PWM) IN

### NOTE

Only BMS Model 168 can utilize Pulse Width Modulation (PWM), not the BMS II (Model 5R5-384).

These terminals are used to connect the AERCO Boiler Management System (BMS) Model 168 to the unit. The BMS Model 168 utilizes a 12 millisecond, ON/OFF duty cycle. This duty cycle is Pulse Width Modulated (PWM) to control firing rate. A 0% firing rate = a 5% ON pulse and a 100% firing rate = a 95% ON pulse.

## 2.7.5 SHIELD

The SHIELD terminals are used to terminate any shields used on sensor wires connected to the unit. Shields must only be connected to these terminals.

## 2.7.6 mA OUT

These terminals provide a 4 to 20 mA output that can be used to monitor setpoint (40°F to 220°F), outlet temperature (30°F to 245°F), or fire rate (0% to 100%). This function is enabled in the Configuration Menu (Section 3, Table 3.4).

## 2.7.7 RS-485 COMM

These terminals are used for RS-485 MODBUS serial communication between the unit and an external "Master", such as a Boiler Management System or other suitable device.

## 2.7.8 EXHAUST SWITCH IN

These terminals permit an external exhaust switch to be connected to the exhaust manifold of the boiler. The exhaust sensor should be a normally open type switch (such as AERCO Part No. 123463) that closes (trips) at 500°F.

## 2.7.9 INTERLOCKS

The unit offers two interlock circuits for interfacing with Energy Management Systems and auxiliary equipment such as pumps or louvers. These interlocks are called the Remote Interlock and Delayed Interlock (Fig. 2.11). The wiring terminals for these interlocks are located inside the I/O Box on the left side of the unit. The I/O Box cover contains a wiring diagram which shows the terminal strip locations for these interlocks which are labeled REMOTE INTL'K IN and DELAYED INTL'K IN. Both interlocks, described in the following paragraphs, are factory wired in the closed position.

**NOTE:**

Both the Delayed Interlock and Remote Interlock must be in the closed position to allow the unit to fire.

### **2.7.9.1 REMOTE INTERLOCK IN**

The remote interlock circuit (REMOTE INTL'K IN) is provided to remotely start (enable) and stop (disable) the Boiler if desired. The circuit is 24 VAC and comes factory pre-wired closed (jumpered).

### **2.7.9.2 DELAYED INTERLOCK IN**

The delayed interlock circuit (DELAYED INTL'K IN) is typically used in conjunction with the auxiliary relay described in paragraph 2.8. This interlock circuit is located in the purge section of the start string. It can be connected to the proving device (end switch, flow switch etc.) of an auxiliary piece of equipment started by the boiler's auxiliary relay. The delayed interlock must be closed for the boiler to fire. If the delayed interlock is connected to a proving device that requires time to close (make), a time delay (Aux Start On Dly) that holds the start sequence of the boiler long enough for for a proving switch to make can be programmed. Should the proving switch not prove within the programmed time frame, the boiler will shut down. The Aux Start On Dly can be programmed from 0 to 120 seconds. This option is locate in the Configuration Menu (Section 3).

### **2.7.10 FAULT RELAY**

The fault relay is a single pole double throw (SPDT) relay having a normally open and normally close set of relay contacts that are rated for 5 amps at 120 VAC and 5 amps at 30 VDC. The relay energizes when any fault condition occurs and remains energized until the fault is cleared and the CLEAR button is depressed. The fault relay connections are shown in Figure 2.11.

### **2.8 AUXILIARY RELAY CONTACTS**

Each KC Boiler is equipped with a single pole double throw (SPDT) relay that is energized when there is a demand for heat and de-energized after the demand for heat is satisfied. The relay is provided for the control of auxiliary equipment, such as pumps and louvers, or can be used as a Boiler status indicator (firing or not firing). Its contacts are rated for 120 VAC @ 5 amps. Refer to Figure 2.11 to locate the AUX RELAY terminals for wiring connections.

### **2.9 FLUE GAS VENT INSTALLATION**

The AERCO Venting and Combustion Air Guide, GF-1050, must be consulted before any flue or inlet air venting is designed or installed. Suitable, U/L approved, positive pressure, water-tight vent materials as specified in AERCO's GF-1050, must be used for safety and UL certification. Because the unit is capable of discharging low temperature exhaust gases, the flue must be pitched back to the unit a minimum of 1/4" per foot to avoid any condensate pooling and to allow for proper drainage.

While there is a positive flue pressure during operation, the combined pressure drop of vent and combustion air systems must not exceed 140 equivalent feet of 0.81" W.C. Fittings as well as pipe lengths must be calculated as part of the equivalent length. For a natural draft installation the draft must not exceed - 0.25" W.C. These factors must be planned into the vent installation. If the maximum allowable equivalent lengths of piping are exceeded, the unit will not operate properly or reliably.

### **2.10 COMBUSTION AIR**

The AERCO Venting and Combustion Air Guide, GF-1050, MUST be consulted *before* any flue or combustion supply air venting is designed or started. Combustion air supply is a direct requirement of ANSI 223.1, NFPA-54, and local codes. These codes should be consulted before a permanent design is determined.

The combustion air must be free of chlorine, halogenated hydrocarbons, or other chemicals that can become hazardous when used in gas-fired equipment. Common sources of these compounds are swimming pools, degreasing compounds, plastic processing and refrigerants. Whenever the environment contains these types of chemicals, combustion air must be supplied from a clean area outdoors for the protection and longevity of the equipment.

The more common methods of supplying combustion air are outlined below. For more information on combustion air, consult the AERCO GF-1050, Venting and Combustion Air Guide.

#### **2.10.1 COMBUSTION AIR FROM OUTSIDE THE BUILDING**

Air supplied from outside the building must be provided through two permanent openings. For each unit these two openings must have a free area of not less than one square inch for each 4000 BTUs input of the equipment or 250

## INSTALLATION


square inches of free area. The free area must take into account restrictions such as louvers and bird screens.

### 2.10.2 COMBUSTION AIR FROM INSIDE THE BUILDING

When combustion air is provided from within the building, it must be supplied through two permanent openings in an interior wall. Each opening must have a free area of not less than one square inch per 1000 BTUH of total input or 1000 square inches of free area. The free area must take into account any restrictions such as louvers.

#### NOTE

KC1000 units equipped with Low NOx Burners require an optional Cold Air Damper for operation with Direct Vent/ Sealed Combustion. The Cold Air Damper is also required when the unit is installed in an area where the combustion air supply temperature can drop below 55°F. Refer to the following paragraph (2.10.3) and GF-1050 for installation details.



**Figure 2.12**  
**Sealed Combustion Air Connection**

### 2.10.3 SEALED COMBUSTION

The KC Boiler is UL approved for 100% sealed combustion application when installed properly. When a sealed combustion air application is installed, the sealed combustion air piping must be deducted from the maximum allowable discharge piping amounts. Each unit must have a minimum 6" diameter connection made to the special Inlet Air Adapter # GP-18917 available from AERCO. This adapter bolts directly on to the air inlet of the unit's blower. See installation instructions with adapter. All inlet air ducts must be sealed air tight.

In addition, Cold Air Damper # 99026 must be installed. It should be located along the inlet duct run as close as possible to the KC1000 (See Figure 2.12). The Cold Air Damper must be placed on individual sections (one Damper per unit), not in a manifold section. The adjustment screw on the Damper should be moved to the center of the slot position and tightened 1/2 turn past "finger-tight". DO NOT over-tighten.

See AERCO Venting Guide GF-1050 for further details.



# CONTROL PANEL OPERATING PROCEDURES

## SECTION 3 - CONTROL PANEL OPERATING PROCEDURES

### 3.1. INTRODUCTION

The information in this Section provides a guide to the operation of the KC1000 Boiler using the Control Panel mounted on the front of the unit. It is imperative that the initial startup of this unit be performed by factory trained personnel. Operation prior to initial startup by factory trained personnel will void the equipment warranty. In addition, the following WARNINGS and CAUTIONS must be observed at all times.

#### CAUTION:

All initial installation procedures must be satisfied before attempting to start the unit.

#### WARNING:

THE ELECTRICAL VOLTAGES IN THIS SYSTEM INCLUDE 120 AND 24 VOLTS AC. IT MUST NOT BE SERVICED OR ACCESSED BY OTHER THAN FACTORY CERTIFIED SERVICE TECHNICIANS.

#### WARNING:

DO NOT ATTEMPT TO DRY FIRE THE BOILER. STARTING THE UNIT WITHOUT A FULL WATER LEVEL CAN SERIOUSLY DAMAGE THE UNIT AND MAY RESULT IN PERSONNEL INJURY OR PROPERTY DAMAGE. THIS SITUATION WILL VOID ANY WARRANTY.

### 3.2. CONTROL PANEL DESCRIPTION

The KC1000 Control Panel shown in Figure 3-1 contains all of the controls, indicators and displays necessary to operate, adjust and troubleshoot the KC1000 Boiler. These operating controls, indicators and displays are listed and described in Table 3-1. Additional information on these items are provided in the individual operating procedures provided in this Section.




Figure 3-1. Control Panel Front View

# CONTROL PANEL OPERATING PROCEDURES

Table 3-1. Operating Controls, Indicators and Displays

| ITEM NO. | CONTROL, INDICATOR OR DISPLAY  | FUNCTION   |
|----------|--|--|
| 1        | <u>LED Status Indicators</u><br><br><b>COMM</b><br><b>MANUAL</b><br><br><b>REMOTE</b><br><br><b>DEMAND</b> | Four Status LEDs indicate the current operating status as follows:<br>Lights when RS-232 communication is occurring<br>Lights when the unit is being controlled using the front panel keypad.<br>Lights when the unit is being controlled by an external signal from an Energy Management System<br>Lights when there is a demand for heat.  |
| 2        | VFD Display  | Vacuum Fluorescent Display (VFD) consists of 2 lines, each capable of displaying up to 16 alphanumeric characters. The information displayed includes:<br>Startup Messages<br>Alarm Messages<br>Operating Status Messages<br>Menu Selection  |
| 3        | <b>OUTLET TEMPERATURE</b> Display  | 3-Digit, 7-Segment LED display continuously displays the outlet water temperature. The °F or °C LED next to the display lights to indicate whether the displayed temperature is in degrees Fahrenheit or degrees Celsius.  |
| 4        | <b>RS-232</b> Port   | Port permits a Laptop Computer or External Modem to be connected to the boiler Control Panel.  |
| 5        | <b>READY</b> Indicator   | Lights when all Pre-Purge conditions have been satisfied.  |
| 6        | <b>ON/OFF</b> Switch   | Enables and disables boiler operation.   |
| 7        | <b>LOW WATER LEVEL TEST/RESET</b> Switches   | Allow the operator to test the operation of the water level monitor.<br>Pressing <b>TEST</b> opens the water level probe circuit and simulates a Low Water Level alarm.<br>Pressing <b>RESET</b> resets the water level monitor circuit.<br>Pressing <b>CLEAR</b> resets the display.  |
| 8        | <b>FAULT</b> Indicator   | Red <b>FAULT</b> LED indicator lights when a boiler alarm condition occurs. An alarm message will appear in the VFD.   |
| 9        | <b>CLEAR</b> Key   | Turns off the <b>FAULT</b> indicator and clears the alarm message if the alarm is no longer valid. Lockout type alarms will be latched and cannot be cleared by simply pressing this key. Troubleshooting may be required to clear these types of alarms   |
| 10       | <u>MENU Keypad</u><br><br><b>MENU</b><br><br><b>BACK</b>   | Consists of 6 keys which provide the following functions for the Control Panel Menus:<br><b>MENU</b><br>Steps through the main menu categories shown in Figure 3-2. The Menu categories wrap around in the order shown.<br><b>BACK</b><br>Allows you to go back to the previous menu level without changing any information. Continuously pressing this key will bring you back to the default status display in the VFD. Also, this key allows you to go back to the top of a main menu category. |

# CONTROL PANEL OPERATING PROCEDURES

**Table 3-1. Operating Controls, Indicators and Displays - Continued**

| ITEM NO.      | CONTROL, INDICATOR OR DISPLAY  | FUNCTION   |
|---------------|--|--|
| 10<br>(Cont.) | <p style="margin: 0;">▲ (Up) Arrow</p> <p style="margin: 0;">▼ (Down) Arrow</p> <p style="margin: 0;"><b>CHANGE</b></p> <p style="margin: 0;"><b>ENTER</b></p> | <p>When in one of the main menu categories (Figure 3-2), pressing this key will select the displayed menu category. If the <b>CHANGE</b> key was pressed and the menu item is flashing, pressing the ▲ arrow key will increment the selected setting.</p> <p>When in one of the main menu categories (Figure 3-2), pressing this key will select the displayed menu category. If the <b>CHANGE</b> key was pressed and the menu item is flashing, pressing the ▼ (Down) arrow key will increment the selected setting.</p> <p>Permits a setting to be changed (edited). When the <b>CHANGE</b> key is pressed, the displayed menu item will begin to flash. Pressing the ▲ or ▼ arrow key when the item is flashing will increment or decrement the displayed setting.</p> <p>Saves the modified menu information in memory. The display will stop flashing.</p> |
| 11            | <b>AUTO/MAN</b> Switch   | <p>This switch toggles the boiler between the Automatic and Manual modes of operation. When in the Manual (<b>MAN</b>) mode, the front panel controls are enabled and the <b>MANUAL</b> status LED lights.</p> <p>When in the Automatic (<b>AUTO</b>) mode, the <b>MANUAL</b> status LED will be off and the front panel controls disabled.</p>  |
| 12            | <b>FIRE RATE</b> Bargraph  | 20 segment red LED bargraph continuously shows the Fire Rate in 5% increments from 0 to 100%   |

### 3.3. CONTROL PANEL MENUS

The Control Panel incorporates an extensive menu structure which permits the operator to set up, and configure the unit. The menu structure consists of four major menu categories as shown in Figure 3-2. Each of the menus shown, contain options which permit operating parameters to be viewed or changed. The menus are protected by a password to prevent unauthorized use.

Prior to entering the correct password, the options contained in the Operating, Setup, Configuration and Tuning Menu categories can be viewed. However, with the exception of Internal Setpoint Temperature (Configuration Menu), none of the viewable menu options can be changed.

Once the valid password (159) is entered, the options listed in the Setup, Configuration and Tuning menus can be viewed and changed, if desired.

#### 3.3.1. Menu Processing Procedure

Accessing each menu and option is accomplished using the Menu Keys shown in Figure 3-1. Therefore, it is imperative that you be thoroughly familiar with the following basic steps before attempting to perform specific menu procedures.

1. The Control Panel will normally be in the Operating Menu and the VFD will display the current unit status. Pressing the ▲ or ▼ arrow key will display the other available data items in the Operating Menu.
2. Press the **MENU** key. The display will show the Setup Menu which is the next menu category shown in Figure 3-2. This menu contains the Password option which must be entered if other menu options will be changed.
3. Continue pressing the **MENU** key until the desired menu is displayed.

# CONTROL PANEL OPERATING PROCEDURES

4. With the desired menu displayed, press the ▲ or ▼ arrow key. The first option in the selected menu will be displayed.
5. Continue to press the ▲ or ▼ arrow key until the desired menu option is displayed. Pressing the ▲ arrow key will display the available menu options in the Top-Down sequence. Pressing the ▼ arrow key will display the options in the Bottom-Up sequence. The menu options will wrap-around after the first or last available option is reached.
6. To change the value or setting of a displayed menu option, press the **CHANGE** key. The displayed option will begin to flash. Continue to press the ▲ or ▼ arrow key for the option to be changed. The available menu option choices will be displayed. The menu option choices do not wrap around.
7. To select and store a changed menu option, press the **ENTER** key.

## NOTE:

The following paragraphs provide brief descriptions of the options contained in each menu. Refer to Appendix A for detailed descriptions of each menu option. Refer to Appendix B for listings and descriptions of displayed startup, status and error messages.

### 3.4. OPERATING MENU

The Operating Menu displays a number of key operating parameters for the unit as listed in Table 3-2. This menu is "Read-Only" and does not allow personnel to change or adjust any of the displayed items. Since this menu is "Read-Only", it can be viewed at any time without entering a password. Press the ▲ arrow key to display the menu items in the order listed (Top-Down). Pressing the ▼ arrow key will display the menu items in reverse order (Bottom-Up).

### 3.5. SETUP MENU

The Setup Menu (Table 3-3) permits the operator to set the unit password which is required to change any of the menu options. To prevent unauthorized use, a previously entered password entry will time-out after 1 hour. Therefore, the password must be reentered when required. In addition to permitting password entries, the Setup Menu is also used to enter date and time, language to be used for display messages, units of temperature measurements and entries required for external communication and control of the unit via the RS-232 port. A view-only software version display is also provided to indicate the current Control Box software version.




Figure 3-2. Menu Structure



# CONTROL PANEL OPERATING PROCEDURES

## NOTE

The Outdoor Temp display item shown with an asterisk in Table 3-2 will not be displayed unless the Outdoor Sensor function has been enabled in the Configuration Menu (Table 3-4).

**Table 3-2. Operating Menu**

| Menu Item Display | Available Choices or Limits |               | Default |
|-------------------|-----------------------------|---------------|---------|
|                   | Minimum                     | Maximum       |         |
| Status Message    |                             |               |         |
| Active Setpoint   | 40°F                        | 240°F         |         |
| Aux Temp          | 30°F                        | 245°F         |         |
| Outdoor Temp*     | -70°F                       | 130°F         |         |
| Fire Rate In      | 0%                          | Max Fire Rate |         |
| Flame Strength    | 0%                          | 100%          |         |
| Run Cycles        | 0                           | 999,999       |         |
| Run Hours         | 0                           | 999,999       |         |
| Fault Log         | 0                           | 9             | 0       |

**Table 3-3. Setup Menu**

| Menu Item Display | Available Choices or Limits   |          | Default    |
|-------------------|-------------------------------|----------|------------|
|                   | Minimum                       | Maximum  |            |
| Passsword         | 0                             | 9999     | 0          |
| Language          | English                       |          | English    |
| Time              | 12:00 am                      | 11:59 pm |            |
| Date              | 01/01/00                      | 12/31/99 |            |
| Unit of Temp      | Fahrenheit<br>Celsius         |          | Fahrenheit |
| Comm Address      | 0                             | 127      | 0          |
| Baud Rate         | 2400<br>4800<br>9600<br>19.2K |          | 9600       |
| Software          | Ver 0.00                      | Ver 9.99 |            |

### 3.6. CONFIGURATION MENU

The Configuration Menu shown in Table 3-4 permits adjustment of the Internal Setpoint (Setpt) temperature regardless of whether the valid password has been entered. Setpt is required for operation in the Constant Setpoint mode. The remaining options in this menu require the valid password to be entered, prior to changing existing entries. This menu contains a number of other configuration settings which may or may not be displayed, depending on the current operating mode setting.

#### **NOTE:**

The Configuration Menu settings shown in Table 3-4 are Factory-Set in accordance with the requirements specified for each individual order. Therefore, under normal operating conditions, no changes will be required.

# CONTROL PANEL OPERATING PROCEDURES

**Table 3-4. Configuration Menu**

| Menu Item Display   | Available Choices or Limits  |                | Default            |
|---|--|----------------|--------------------|
|   | Minimum  | Maximum        |                    |
| Internal Setpt  | Lo Temp Limit  | Hi Temp Limit  | 130°F              |
| Unit Type   | Boiler<br>Water Heater   |                | Boiler             |
| Unit Size   | 0.5 MBTU<br>1.0 MBTU<br>1.5 MBTU<br>2.0 MBTU<br>2.5 MBTU<br>3.0 MBTU                 |                | 1.0 MBTU           |
| Boiler Mode   | Constant Setpoint<br>Remote Setpoint<br>Direct Drive<br>Combination<br>Outdoor Reset |                | Constant Setpoint  |
| Remote Signal<br>(If Mode = Remote Setpoint, Direct Drive or Combination) | 4 – 20 mA/1 – 5V<br>0 -20 mA/0 – 5V<br>PWM Input (BMS)<br>Network                    |                | 4 – 20 mA,<br>1-5V |
| Bldg Ref Temp<br>(If Boiler Mode = Outdoor Reset)                         | 40°F   | 240°F          | 70°F               |
| Reset Ratio<br>(If Boiler Mode = Outdoor Reset)                           | 0.1  | 9.9            | 1.2                |
| Outdoor Sensor  | Enabled or Disabled  |                | Disabled           |
| System Start Tmp<br>(If Outdoor Sensor = Enabled)                         | 30°F   | 100°F          | 60°F               |
| Setpt Lo Limit  | 40°F   | Setpt Hi Limit | 60°F               |
| Setpt Hi Limit  | Setpt Lo Limit   | 240°F          | 200°F              |
| Temp Hi Limit   | 40°F   | 240°F          | 215°F              |
| Max Fire Rate   | 40%  | 100%           | 100%               |
| Pump Delay Timer  | 0 min  | 30 min         | 0 min              |
| Aux Start On Dly  | 0 sec  | 120 sec        | 0 sec              |
| Failsafe Mode   | Shutdown or Constant Setpt   |                | Shutdown           |
| mA Output   | Setpoint, Outlet Temp,<br>Fire Rate Out, Off   |                | Off                |
| Lo Fire Timer   | 2 sec  | 120 sec        | 2 sec              |
| Setpt Limiting  | Enabled or Disabled  |                | Disabled           |
| Setpt Limit Band  | 0°F  | 10°F           | 5°F                |

# CONTROL PANEL OPERATING PROCEDURES

## 3.7. TUNING MENU

The Tuning Menu items in Table 3-5 are Factory set for each individual unit.

Do not change these menu entries unless specifically requested to do so by Factory-Trained personnel.

**Table 3-5. Tuning Menu**

| Menu Item Display | Available Choices or Limits |         | Default |
|-------------------|-----------------------------|---------|---------|
|                   | Minimum                     | Maximum |         |
| Prop Band         | 1°F                         | 120°F   | 70°F    |
| Integral Gain     | 0.00                        | 2.00    | 1.00    |
| Derivative Time   | 0.0 min                     | 2.0 min | 0.0 min |
| Reset Defaults?   | Yes<br>No<br>Are You Sure?  |         | No      |

## 3.8. START SEQUENCE

When the Control Box **ON/OFF** switch is set to the **ON** position, it checks all pre-purge safety switches to ensure they are closed. These switches include:


- Safety Shut-Off Valve Proof of Closure (POC) switch
- Low Water Level switch
- High Water Temperature switch
- High Gas Pressure switch
- Low Gas Pressure switch

If all of the above switches are closed, the **READY** light above the **ON/OFF** switch will light and the unit will be in the Standby mode.

When there is a demand for heat, the following events will occur:

**NOTE:**

If any of the Pre-Purge safety device switches are open, the appropriate fault message will be displayed. Also, the appropriate fault messages will be displayed throughout the start sequence, if the required conditions are not observed.



**Figure 3-3.**


**Safety Shut-Off Valve**

1. The **DEMAND** LED status indicator will light.
2. The unit checks to ensure that the proof of closure switch in the Safety Shut-Off Valve (SSOV) is closed (Figure 3-3).

3. With all required safety switches closed, a purge cycle will be initiated and the following events will occur:

# CONTROL PANEL OPERATING PROCEDURES


- (a) Blower relay energizes and turns on blower.
- (b) Air/Fuel Valve rotates to the full-open purge position and closes purge position switch. The dial on the Air/Fuel Valve (Figure 3-4) will read 100 to indicate that the valve is full-open (100%).
- (c) The **FIRE RATE** bargraph will show 100%.



**Figure 3-4.**

## Air/Fuel Valve In Purge Position

- 4. Next, the blower proof switch (Figure 3-5) closes and the display will show *Purging* and indicate the elapsed time of the purge cycle in seconds. The normal (default) time for the purge cycle is 7 seconds.




**Figure 3-5.**

## Blower Proof Switch

- 5. Upon completion of the purge cycle, the Control Box initiates an ignition cycle and the following events occur:
  - (a) The Air/Fuel Valve rotates to the low-fire ignition position and closes the ignition switch. The dial on the Air/Fuel Valve (Figure 3-6) will read between 25 and 35 to indicate that the valve is in the low-fire position.
  - (b) The igniter relay is activated and provides ignition spark.
  - (c) The gas Safety Shut Off Valve (SSOV) is energized (opened) allowing gas to flow into the Air/Fuel Valve.
- 6. Up to 7 seconds will be allowed for ignition to be detected. The igniter relay will be turned off one second after flame is detected.
- 7. After 2 seconds of continuous flame, *Flame Proven* will be displayed and the flame strength will be indicated. After 5 seconds, the current date and time will be displayed in place of the flame strength.

# CONTROL PANEL OPERATING PROCEDURES



8. With the unit firing properly, it will be controlled by the temperature controller circuitry. The **FIRE RATE** will be continuously displayed on the front panel bargraph.
9. Once the demand for heat has been satisfied, the Control Box will turn off the gas valve. The blower relay will be deactivated and the Air/Fuel Valve will be closed. *Standby* will be displayed.

### 3.9. START/STOP LEVELS

The start and stop levels are the fire rate percentages that start and stop the unit, based on load. These levels are Factory preset as follows:

- Start Level: 20%
- Stop Level: 16%

Normally, these settings should not require adjustment.

**Figure 3-6.**  
**Air/Fuel Valve In Ignition Position**



## SECTION 4 - INITIAL START- UP

### 4.1 INITIAL START- UP REQUIREMENTS

The initial start-up of the KC-1000 Low NOx Boiler is comprised of the following steps:

- Installation completed 100%
- Combustion calibration
- Proper setting of controls and limits
- Mode of operation settings (see Section 5)
- Safety device testing (see Section 6)

Installation procedures should be completed 100% before performing initial start-up. Also, the initial start-up must be complete prior to putting the unit into service. Starting a unit without the proper piping, venting, or electrical systems can be dangerous and void the product's warranty. These start-up instructions should be precisely followed in order for the unit to operate safely, at a high thermal efficiency, and with low flue gas emissions.

Initial unit start-up must be performed ONLY by AERCO factory trained start-up and service personnel. After following the steps in this section, it will be necessary to perform the mode of operation settings in Section 5, and the safety device test procedures in Section 6 to complete the initial unit start-up.

An AERCO Gas Fired Startup Sheet included with each KC-1000 must be completed for each unit for warranty validation and a copy must be returned promptly to AERCO at:

**AERCO International, Inc.**  
**159 Paris Ave.**  
**Northvale, NJ 07647**

**WARNING!**  
*DO NOT ATTEMPT TO FIRE THE UNIT WITHOUT FULL WATER LEVEL. THIS CAN SERIOUSLY DAMAGE THE UNIT AND MAY RESULT IN PERSONAL INJURY OR PROPERTY DAMAGE. THIS IS NOT COVERED BY WARRANTY.*

**CAUTION!**  
All installation procedures in Section 2 must be completed before attempting to start the unit.

### 4.2 TOOLS AND INSTRUMENTATION FOR COMBUSTION CALIBRATION

To properly perform combustion calibration on a KC Boiler equipped with a low NOx burner, the proper instruments and tools must be used and correctly installed on the unit. The following paragraphs outline the necessary tools and instrumentation as well as their installation.

#### 4.2.1 REQUIRED TOOLS AND INSTRUMENTATION


The following tools and instrumentation are necessary to perform combustion calibration of a low NOx unit:

1. Digital Combustion Analyzer - Oxygen accuracy to  $\pm 0.4\%$ ; Carbon Monoxide and NOx resolution to 1 PPM.
2. A 16" W.C. manometer and plastic tubing.
3. One 1/4" and two 1/8" NPT-to-barbed fittings for use with manometers.
4. AERCO differential gas pressure regulator adjustment tool P/N GM-122643 (one supplied per installation site)
5. Small and large flat blade screwdrivers.
6. 7/16" open end wrench and small adjustable wrenches.
7. Tube of silicone adhesive

#### 4.2.2 INSTALLING THE SUPPLY GAS MANOMETER

1. Close the main manual gas supply valve up stream of the unit.
2. Remove the 1/4" NPT pipe plug from the port on the inlet side of the safety shut off valve (see Figure 4.1).
3. Install a barbed fitting into the pipe plug tapping.
4. Attach one end of a length of plastic tubing to the barbed fitting and one end to the 16" W.C. manometer.


## INITIAL START-UP



**Figure 4.1**  
**1/8" Gas Plug Location**

### 4.2.3 PREPARING THE FLUE VENT PROBE HOLE


1. If the unit has been installed using the recommended AL29-4C vent, there will be a 3/8" hole, 18" to 24" above the exhaust manifold. The outer vent section, that covers vent connections must be loosened and moved to uncover the hole (see Figure 4.2).
2. If equipped with one, adjust the stop on the combustion analyzer probe so that it extends into the flue gas flow without hitting the opposite wall of the flue. Do not insert the probe at this time.



**Figure 4.2**  
**Analyzer Probe Hole Location**

### 4.2.4 INSTALLING THE DIFFERENTIAL REGULATOR ADJUSTMENT TOOL

1. First, remove the cap from the differential pressure regulator (see Figure 4.3).
2. Place the gasket from the regulator cap onto the regulator adjustment tool.
3. Prior to installing the tools on the regulator, pull up the tool's screwdriver blade. Then, thread the tool into the regulator.
4. Engage the tool's screwdriver blade into the regulator's adjustment screw slot.



**Figure 4.3**  
**Differential Regulator Adjustment Tool  
Installation**

### IMPORTANT

The unit is shipped from the factory set up for either natural gas or propane, as specified by the Style No. on the Sales Order. If desired, the unit can be easily switched from natural gas to propane (or vice versa) using the regulator spring change procedure in Appendix J.

For propane units, disregard paragraph 4.3 and proceed to paragraph 4.4.

### 4.3 NATURAL GAS COMBUSTION CALIBRATION

The KC-1000 is shipped combustion calibrated from the factory. Recalibration as part of a start-up is necessary due to differences in altitude, gas BTU content, gas supply piping and supply regulators. Factory test data sheets are shipped with each unit as a reference.

The following combustion calibration procedure closely follows the factory procedure. By following this procedure, readjustment of combustion will be kept to a minimum.



## INITIAL START-UP

1. Open the supply and return valves to the unit and ensure that the system pumps are running.
2. Open the gas supply valve(s) to the unit.
3. If a lockup style regulator is installed as a gas supply regulator, adjust the gas supply until a reading of 12" W.C. static pressure is obtained.
4. Set the **ON/OFF** switch to the **OFF** position. Turn on AC power to the unit. The display will show *LOSS OF POWER* and the time and date.
5. Set the unit to the Manual Mode by pressing the **AUTO/MAN** switch. A flashing *Manual Fire Rate* message will be displayed with the present rate in %. Also, the **MANUAL** LED will light.

### NOTE:

For a review of the control panel operating procedures, refer to Section 3.

6. Adjust the rate to 0% by pressing the ▼ arrow key.
7. Set the **ON/OFF** switch to the **ON** position.
8. Change the firing rate to 25% using the ▲ arrow key. This will put the unit into the starting sequence.

### NOTE:

On initial start-up, or return to service from a fault condition, the unit will remain at a 29% firing rate for two-minutes, although the control signal may indicate a greater input.

9. Following the warm-up period, increase the firing rate in 20% increments while monitoring the gas pressure after every increase. If gas pressure dips below 8.8" W.C. for FM gas trains and 9.2" for IRI gas trains at any input firing rate percentage, stop and raise the pressure. Once 100% is reached, adjust the gas pressure for 8.8" W.C. (FM) or 9.2" W.C. (IRI).

### NOTE:

If 8.8" W.C. for FM gas trains or 9.2" W.C. for IRI gas trains cannot be obtained at the 100% firing rate, it will be necessary to stop calibration and contact the local AERCO representative in your area. Running the unit on insufficient gas pressure will void the warranty

10. Once 8.8" W.C. or 9.2" W.C. is set at the 100% level change the firing rate to 30%. Insert the combustion analyzer probe into the stack.

### NOTE:

Always approach a firing rate percentage from the same direction, (i.e., 100% to 30%, 30% to 20%, etc.). Whenever going to an increased firing rate from below (i.e., 20% to 30%), first go above and then back down to the desired firing rate. This is necessary due to hysteresis in the air/fuel stepper motor. Hysteresis causes the air/fuel valve to stop in a slightly different position if the firing rate percentage is approached from below or above. This results in a difference in oxygen readings for the same firing rate percentage causing unnecessary recalibration.

11. Allow enough time for the combustion analyzer to settle. Compare the measured oxygen level to the oxygen range for intake air temperature in Table 1 (page 4-5). Also, ensure that the carbon monoxide (CO) and nitrogen oxide (NOx) readings do not exceed the values shown.
12. If the measured oxygen level, CO and NOx emissions are within the ranges shown in Table 1, no adjustment is necessary. Proceed to step 17.
13. If the measured oxygen level is below the range in Table 1, rotate the differential regulator adjustment tool counterclockwise 1/4 to 1/2 revolution to decrease gas flow.
14. Wait for the combustion analyzer to settle, then compare the new oxygen reading to Table 1. Repeat adjustment until oxygen is within the specified range.
15. If the measured oxygen level is above the oxygen range in Table 1, rotate the differential regulator adjustment tool clockwise 1/4 to 1/2 revolution to increase gas flow.
16. Wait for the analyzer reading to settle, then compare the new reading to Table 1. Repeat adjustment until oxygen is within the specified range.

### NOTE:

Adjust only the differential regulator at 30% control signal; do not adjust the air shutter.

17. Once the oxygen level is within the specified range at 30%, change the firing rate to 16%.


## INITIAL START-UP

- Oxygen levels at the 16% firing rate should be as shown in Table 2 (page 4-5). Also, ensure that the CO and NO<sub>x</sub> readings do not exceed the values shown. No adjustment should be necessary. Contact the Factory if the oxygen, CO or NO<sub>x</sub> levels are not within the specified ranges.

### NOTE:

At a 100% firing rate, the KC1000 will not operate reliably at inlet air temperatures below 55°F if the Cold Air Damper (P/N 99026) is not installed. See paragraphs 2.10.2 and 2.10.3.

- Change the firing rate to 100% and allow the combustion analyzer to settle. If the optional Cold Air Damper (P/N 99026) is installed, compare the measured oxygen level with the levels in Table 3. If the Cold Air Damper is not installed, compare the oxygen levels with the readings in Table 3A.
- If the measured oxygen reading is below the oxygen range in Table 3 (or 3A), loosen the two bolts that secure the inlet air shutter to the unit using a 7/16" wrench (see Figure 4.4). Open the shutter 1/4" to 1/2" to increase the oxygen level, then tighten the nuts.



**Figure 4.4**  
**Air Shutter Locking Nut Location**

- Wait for the analyzer to settle then compare the new oxygen reading to Table 3 (or 3A). Repeat the inlet air shutter adjustment until the oxygen is within the specified range. Also, ensure that the CO and NO<sub>x</sub> emissions do not exceed the values shown. Firmly tighten the inlet air shutter locking nuts when finished.

### REMINDER:

At 30% firing rate, adjust only the differential pressure regulator. At 100% firing rate, adjust only the inlet air shutter.

- If the measured oxygen reading is above the oxygen range in Table 3, loosen the two 7/16" locking nuts securing the inlet air shutter. Close the air shutter 1/4" to 1/2" to decrease the oxygen level and tighten the two nuts.
- Allow the analyzer to settle then compare the new oxygen reading to Table 3 (or 3A).
- Repeat the adjustment until the oxygen is within the specified range. Also, ensure that the CO and NO<sub>x</sub> readings do not exceed the values shown. Firmly tighten the inlet air shutter locking nuts when finished.

### NOTE:

Adjust the inlet air shutter only at 100% firing rate. Do Not adjust the differential pressure regulator.

- Change the firing rate to 30%. Allow time for the combustion analyzer to settle. Check the measured oxygen level, CO and NO<sub>x</sub> emissions to ensure that they are still within the ranges shown in Table 1.
- Continue these procedures until all oxygen levels are within the ranges specified in Tables 1, 2 and 3 (or 3A) on page 4-5.
- Record all readings on the AERCO start-up sheet provided with each unit. Proceed to **paragraph 4.5** when all natural gas combustion calibration procedures are completed.

# INITIAL START-UP

**Table 1**  
**Combustion Oxygen Levels for a 30% Firing Rate**

| Inlet Air Temp | Oxygen (±0.2%) | Carbon Monoxide | *NOx    |
|----------------|----------------|-----------------|---------|
| -25°F          | 7.8%           | <100 ppm        | <30 ppm |
| -10°F          | 7.5%           | <100 ppm        | <30 ppm |
| 0°F            | 7.4%           | <100 ppm        | <30 ppm |
| 10°F           | 7.2%           | <100 ppm        | <30 ppm |
| 25°F           | 6.9%           | <100 ppm        | <30 ppm |
| 40°F           | 6.5%           | <100 ppm        | <30 ppm |
| 55°F           | 6.4%           | <100 ppm        | <30 ppm |
| 70°F           | 6.2%           | <100 ppm        | <30 ppm |
| 85°F           | 5.9%           | <100 ppm        | <30 ppm |
| 100°F          | 5.7%           | <100 ppm        | N/A     |

\* NOx readings corrected to 3% oxygen.

**Table 2**  
**Combustion Oxygen Levels for a 16% Firing Rate**

| Inlet Air Temp | Oxygen (±0.2%) | Carbon Monoxide | *NOx    |
|----------------|----------------|-----------------|---------|
| -25°F          | <10%           | <100 ppm        | <30 ppm |
| -10°F          | <10%           | <100 ppm        | <30 ppm |
| 0°F            | <10%           | <100 ppm        | <30 ppm |
| 10°F           | <10%           | <100 ppm        | <30 ppm |
| 25°F           | <10%           | <100 ppm        | <30 ppm |
| 40°F           | <10%           | <100 ppm        | <30 ppm |
| 55°F           | <10%           | <100 ppm        | <30 ppm |
| 70°F           | <10%           | <100 ppm        | <30 ppm |
| 85°F           | <10%           | <100 ppm        | <30 ppm |
| 100°F          | <10%           | <100 ppm        | N/A     |

\* NOx readings corrected to 3% oxygen.

**Table 3**  
**Combustion Oxygen Levels for a 100% Firing Rate With Cold Air Damper**

| Inlet Air Temp | Oxygen (±0.2%) | Carbon Monoxide | *NOx    |
|----------------|----------------|-----------------|---------|
| -25°F          | 6.7            | <100 ppm        | <30 ppm |
| -10°F          | 6.5            | <100 ppm        | <30 ppm |
| 0°F            | 6.4            | <100 ppm        | <30 ppm |
| 10°F           | 6.3            | <100 ppm        | <30 ppm |
| 25°F           | 6.2            | <100 ppm        | <30 ppm |
| 40°F           | 6.1            | <100 ppm        | <30 ppm |
| 55°F           | 5.9            | <100 ppm        | <30 ppm |
| 70°F           | 5.8            | <100 ppm        | <30 ppm |
| 85°F           | 5.6            | <100 ppm        | <30 ppm |
| 100°F          | 4.7            | <100 ppm        | N/A     |

\* NOx readings corrected to 3% oxygen.

**Table 3A**  
**Combustion Oxygen Levels for a 100% Firing Rate Without Cold Air Damper**

| Inlet Air Temp | Oxygen (±0.2%) | Carbon Monoxide | *NOx    |
|----------------|----------------|-----------------|---------|
| 55°F           | 7.5%           | <100 ppm        | <30 ppm |
| 70°F           | 6.5%           | <100 ppm        | <30 ppm |
| 85°F           | 5.5%           | <100 ppm        | <30 ppm |
| 100°F          | 4.5%           | <100 ppm        | N/A     |

\* NOx readings corrected to 3% oxygen.

## IMPORTANT

The unit is shipped from the factory set up for either natural gas or propane, as specified by the Style No. on the Sales Order. If desired, the unit can be easily switched from natural gas to propane (or vice versa) using the regulator spring change procedure in Appendix J.

Since the required gas supply pressures for propane differ from those required for natural gas, the Propane Combustion Calibration procedures are repeated in their entirety in paragraph 4.4. It should be noted that the Combustion Calibration data in Tables 1, 2, 3 (and 3A) apply to both natural gas and propane units.

## 4.4 PROPANE COMBUSTION CALIBRATION

The KC-1000 is shipped combustion calibrated from the factory. Recalibration as part of a start-up is necessary due to differences in altitude, gas BTU content, gas supply piping and supply regulators. Factory test data sheets are shipped with each unit as a reference.

Prior to starting these procedures, ensure that the KC1000 has been set up as specified in paragraphs 4.2 through 4.2.4.

The following combustion calibration procedure closely follows the factory procedure. By following this procedure, readjustment of combustion will be kept to a minimum.

## INITIAL START-UP

1. Open the supply and return valves to the unit and ensure that the system pumps are running.
2. Open the gas supply valve(s) to the unit.
3. If a lockup style regulator is installed as a gas supply regulator, adjust the gas supply until a reading of 11" W.C. static pressure is obtained.
4. Set the **ON/OFF** switch to the **OFF** position. Turn on AC power to the unit. The display will show *LOSS OF POWER* and the time and date.
5. Set the unit to the Manual Mode by pressing the **AUTO/MAN** switch. A flashing *Manual Fire Rate* message will be displayed with the present rate in %. Also, the **MANUAL** LED will light.

### NOTE:

For a review of the control panel operating procedures, refer to Section 3.

6. Adjust the rate to 0% by pressing the ▼ arrow key.
7. Set the **ON/OFF** switch to the **ON** position.
8. Change the firing rate to 25% using the ▲ arrow key. This will put the unit into the starting sequence.

### NOTE:

On initial start-up, or return to service from a fault condition, the unit will remain at a 29% firing rate for two-minutes, although the control signal may indicate a greater input.

9. Following the warm-up period, increase the firing rate in 20% increments while monitoring the gas pressure after every increase. If gas pressure dips below 7.7" W.C. for FM gas trains and 8.1" for IRI gas trains at any input firing rate percentage, stop and raise the pressure. Once 100% is reached, adjust the gas pressure for 7.7" (FM) W.C. or 8.1" W.C. (IRI).

### NOTE:

If 7.7" W.C. for FM gas trains or 8.1" W.C. for IRI gas trains cannot be obtained at the 100% firing rate, it will be necessary to stop calibration and contact the local AERCO representative in your area. Running the unit on insufficient gas pressure will void the warranty

10. Once 7.7" W.C. or 8.1" W.C. is set at the 100% level change the firing rate to 30%. Insert the combustion analyzer probe into the stack.

### NOTE:

Always approach a firing rate percentage from the same direction, (i.e., 100% to 30%, 30% to 20%, etc.). Whenever going to an increased firing rate from below (i.e., 20% to 30%), first go above and then back down to the desired firing rate. This is necessary due to hysteresis in the air/fuel stepper motor. Hysteresis causes the air/fuel valve to stop in a slightly different position if the firing rate percentage is approached from below or above. This results in a difference in oxygen readings for the same firing rate percentage causing unnecessary recalibration.

11. Allow enough time for the combustion analyzer to settle. Compare the measured oxygen level to the oxygen range for intake air temperature in Table 1. Also, ensure that the carbon monoxide (CO) and nitrogen oxide (NOx) readings do not exceed the values shown.
12. If the measured oxygen level, CO and NOx emissions are within the ranges shown in Table 1, no adjustment is necessary. Proceed to step 17.
13. If the measured oxygen level is below the range in Table 1, rotate the differential regulator adjustment tool counterclockwise 1/4 to 1/2 revolution to decrease gas flow.
14. Wait for the combustion analyzer to settle, then compare the new oxygen reading to Table 1. Repeat adjustment until oxygen is within the specified range.
15. If the measured oxygen level is above the oxygen range in Table 1, rotate the differential regulator adjustment tool clockwise 1/4 to 1/2 revolution to increase gas flow.
16. Wait for the analyzer reading to settle, then compare the new reading to Table 1. Repeat adjustment until oxygen is within the specified range.

### NOTE:

Adjust only the differential regulator at 30% control signal; do not adjust the air shutter.

## INITIAL START-UP

17. Once the oxygen level is within the specified range at 30%, change the firing rate to 16%.
18. Oxygen levels at the 16% firing rate should be as shown in Table 2. Also, ensure that the CO and NOx readings do not exceed the values shown. No adjustment should be necessary. Contact the Factory if the oxygen, CO or NOx levels are not within the specified ranges.

### NOTE:

At a 100% firing rate, the KC1000 will not operate reliably at inlet air temperatures below 55°F if the Cold Air Damper (P/N 99026) is not installed. See paragraphs 2.10.2 and 2.10.3.

19. Change the firing rate to 100% and allow the combustion analyzer to settle. If the optional Cold Air Damper (P/N 99026) is installed, compare the measured oxygen level with the levels in Table 3. If the Cold Air Damper is not installed, compare the oxygen levels with the readings in Table 3A.
20. If the measured oxygen reading is below the oxygen range in Table 3 (or 3A), loosen the two bolts that secure the inlet air shutter to the unit using a 7/16" wrench (see Figure 4.4). Open the shutter 1/4" to 1/2" to increase the oxygen level, then tighten the nuts.
21. Wait for the analyzer to settle then compare the new oxygen reading to Table 3 (or 3A). Repeat the inlet air shutter adjustment until the oxygen is within the specified range. Also, ensure that the CO and NOx emissions do not exceed the values shown. Firmly tighten the inlet air shutter locking nuts when finished.

### REMINDER:

At 30% firing rate, adjust only the differential pressure regulator. At 100% firing rate, adjust only the inlet air shutter.

22. If the measured oxygen reading is above the oxygen range in Table 3, loosen the two 7/16" locking nuts securing the inlet air shutter. Close the air shutter 1/4" to 1/2" to decrease the oxygen level and tighten the two nuts.
23. Allow the analyzer to settle then compare the new oxygen reading to Table 3 (or 3A).
24. Repeat the adjustment until the oxygen is within the specified range. Also, ensure that

the CO and NOx readings do not exceed the values shown. Firmly tighten the inlet air shutter locking nuts when finished.

### NOTE:

Adjust the inlet air shutter only at 100% firing rate. Do Not adjust the differential pressure regulator.

25. Change the firing rate to 30%. Allow time for the combustion analyzer to settle. Check the measured oxygen level, CO and NOx emissions to ensure that they are still within the ranges shown in Table 1.
26. Continue these procedures until all oxygen levels are within the ranges specified in Tables 1, 2 and 3.
27. Record all readings on the AERCO start-up sheet provided with each unit. Proceed to paragraph 4.5 when all propane combustion calibration procedures are completed.

## 4.5 UNIT REASSEMBLY

Once combustion calibration is set properly, the unit can be re-assembled for permanent operation.

1. Set the **ON/OFF** switch to the **OFF** position. Disconnect the AC power supply from the unit.
2. Shut off the gas supply to the unit.
3. Remove the regulator adjustment tool by first pulling up the screwdriver blade to disengage it from the regulator adjusting screw, and then turning the tool out of the top of the regulator.
4. Apply a drop of silicone adhesive to the regulator adjusting screw to lock its setting.
5. Remove the gasket from the tool and place it back onto the regulator cap.
6. Reinstall the cap and gasket back on the regulator. Tighten the cap using a screwdriver or wrench.
7. Remove all of the manometers and barbed fittings and reinstall the pipe plugs using a suitable thread compound.
8. Remove the combustion analyzer probe from the vent hole. Seal the probe hole and replace the vent connection cover.
9. Replace the unit's panels and hood.



# INITIAL START-UP

## 4.6 OVER TEMPERATURE LIMIT SWITCH ADJUSTMENTS

There are two Over-Temperature Limit switches that turn off the unit when the outlet water temperature becomes too hot. The lower over-temperature limit switch is adjustable and should be adjusted 20° to 40°F above the operating header temperature. The upper over-temperature limit switch is a manual reset device and is not adjustable. It will shut the unit off if the water temperature reaches 240°F. **DO NOT** attempt to adjust its setpoint.

To adjust the lower over temperature switch limit switch:

1. Remove the wing nut from the top center of the shell cap. Lift the cap off the shell.
2. The two over-temperature limit switches are located at the top of the shell (see Fig. 4.6). Do not adjust the upper switch it has been factory preset. Adjust the lower switch between 20° to 40°F higher than the maximum header temperature the unit may see.
3. Replace the shell cap and wing nut.



**Figure 4.6**  
**Over Temperature Limit Switch Location**

## SECTION 5 - MODE OF OPERATION

### 5.1 INTRODUCTION

The following paragraphs provide detailed descriptions of the six different modes of operation for the KC1000 Boiler. Each unit is shipped from the factory tested and configured for the ordered mode of operation. All temperature related parameters are at factory defaults and work well in most applications. However, it may be necessary to change certain parameters to customize the unit to the system. A complete listing and descriptions of the temperature related parameters are included in Appendix A. Factory defaults are listed in Appendix E. After reading this section, parameters can be customized to suit the needs of the specific application.

### 5.2 INDOOR/OUTDOOR RESET MODE

This mode of operation is based on outside air temperatures. As the outside air temperature decreases, the supply header temperature will increase and vice versa. For this mode, it is necessary to install an outside air sensor as well as select a building reference temperature and a reset ratio.

#### 5.2.1 RESET RATIO

Reset ratio is an adjustable number from 0.1 to 9.9. Once it is adjusted, the supply header temperature will increase by that number for each degree that the outside air temperature decreases. For instance, if a reset ratio of 1.6 is used, for each degree that outside air temperature decreases the supply header temperature will increase by 1.6 degrees.

#### 5.2.2. BUILDING REFERENCE TEMPERATURE

This is a temperature from 40°F to 240°F. Once selected, it is the temperature that the system references to begin increasing its temperature. For instance, if a reset ratio of 1.6 is used and we select a building reference temperature of 70°F, then at an outside temperature of 69°F, the supply header temperature will increase by 1.6° to 71.6°F.

#### 5.2.3 OUTDOOR AIR TEMPERATURE SENSOR INSTALLATION

The outdoor air temperature sensor must be mounted on the North side of the building in an area where the average outside air temperature

is expected. The sensor must be shielded from the sun's direct rays, as well as from direct impingement by the elements. If a cover or shield is used, it must allow free air circulation. The sensor may be mounted up to 200 feet from the unit. Sensor connections are made inside the Input/Output (I/O) Box on the left side of the KC1000 Boiler. Connections are made at the terminals labeled OUTDOOR SENSOR IN and SENSOR COMMON inside the I/O Box using shielded 18 to 22 AWG wire. A wiring diagram is provided on the cover of the I/O Box. Refer to Section 2, paragraph 2.6.2 for additional wiring information.

### 5.2.4 INDOOR/OUTDOOR STARTUP

1. Refer to the indoor/outdoor reset ratio charts in Appendix D.
2. Choose the chart corresponding to the desired building reference temperature.
3. Go down the left column of the chart to the coldest design outdoor air temperature expected in your area.

**NOTE:**

A design engineer typically provides design outdoor air temperature and supply header temperature data

4. Once the design outdoor air temperature is chosen, go across the chart to the desired supply header temperature for the design temperature chosen in step 3.
5. Next, go up that column to the Reset Ratio row to find the corresponding reset ratio.
6. Access the Configuration Menu and scroll through it until the display shows *Bldg Ref Temp (Building Reference Temperature)*.
7. Press the **CHANGE** key. The display will begin to flash.
8. Use the **▲** and **▼** arrow keys to select the desired building reference temperature.
9. Press **ENTER** to save any changes.
10. Next, scroll through the Configuration Menu until the display shows *Reset Ratio*.

## MODE OF OPERATION

11. Press the **CHANGE** key. The display will begin to flash.
12. Use the **▲** and **▼** arrow keys to select the reset ratio determined in step 5.
13. Press **ENTER** to save the change.

Refer to paragraph 3.3 for detailed instructions on menu changing.

### 5.3 CONSTANT SETPOINT MODE

The Constant Setpoint mode is used when a fixed header temperature is desired. Common uses of this mode of operation include water source heat pump loops, and indirect heat exchangers for potable hot water systems or processes.

There are no external sensors necessary to operate in this mode. While it is necessary to set the desired setpoint temperature, it is not necessary to change any other temperature-related functions. The unit is factory preset with settings that work well in most applications. Prior to changing any temperature-related parameters, other than the setpoint, it is suggested that an AERCO representative be contacted. For a complete listing of factory defaults and descriptions of temperature related functions, see Appendices A and E.

#### 5.3.1 SETTING THE SETPOINT

The setpoint temperature of the unit is adjustable from 40°F to 240°F. To set the unit for operation in the Constant Setpoint Mode, the following menu settings must be made in the Configuration Menu:

| MENU OPTION           | SETTING  |
|-----------------------|--|
| <i>Boiler Mode</i>    | <i>Constant Setpoint</i>   |
| <i>Internal Setpt</i> | Select desired setpoint using <b>▲</b> and <b>▼</b> arrow keys (40°F to 240°F) |

Refer to paragraph 3.3 for detailed instructions on changing menu options.

### 5.4 REMOTE SETPOINT MODES

The unit's setpoint can be remotely controlled by an Energy Management System (EMS) or Building Automation System (BAS). The Remote Setpoint can be driven by a current or voltage signal within the following ranges:

4-20 mA/1-5 Vdc

0-20 mA/0-5 Vdc

The factory default setting for the Remote Setpoint mode is 4 - 20 mA/1 - 5 Vdc. With this setting, a 4 to 20 mA/1 to 5 Vdc signal, sent by an EMS or BAS, is used to change the unit's setpoint. The 4 mA/1V signal is equal to a 40°F setpoint while a 20 mA /5V signal is equal to a 240°F setpoint. When a 0 to 20 mA/0 to 5 Vdc signal is used, 0 mA is equal to a 40°F setpoint.

In addition to the current and voltage signals described above, the Remote Setpoint mode can also be driven by a RS485 Modbus Network signal from an EMS or BAS.

The Remote Setpoint modes of operation can be used to drive single as well as multiple units.

#### NOTE:

If a voltage, rather than current signal is used to control the remote setpoint, a DIP switch adjustment must be made on the PMC Board in the Control Box. Contact your local AERCO representative for details.

In order to enable the Remote Setpoint Mode, the following menu setting must be made in the Configuration Menu:

| MENU OPTION   | SETTING                                    |
|---------------|--|
| Boiler Mode   | Remote Setpoint                            |
| Remote Signal | 4-20mA/1-5V,<br>0-20mA/0-5V, or<br>Network |

Refer to paragraph 3.3 for detailed instructions on changing menu options.



# MODE OF OPERATION

If the Network setting is selected for RS485 Modbus operation, a valid Comm Address must be entered in the Setup Menu. Refer to Modbus Communication Manual GF-114 for additional information.

While it is possible to change the settings of temperature related functions, the unit is factory preset with settings that work well in most applications. It is suggested that an AERCO representative be contacted, prior to changing any temperature related function settings. For descriptions of temperature-related functions and their factory defaults, refer to Appendices A and E.

## 5.4.1 REMOTE SETPOINT FIELD WIRING

The only wiring connections necessary for the Remote Setpoint mode are connection of the remote signal leads from the source to the unit's I/O Box. The I/O Box is located on the front panel of the Benchmark Boiler. For either a 4-20mA/0-5V or a 0-20mA/0-5V setting, the connections are made at the ANALOG IN terminals in the I/O Box. For a Network setting, the connections are made at the RS-485 COMM terminals in the I/O Box. The signal must be floating, (ungrounded) at the I/O Box and the wire used must be a two wire shielded pair from 18 to 22 AWG. Polarity must be observed. The source end of the shield must be connected at the source. When driving multiple units, each unit's wiring must conform to the above.

## 5.4.2 REMOTE SETPOINT STARTUP

Since this mode of operation is factory preset and the setpoint is being externally controlled, no startup instructions are necessary. In this mode, the **REMOTE** LED will light when the external signal is present.

To operate the unit in the Manual mode, press the **AUTO/MAN** switch. The **REMOTE** LED will go off and the **MANUAL** LED will light.

To change back to the Remote Setpoint mode, simply press the **AUTO/MAN** switch. The **REMOTE** LED will again light and the **MANUAL** LED will go off.

## 5.5 DIRECT DRIVE MODES

The unit's fire rate can be changed by a remote signal which is typically sent from an Energy Management System (EMS) or from a Building Automation System (BAS). The Direct Drive mode can be driven by a current or voltage signal within the following ranges:

4-20 mA/1-5 Vdc

0-20 mA/0-5 Vdc

The factory default setting for the Direct Drive mode is 4-20 mA/1-5 Vdc. With this setting, a 4 to 20 mA signal, sent by an EMS or BAS is used to change the unit's fire rate from 0% to 100%. A 4 mA/1V signal is equal to a 0% fire rate, while a 20 mA /5V signal is equal to a 100% fire rate. When a 0-20 mA/0-5 Vdc signal is used, zero is equal to a 0% fire rate.

In addition to the current and voltage signals described above, the Direct Drive mode can also be driven by a RS485 Modbus Network signal from an EMS or BAS.

When in a Direct Drive mode, the unit is a slave to the EMS or BAS and does not have a role in temperature control. Direct Drive can be used to drive single, or multiple units.

### NOTE:

If a voltage, rather than current signal is used to control the fire rate, a DIP switch adjustment must be made on the PMC Board in the Control Box. Contact your local AERCO representative for details.

To enable the Direct Drive Mode, the following menu setting must be made in the Configuration Menu:

| MENU OPTION   | SETTING                                    |
|---------------|--|
| Boiler Mode   | Direct Drive                               |
| Remote Signal | 4-20mA/1-5V,<br>0-20mA/0-5V, or<br>Network |

Refer to paragraph 3.3 for instructions on changing menu options.

## MODE OF OPERATION

If the Network setting is selected for RS485 Modbus operation, a valid Comm Address must be entered in the Setup Menu. Refer to Modbus Communication Manual GF-114 for additional information.

### 5.5.1 DIRECT DRIVE FIELD WIRING

The only wiring connections necessary for Direct Drive mode are connection of the remote signal leads from the source to the unit's I/O Box. For either a 4-20mA/0-5V or a 0-20mA/0-5V setting, the connections are made at the ANALOG IN terminals in the I/O Box. For a Network setting, the connections are made at the RS-485 COMM terminals in the I/O Box. The signal must be floating, (ungrounded) at the I/O Box and the wire used must be a two wire shielded pair from 18 to 22 AWG. Polarity must be observed. The source end of the shield must be connected at the source. When driving multiple units, each unit's wiring must conform to the above.

### 5.5.2 DIRECT DRIVE STARTUP

Since this mode of operation is factory preset and the fire rate is being externally controlled, no startup instructions are necessary. In this mode, the **REMOTE** LED will light when the signal is present.

To operate the unit in manual mode, press the **AUTO/MAN** switch. The **REMOTE** LED will go off and the **MANUAL** LED will light.

To change back to the Direct Drive mode, simply press the **AUTO/MAN** switch. The **REMOTE** LED will again light and the **MANUAL** LED will go off.

## 5.6 BOILER MANAGEMENT SYSTEM (BMS) MODE

### NOTE

BMS Model 168 can utilize either pulse width modulation (PWM) or RS485 Modbus signaling to the Boiler. BMS II Model 5R5-384 can utilize only RS485 signaling to the Boiler.

The BMS mode of operation is used in conjunction with an AERCO Boiler Management System. The BMS mode is used when it is desired to operate multiple units in the most efficient manner possible. The BMS can control up to 40 boilers; 8 via pulse width modulation (PWM) and up to 32 via Modbus (RS485) network communication. For BMS programming

and operation, see GF-108M (BMS Model 168) and GF-124 (BMS II Model 5R5-384), BMS Operations Guides. For operation via an RS485 Modbus network, refer to Modbus Communication Manual GF-114.

To enable the BMS Mode, the following menu settings must be made in the Configuration Menu:

| MENU OPTION   | SETTING                                  |
|---------------|--|
| Boiler Mode   | Direct Drive                             |
| Remote Signal | BMS (PWM Input)<br>or<br>Network (RS485) |

Refer to paragraph 3.3 for instructions on changing menu options.

### 5.6.1 BMS EXTERNAL FIELD WIRING

Wiring connections for BMS control using PWM signaling are made between connector JP2 on the BMS panel (boilers 1 through 8), and the B.M.S. (PWM) IN terminals in the I/O Box on the front of the Benchmark Boilers. Refer to the wiring diagram provided on the cover of the I/O Box.

Wiring connections for RS485 Modbus control are made between connector JP11 on the BMS (boilers 9 through 40) and the RS485 COMM terminals in the I/O Box on the front of the unit.

Wire the units using shielded twisted pair wire between 18 and 22 AWG. Observe the proper polarity for the B.M.S. (PWM) IN and/or RS485 COMM wiring connections. Shields should be terminated only at the BMS and the boiler end must be left floating. Each unit's wiring must conform to the above.

### 5.6.2 BMS SETUP AND STARTUP

This mode of operation is factory preset and the AERCO BMS controls the firing rate. There are no setup instructions for each individual unit.

To operate the unit in manual mode, press the **AUTO/MAN** switch. The **REMOTE** LED will go off and the **MANUAL** LED will light

To change back to the BMS mode, simply press the **AUTO/MAN** switch. The **REMOTE** LED will again light and the **MANUAL** LED will go off.

## MODE OF OPERATION

### 5.7 COMBINATION CONTROL SYSTEM (CCS)

#### NOTE

Only BMS Model 168 can be utilized for the Combination Mode, not the BMS II (Model 5R5-384).

A Combination Control System (CCS) is one that uses multiple boilers to cover both space-heating and domestic hot water needs. An AERCO Boiler Management System (BMS) Model 168 and a Combination Control Panel (CCP) are necessary to configure this system. Typically, an adequate number of boilers are installed to cover the space-heating load on the design day, however one or more units are used for the domestic hot water load.

The theory behind this type of system is that the maximum space-heating load and the maximum domestic hot water load do not occur simultaneously. Therefore, boilers used for the domestic hot water are capable of switching between constant setpoint and BMS modes of operation. These boilers are the combination units and are referred to as the combo boilers. The combo boilers heat water to a constant setpoint temperature. That water is then circulated through a heat exchanger in a domestic hot water storage tank.

When the space-heating load is such that all the space-heating boilers are at 100% firing rate, the BMS will then ask the Combination Control Panel for the domestic boilers to become space-heating boilers. Provided the domestic hot water load is satisfied, the combo (hot water) boilers will then become space-heating boilers. If the domestic hot water load is not satisfied, the combo boiler(s) remain on the domestic hot water load. If the combo boilers switch over to space heating, but there is a call for domestic hot water, the CCP switches the combo units back to the domestic load.

When the combo units are satisfying the domestic load they are in constant setpoint mode of operation. When the combo units switch over to space heating, their mode of operation changes to the BMS mode. For more information concerning the operation of the Combination Control Panel see the AERCO CCP-1 literature.

### 5.7.1 COMBINATION CONTROL SYSTEM FIELD WIRING

Wiring for this system is between the BMS Model 168 panel, the CCP and the B.M.S. (PWM) IN terminals in the I/O Box. Wire the units using a shielded twisted pair of 18 to 22 AWG wire. When wiring multiple units, each unit's wiring must conform to the above. For a complete CCP system-wiring diagram see the AERCO CCP-1 literature.

### 5.7.2 COMBINATION CONTROL SYSTEM SETUP AND STARTUP

Setup for the Combination Mode requires entries to be made in the Configuration Menu for boiler mode, remote signal type and setpoint. The setpoint is adjustable from 40°F to 240°F.

Enter the following settings in the Configuration Menu:

| MENU OPTION    | SETTING         |
|----------------|-----------------|
| Boiler Mode    | Combination     |
| Remote Signal  | BMS (PWM Input) |
| Internal Setpt | 40°F to 240°F   |

Refer to paragraph 3.3 for instructions on changing menu options.

While it is possible to change other temperature-related functions for combination mode, these functions are preset to their factory default values. These default settings work well in most applications. It is suggested that AERCO be contacted prior to changing settings other than the unit's setpoint. For a complete listing of temperature related function defaults, see Appendix E.

To set the unit to the manual mode, press the **AUTO/MAN** switch. The **MANUAL** LED will light.

To set the unit back to the auto mode, press the **AUTO/MAN** switch. The **MANUAL** LED will go off and the **REMOTE** LED will light.

When the boiler is switched to BMS mode, the AERCO BMS controls the firing rate. There are no setup requirements to the boiler(s) in this mode.



# SAFETY DEVICE TESTING

## SECTION 6-SAFETY DEVICE TESTING PROCEDURES

### 6.1 TESTING OF SAFETY DEVICES

Periodic testing of all controls and safety devices is required to insure that they are operating as designed. Precautions must be taken while tests are being performed to protect against bodily injury and property damage.

Systematic and thorough testing of the operating and safety controls should be performed on a scheduled basis, or whenever a control component has been serviced or replaced. All testing must conform to local jurisdictions or codes such as ASME CSD-1.

**NOTE:**

MANUAL and AUTO modes are required to perform the following tests. For a complete explanation of these modes, see Section 3.

**NOTE:**

It will be necessary to remove the sheet metal covers and cap from the unit to perform the following tests.


**WARNING!**

*ELECTRICAL VOLTAGES USED IN THIS SYSTEM INCLUDE 120 AND 24 VOLTS AC. POWER MUST BE REMOVED PRIOR TO PERFORMING WIRE REMOVAL OR OTHER TESTING PROCEDURES THAT CAN RESULT IN ELECTRICAL SHOCK.*

### 6.2 LOW GAS PRESSURE FAULT TEST

1. Shut off the gas supply to the unit.
2. Install a 0-16" W.C. manometer in the gas pipe assembly below the low gas pressure switch. (See Fig. 6.1)
3. Open the gas supply to the unit and depress the **CLEAR** button to clear any displayed fault messages..
4. Place the unit in Manual Mode and fire the unit at a firing rate between 25% and 30%.
5. Slowly close the manual gas supply valve while monitoring the gas pressure. The unit should fault and shutdown on *LOW GAS PRESSURE* when the manometer indicates approximately 6.5" W.C.

6. Open the gas supply to the unit and press the **CLEAR** button on the Control Box.
7. The unit should restart.



**Figure 6.1**  
**1/8" Pipe Plug Position for Manometer Installation**


**NOTE:**

After faulting the unit, the fault message will be displayed and the fault indicator light will flash until the **CLEAR** button is pressed.

### 6.3 HIGH GAS PRESSURE TEST

1. Start the unit in manual mode and fire between 25% and 30%.
2. Remove either wire # 150 or wire #151 from the high gas pressure switch. See Fig. 6.2.
3. The unit should shut down on a *HIGH GAS PRESSURE FAULT*.
4. Reconnect the wire previously removed from the high gas pressure switch and depress the **CLEAR** button.
5. The unit should restart.

# SAFETY DEVICE TESTING



**Figure 6.2**  
**High Gas Pressure Switch**

## 6.4 LOW WATER LEVEL FAULT TEST


1. Set the **ON/OFF** switch in the **OFF** position.
2. Close shut-off valves in the supply and return piping to the unit.
3. Open the drain valve on the unit.
4. Allow air flow into the unit by either opening the relief valve or by removing the 1/4" plug in the top of the unit.
5. The **LOW WATER LEVEL** message will be displayed and the **FAULT** LED will flash after the water level has gone below the level of the probe.
6. Set the **ON/OFF** switch to **ON**. The **READY** light should remain off and the unit should not start. If the unit does start, shut the unit off immediately and refer fault to qualified service personnel.
7. Close the drain and pressure relief valve or reinstall the plug in the top of the unit if removed.
8. Open the water shut-off valve in the return piping to the unit to fill the shell.
9. Open the water shut-off valve in the supply piping to the unit.
10. After the shell is full, press the **LOW WATER LEVEL RESET** button to reset the

low water cutoff. Press the **CLEAR** button to reset the **FAULT** LED and clear the error message.

11. Set the **ON/OFF** switch to the **ON** position. The unit is now ready for operation.

## 6.5 WATER TEMPERATURE FAULT TEST

1. In the normal operating mode, allow the unit to stabilize at its setpoint.
2. Lower the adjustable temperature limit switch setting to match the outlet water temperature. (See Fig. 6.3).



**Figure 6.3**  
**Temperature Limit Switch Setting**

3. Once the switch setting is approximately at the actual water temperature, the unit should shutdown. The red **FAULT** LED should be flashing and the message **HIGH WATER TEMP SWITCH OPEN** should be displayed. The unit should not start.
4. Reset the temperature limit switch setting to its prior setting.
5. The unit should start once the adjustable temperature limit switch setting is above the actual outlet water temperature.

# SAFETY DEVICE TESTING

## 6.6 INTERLOCK TESTS

The unit is equipped with two interlock circuits called the Remote Interlock and the Delayed Interlock. Terminal connections for these circuits are located in the I/O Box and are labeled REMOTE INTL'K IN and DELAYED INTL'K IN. These circuits can shut down the unit in the event that an interlock is opened. These interlocks are shipped from the factory jumped (closed). However, each of these interlocks may be utilized in the field as a remote stop and start, an emergency cut-off, or to prove that a device such as a pump gas booster, or louver is operational.

### 6.6.1 REMOTE INTERLOCK


1. Remove the cover from the I/O Box and locate the REMOTE INTL'K IN terminals.
2. Start the unit in manual mode and fire at 25% to 30% firing rate.
3. If there is a jumper across the REMOTE INTL'K IN terminals, remove one side of the jumper. If the interlock is being controlled by an external device, either open the interlock via the external device or disconnect one of the wires leading to the external device.
4. The unit should shut down and display *INTERLOCK OPEN*.
5. Once the interlock connection is reconnected, the *INTERLOCK OPEN* message should automatically clear and the unit should resume running.

### 6.6.2 DELAYED INTERLOCK

1. Remove the cover from the I/O Box and locate the DELAYED INTL'K IN terminals.
2. Start the unit in manual mode and fire at a 25% to 30% firing rate.
3. If there is a jumper across the DELAYED INTL'K IN terminals, remove one side of the jumper. If the interlock is connected to a proving switch of an external device, disconnect one of the wires leading to the proving switch.
4. The unit should shut down and display *DELAYED INTERLOCK OPEN*. The **FAULT** LED should be flashing.
5. Once the interlock connection is reconnected, depress the **CLEAR** button. The unit should start.

## 6.7 FLAME FAULT TEST

1. Place the **ON/OFF** switch in the **OFF** position.
2. Place the unit in the Manual Mode and set the firing rate between 25% and 30%.
3. Close the manual leak detection valve located between the safety shut-off valve and the differential regulator (see Fig. 6.4).
4. Start the unit.
5. The unit should shut down after reaching the Ignition cycle and display *FLAME LOSS DURING IGN.*
6. Open the valve previously closed in step 3 and depress the **CLEAR** button.
7. Restart the unit and allow it to prove flame.
8. Once flame is proven, close the manual leak detection valve located between the safety shut-off valve and the differential regulator.
9. The unit should shut down and display *FLAME LOSS DURING RUN.*
10. Open the valve previously closed in step 8 and depress the **CLEAR** button. The unit should restart and fire.




**Figure 6.4**  
**Manual Leak Detection Valve**

# SAFETY DEVICE TESTING

## 6.8 AIR FLOW FAULT TEST

1. Start the unit in manual mode and set the fire rate between 25% and 30%.
2. Once the unit has proved flame, remove either wire #154 or #155 from the blower proof switch (see Fig. 6.5) located on the air/fuel valve.
3. The unit should shut down and display *AIRFLOW FAULT DURING RUN*.
4. Replace the wire previously removed from the blower-proof switch and depress the **CLEAR** button. The unit should restart.


**WARNING!**  
*ELECTRICAL VOLTAGES USED IN THIS SYSTEM INCLUDE 120 AND 24 VOLTS AC. POWER MUST BE REMOVED PRIOR TO PERFORMING WIRE REMOVAL OR OTHER TESTING PROCEDURES THAT CAN RESULT IN ELECTRICAL SHOCK.*



**Figure 6.5**  
**Blower Proof Switch Location and Wiring**

## 6.9 SSOV PROOF OF CLOSURE SWITCH

1. Set the unit's **ON/OFF** switch to the **OFF** position. Place the unit in manual mode and set the fire rate between 25% and 30%.
2. Remove the Safety Shut-Off Valve (SSOV) cover to access the terminal connections. See Fig. 6.6. For units with IRI gas trains, access the terminals of the downstream SSOV (see drawing SD-A-660 in Appendix F).
3. Remove either wire #149 or #148 from the SSOV.
4. The unit should fault and display *SSOV SWITCH OPEN*.
5. Replace the wire previously removed and depress the **CLEAR** button.
6. Start the unit.
7. Remove the wire again when the unit reaches the purge cycle.
8. The unit should shut down and display *SSOV FAULT DURING PURGE*.
9. Replace the wire on the SSOV and depress the **CLEAR** button. The unit should restart.




**Figure 6.6**  
**SSOV Actuator Cover Screw Location**



## SAFETY DEVICE TESTING

### 6.10 PURGE SWITCH OPEN DURING PURGE


1. Set the unit's **ON/OFF** switch to the **OFF** position. Place the unit in manual mode and set the fire rate between 25% and 30%
2. Remove the air/fuel valve cover by rotating the cover counterclockwise to unlock it and then pulling it towards you. See Fig. 6.7.
3. Remove one of the two wires from the purge switch (Fig. 6.8) and start the unit.
4. The unit should begin to start, then shut down and display *PRG SWITCH OPEN DURING PURGE*.
5. Replace the wire on the purge switch and depress the **CLEAR** button. The unit should restart.



**Figure 6.7**  
Air/Fuel Valve Cover Location

### 6.11 IGNITION SWITCH OPEN DURING IGNITION

1. Set the unit's **ON/OFF** switch to the **OFF** position. Place the unit in manual mode and set the fire rate between 25% and 30%.
2. Remove the air/fuel valve cover (Fig. 6.7) by rotating the cover counterclockwise to unlock it then pulling it towards you.
3. Remove one of the two wires from the ignition switch (Fig. 6.8) and start the unit.
4. The unit should begin to start then shut down and display *IGN SWITCH OPEN DURING IGNITION*.
5. Replace the wire on the ignition switch and depress the **CLEAR** button. The unit should restart.



**Figure 6.8**  
Air/Fuel Valve Purge and Ignition Switch Locations

## **SAFETY DEVICE TESTING**

### **6.12 SAFETY PRESSURE RELIEF VALVE TEST**

Test the unit's Safety Pressure Relief Valve in accordance with ASME Boiler and Pressure Vessel Code, Section VI.

## SECTION 7 - MAINTENANCE

### 7.1 MAINTENANCE SCHEDULE

The unit requires regular routine maintenance to keep up efficiency and reliability. For best operation and life of the unit, the routine maintenance procedures listed in Table 1 should be performed within the specified time periods.

**Table 1 Maintenance Schedule**

| Para | Item                      | 6 Mos.  | 12 Mos.         | 24 Mos.                   | Labor Time |
|------|---------------------------|---------|-----------------|---------------------------|------------|
| 7.2  | Spark Igniter             | Inspect | Replace         |                           | 20 mins.   |
| 7.3  | Flame Detector            | Inspect | Replace         |                           | 20 mins.   |
| 7.4  | Combustion Cal.           | Check   | Check           |                           | 1 hr.      |
| 7.5  | Testing of Safety Devices |         | Test            |                           | 20 mins.   |
| 7.6  | *Manifold & Tubes         |         |                 | Inspect & clean if needed | 4 hrs.     |
| 7.7  | Water Side Inspection     |         |                 | Inspect                   | 2 hr.      |
| 7.8  | Condensate Drain          |         | Inspect & clean |                           | 30 mins.   |

*\* Recommended only when unit will be run in an extreme condensing mode for prolonged periods of time.*

#### **WARNING!**

**TO AVOID PERSONAL INJURY, BEFORE SERVICING:**

**(A) DISCONNECT AC POWER FROM THE UNIT.**

**(B) SHUT OFF THE GAS SUPPLY TO THE UNIT.**

**(C) ALLOW THE UNIT TO COOL TO A SAFE TEMPERATURE.**


### 7.2 SPARK IGNITER

The spark igniter assembly is located in the body of the burner (Figure 7.1). The igniter may be HOT. Care should be exercised. It is easier to remove the igniter from the unit after the unit has cooled to room temperature.

To inspect or replace the Igniter :

1. Set the **ON/OFF** switch on the control panel to the **OFF** position and disconnect AC power from the unit.

2. To access the spark igniter, remove the unit's left side panel and left rear cover.
3. Disconnect the igniter cable from the igniter contact.
4. Using a 15/16" open-end wrench, remove the igniter from the burner shell.
5. Inspect the igniter for erosion or carbon build-up. If there is substantial erosion of the spark gap or ground electrode, the igniter should be replaced. If carbon build-up is present, clean the igniter using fine emery cloth. Repeated carbon build-up on the igniter is an indication that a check of the combustion settings is required. See Section 4 for Combustion Calibration procedures.
6. Prior to reinstalling the igniter, a conductive anti-seize compound must be applied to the igniter threads.
7. Reinstall the igniter in the burner shell. Do Not over-tighten. A slight snugging up is sufficient.
8. Reconnect the igniter cable.
9. Replace the left side panel and left rear cover on the unit.



**Figure 7.1**  
**Spark Igniter and Flame Detector Location**

# MAINTENANCE

## 7.3 FLAME DETECTOR

The flame detector assembly is located in the body of the burner (Figure 7.1). The flame detector may be HOT. Allow the unit to cool sufficiently before removing the flame detector.

To inspect or replace the flame detector:

1. Set the ON/OFF switch on the control panel to the OFF position and disconnect AC power from the unit.
2. To access the flame detector, remove the unit's left side panel and left rear cover.
3. Disconnect the flame detector wire lead.
4. Using a 15/16" open-end wrench, loosen and remove the flame detector from the burner shell.
5. Inspect the detector thoroughly. If eroded, the detector should be replaced. Otherwise, clean the detector with a fine emery cloth.
6. Reinstall the flame detector in the burner shell. Do Not over-tighten. A slight snugging up is sufficient.
7. Reconnect the flame detector wire lead.
8. Replace the left side panel and left rear cover on the unit.

## 7.4 COMBUSTION CALIBRATION

Combustion settings must be checked at the intervals shown in Table 1 as part of the scheduled maintenance requirements. Refer to the combustion calibration instructions in Section 4..

## 7.5 SAFETY DEVICE TESTING

Systematic and thorough testing of the operating and safety devices should be performed to ensure that they are operating properly. Certain code requirements, such as ASME CSD-1, require that these tests be performed on a scheduled basis. Test schedules must conform to local jurisdictions. The results of the tests should be recorded in a log book. See Section 6 - Safety Device Testing Procedures.

## 7.6 MANIFOLD AND EXHAUST TUBES

The presence of even trace amounts of chlorides and/or sulfur, in the combustion air and fuel sources, can lead to the formation of deposits on the inside of the exchanger tubes, exhaust manifold, and/or the condensate cup. The degree of deposition is influenced by the extent of the condensing operation and the chloride and sulfur levels that vary significantly from application to application.


The following replacement parts will be required for reassembly after inspection:

|           |                              |
|-----------|------------------------------|
| GP-122537 | Combustion Chamber Gasket    |
| GP-18900  | Manifold to Tubesheet Gasket |
| 124749    | Burner Head/Plate Gasket     |
| 124834    | Burner Plate/Shell Gasket    |
| *124839   | Combustion Chamber Liner     |

*\*Not necessary to change but should be on hand in case damage occurs during the inspection.*


To remove the manifold for inspection:

1. Remove the sheet metal covers from the unit.
2. Disconnect the plastic tubing from the condensate cup to drain and remove the rear covers.
3. Remove the condensate cup from under the unit. Disconnect AC power and turn off the gas supply to the unit.
4. and disconnect the condensate drain tubing from the exhaust manifold.
5. Remove the flame detector and ignition cable wires from the flame detector and igniter contactor. Remove the igniter and flame detector per paragraphs 7.2, and 7.3.
6. Remove the grounding terminal from the burner by loosening the upper screw and sliding the connector from the grounding rod. (See Fig. 7.2)




**Figure 7.2**  
**Grounding Terminal Location**

7. Loosen the 1/4" NPT union on the low NOx staged ignition assembly (Figure 7.3).
8. Disconnect the staged ignition assembly 1/8" elbow from the 3" long NPT nipple at the bottom of the burner shell.




**Figure 7.3**  
**Burner Disassembly Diagram**

9. Remove the 3" long NPT nipple and 1/4" O.D. tube (Figure 7.3) from the burner shell.
10. Using a 7/16" socket or open end wrench, remove the four 1/4-20 nuts on the gas inlet pipe flange at the burner.
11. Using two 9/16" wrenches, remove the two 3/8-16 hex nuts and bolts on the gas inlet pipe flange at the air/fuel valve (Figure 7.3). Remove the gas inlet pipe.
12. Loosen the hose clamp on the air/fuel valve outlet (Figure 7.3).
13. Using a 1/2" socket wrench, remove the six 5/16-18 hex nuts supporting the burner (Figure 7.3).
14. Lower the burner while sliding the air hose off the air/fuel valve. Remove the burner through the rear of the unit. Due to space limitations, it will be necessary to separate the burner head and shell during the removal process.
15. Disconnect the exhaust temperature sensor by unscrewing it from the exhaust manifold (Figure 7.4).




**Figure 7.4**  
**Exhaust Sensor Connector Location**

16. Disconnect the air/fuel valve 12-pin connector from the KC wiring harness.
17. Disconnect wires #24 and #17 from the blower proof switch (Figure 7.5).



**Figure 7.5**  
**Blower Proof Switch Wire Locations**


18. Loosen the hose clamp on the air/fuel valve inlet and slide the clamp back towards the blower (Figure 7.6).



**Figure 7.6**  
**Air/Fuel Valve Inlet Hose Clamp**

## MAINTENANCE

- Using an 11/16" wrench, loosen the compression fittings on the feedback tube between the air/fuel valve and the differential pressure regulator. Remove the feedback tube (Figure 7.7).
- Using two 9/16" wrenches, remove the two 3/8-16 hex nuts and bolts securing the air/fuel valve to the differential pressure regulator (Figure 7.7).
- Remove the air/fuel valve, taking care not to damage the flange "O"-ring.




**Figure 7.7**  
**Feedback Tube and Air/Fuel Valve to**  
**Differential Regulator Bolts**

- Remove the flue venting from the exhaust manifold.
- To prevent damage and simplify handling of the exhaust manifold, it will be necessary to remove the exhaust manifold insulation. Using a 7/16" wrench or socket, remove the 3 bolts and fender washers securing the insulation to the exhaust manifold (Figure 7.8).
- Loosen the three 1-1/16" nuts that hold the manifold. Remove the two side nuts. **DO NOT REMOVE THE FRONT NUT** (Figure 7.8).
- Carefully pull the manifold down and back, removing it through the back of the unit.
- Inspect the manifold and exhaust tubes for debris. Clean out any debris as necessary.
- Inspect the combustion chamber and liner. Replace the liner if any signs of cracking or warping are observed.

### NOTE:

The combustion chamber liner should be installed prior to reinstalling the exhaust manifold




**Figure 7.8**  
**Manifold Nut and Bolt Locations**

- Replace the gasket between the manifold and the combustion chamber (Part Number GP-122537). The use of Permatex or a similar gasket adhesive is recommended. Replace the gasket between the manifold and tubesheet (Part No. GP-18900). Do not use any gasket adhesive; this gasket has an adhesive backing.
- Beginning with the manifold, reinstall all the components in the reverse order that they were removed.

### 7.7 HEAT EXCHANGER WATER SIDE INSPECTION


Per CSD-1, the water side of the heat exchanger requires an inspection. To inspect the heat exchanger, proceed as follows:

- Shut off AC power to the unit.
- Close the supply and return valves to the unit (Figure 7.9).
- Open the drain valve and allow the unit to fully drain. The 1/4 inch plug in the top of the shell may be removed to aid in drainage or the relief valve may be opened (Figure 7.9).



**Figure 7.9**  
Heat Exchanger Supply and Return Locations

4. Remove the 2 ½ inch plug located in the shell at the rear of the unit (Figure 7.10).
5. Remove the relief valve, drain valve (Figure 7.9) and any reducing bushings.
6. Perform the inspection. Reassemble the unit once the inspection is completed.
7. Open the supply and return valves and reconnect AC power to the unit.



**Figure 7.10**  
Heat Exchanger 2 ½ Inch Inspection Plug Location

### 7.8 Condensate Drain Assembly

KC Boilers contain a condensate drain cup (Figure 2.6) which should be inspected and cleaned annually to ensure proper operation. To inspect and clean the assembly, proceed as follows:

1. Remove the left side panel and left rear cover to provide access to the condensate drain components (see Figure 2.6).
2. Disconnect the plastic tubing from the condensate cup drain tube to the drain.
3. Remove the condensate cup from the unit. Thoroughly clean the cup and inspect the cup drain tube for blockage.
4. After the above items have been cleaned and inspected, reassemble the drain components by reversing the previous steps.





## Chapter 8- TROUBLESHOOTING GUIDE

### 8.1 INTRODUCTION

This troubleshooting guide is intended to aid service/maintenance personnel in isolating the cause of a fault in a KC1000 Boiler. The troubleshooting procedures contained herein are presented in tabular form on the following pages. These tables are comprised of three columns labeled: Fault Indication, Probable Cause and Corrective Action. The numbered items in the Probable Cause and Corrective Action columns correspond to each other. For example, Probable Cause No. 1 corresponds to Corrective Action No. 1, etc.

When a fault occurs in the KC1000 Boiler, proceed as follows to isolate and correct the fault:

1. Observe the fault messages displayed in the Control Box display.
2. Refer to the Fault Indication column in the following troubleshooting tables and locate the Fault that best describes the existing conditions.
3. Proceed to the Probable Cause column and start with the first item (1) listed for the Fault Indication.
4. Perform the checks and procedures listed in the Corrective Action column for the first Probable Cause candidate.
5. Continue checking each additional Probable Cause for the existing fault until the fault is corrected.
6. If the fault cannot be corrected using the information provided in the Troubleshooting Tables, please contact your local AERCO Representative.

# TROUBLESHOOTING

**TABLE 8-1. BOILER TROUBLESHOOTING**

| FAULT INDICATION              | PROBABLE CAUSES   | CORRECTIVE ACTION  |
|-------------------------------|---|--|
| AIRFLOW FAULT DURING IGNITION | <ol style="list-style-type: none"> <li>1. Blower stopped running due to thermal or current overload</li> <li>2. Blocked Blower inlet or inlet ductwork</li> <li>3. Blocked airflow switch</li> <li>4. Defective airflow switch</li> </ol>                                     | <ol style="list-style-type: none"> <li>1. Check combustion blower for signs of excessive heat or high current drain that may trip thermal or current overload devices.</li> <li>2. Inspect the inlet to the combustion blower including any ductwork leading up to the combustion blower for signs of blockage.</li> <li>3. Remove the airflow switch and inspect for signs of blockage, clean or replace as necessary.</li> <li>4. Measure the airflow switch for continuity with the combustion blower running. If there is an erratic resistance reading or the resistance reading is greater than zero ohms, replace the switch.</li> </ol>  |
| AIRFLOW FAULT DURING PURGE    | <ol style="list-style-type: none"> <li>1. Blower not running or running too slow</li> <li>2. Defective Air Flow Switch</li> <li>3. Blocked Air flow Switch</li> <li>4. Blocked Blower inlet or inlet ductwork.</li> <li>5. No voltage to switch from control box.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Start the unit. If the blower does not run check the blower solid state relay for input and output voltage. If the relay is okay, check the blower.</li> <li>2. Start the unit. If the blower runs, check the airflow switch for continuity. Replace the switch if there is no continuity.</li> <li>3. Remove the air flow switch and inspect for signs of blockage, clean or replace as necessary.</li> <li>4. Inspect the inlet to the combustion blower including any ductwork leading up to the combustion blower for signs of blockage.</li> <li>5. Measure for 24 VAC during start sequence from each side of the switch to ground. If 24VAC is not present refer to qualified service personnel.</li> </ol> |
| AIRFLOW FAULT DURING RUN      | <ol style="list-style-type: none"> <li>1. Blower stopped running due to thermal or current overload</li> <li>2. Blocked Blower inlet or inlet ductwork</li> <li>3. Blocked airflow switch</li> <li>4. Defective airflow switch</li> <li>5. Combustion oscillations</li> </ol> | <ol style="list-style-type: none"> <li>1. Check combustion blower for signs of excessive heat or high current draw that may trip thermal or current overload devices.</li> <li>2. Inspect the inlet to the combustion blower including any ductwork leading up to the combustion blower for signs of blockage.</li> <li>3. Remove the airflow switch and inspect for signs of blockage, clean or replace as necessary.</li> <li>4. Measure the airflow switch for continuity with the combustion blower running. If there is an erratic resistance reading or the resistance reading is greater than zero ohms, replace the switch.</li> <li>5. Run unit to full fire. If the unit rumbles or runs rough, perform combustion calibration.</li> </ol>         |

# TROUBLESHOOTING

**TABLE 8-1. BOILER TROUBLESHOOTING – Continued**

| FAULT INDICATION                 | PROBABLE CAUSES  | CORRECTIVE ACTION   |
|----------------------------------|--|---|
| <p>DELAYED INTERLOCK OPEN</p>    | <ol style="list-style-type: none"> <li>1. Delayed Interlock Jumper not installed or removed.</li> <li>2. Device proving switch hooked to interlocks is not closed</li> </ol>   | <ol style="list-style-type: none"> <li>1. Check for a jumper properly installed across the delayed interlock terminals in the I/O box.</li> <li>2. If there are 2 external wires on these terminals, check to see if an end switch for a device (i.e. a pump, louver, etc.) is tied to these interlocks. Ensure that the device and its end switch are functional. (jumper may be temporarily installed to test interlock</li> </ol>  |
| <p>DIRECT DRIVE SIGNAL FAULT</p> | <ol style="list-style-type: none"> <li>1. Direct drive signal is not present:<br/>Not yet installed.<br/>Wrong polarity.<br/>Signal defective at source.<br/>Broken or loose wiring.</li> <li>2. Signal is not isolated (floating).</li> <li>3. Control Box signal type selection switches not set for correct signal type (voltage or current).</li> </ol>  | <ol style="list-style-type: none"> <li>1. Check I/O Box to ensure signal is hooked up.<br/>Hook up if not installed.<br/>If installed, check polarity.<br/>Measure signal level.<br/>Check continuity of wiring between source and boiler.</li> <li>2. Check signal at source to ensure it is isolated.</li> <li>3. Check DIP switch on PMC board to ensure it is set correctly for the type of signal being sent. Check control signal type set in Configuration Menu.</li> </ol>  |
| <p>FLAME LOSS DURING IGN</p>     | <ol style="list-style-type: none"> <li>1. Burner Ground Screw not installed or loose.</li> <li>2. Worn flame detector</li> <li>3. No spark from Spark Plug</li> <li>4. Defective Ignition Transformer</li> <li>5. Defective Ignition/Stepper (IGST) Board</li> <li>6. Defective SSOV</li> <li>7. Defective Differential Pressure Regulator.</li> <li>8. Carbon or other debris on Burner.</li> </ol> | <ol style="list-style-type: none"> <li>1. Inspect and install/retighten Burner Ground Screw.</li> <li>2. Remove and inspect the flame detector for signs of wear. Replace if necessary.</li> <li>3. Close the internal gas valve in the boiler. Install and arc a spark ignitor outside the unit.</li> <li>4. If there is no spark, check for 120VAC at the primary side to the ignition transformer during the ignition cycle.</li> <li>5. If 120VAC is not present, the IGST Board in the Control Box may be defective. Refer fault to qualified service personnel.</li> <li>6. While externally arcing the spark ignitor, observe the open/close indicator in the Safety Shut-Off Valve to ensure it is opening. If the valve does not open, check for 120VAC at the valves input terminals. If 120VAC is not present, the IGST board in the Control Box may be defective. Refer fault to qualified service personnel.</li> <li>7. Check gas pressure using gauge or manometer into and out of the Air/Fuel Valve to ensure gas is getting to burner.</li> <li>8. Remove burner and inspect for any carbon or debris. Clean and reinstall</li> </ol> |

# TROUBLESHOOTING

**TABLE 8-1. BOILER TROUBLESHOOTING – Continued**

| FAULT INDICATION                | PROBABLE CAUSES   | CORRECTIVE ACTION  |
|---------------------------------|---|--|
| <p>FLAME LOSS DURING RUN</p>    | <ol style="list-style-type: none"> <li>1. Worn Flame Detector or cracked ceramic.</li> <li>2. Defective Differential Regulator.</li> <li>3. Poor combustion calibration.</li> <li>4. Debris on burner.</li> <li>5. Blocked condensate drain.</li> </ol> | <ol style="list-style-type: none"> <li>1. Remove and inspect the Flame Detector for signs of wear or cracked ceramic. Replace if necessary.</li> <li>2. Check gas pressure readings using a gauge or manometer into and out of the Air/Fuel Valve to ensure that the gas pressure into and out of the valve is correct.</li> <li>3. Check combustion calibration. Adjust as necessary.</li> <li>4. Remove the burner and inspect for any carbon or debris. Clean and reinstall.</li> <li>5. Remove blockage in condensate drain.</li> </ol>                        |
| <p>HEAT DEMAND FAILURE</p>      | <ol style="list-style-type: none"> <li>1. The Heat Demand Relays on the Ignition/Stepper board failed to activate when commanded</li> <li>2. Relay is activated when not in Demand</li> </ol>   | <ol style="list-style-type: none"> <li>1. Press CLEAR button and restart the unit. If the fault persists, replace Ignition/Stepper (IGST) Board.</li> <li>2. Defective relay. Replace IGST Board.</li> </ol>   |
| <p>HIGH EXHAUST TEMPERATURE</p> | <ol style="list-style-type: none"> <li>1. Defective exhaust sensor.</li> <li>2. Carboned heat exchanger due to incorrect combustion calibration</li> </ol>  | <ol style="list-style-type: none"> <li>1. Measure the actual exhaust temperature and continuity of the exhaust sensor. If the exhaust temperature is less than 475 °F and the exhaust sensor shows continuity replace the sensor.</li> <li>2. If exhaust temperature is greater than 500 °F, check combustion calibration. Calibrate or repair as necessary.</li> </ol>  |
| <p>HIGH GAS PRESSURE</p>        | <ol style="list-style-type: none"> <li>1. Incorrect supply gas pressure.</li> <li>2. Defective Supply Regulator or Wrong Style Regulator</li> <li>3. Defective High Gas Pressure Switch</li> </ol>  | <ol style="list-style-type: none"> <li>1. If using a non-lock up style regulator for the gas supply, measure static gas pressure downstream, it should be 14"WC or less. Adjust as necessary.</li> <li>2. If gas supply pressure cannot be lowered, a lock-up style regulator may be required or the supply regulator may be defective.</li> <li>3. Remove the leads from the high gas pressure switch. Measure continuity across the common and normally closed terminals with the unit not firing. Replace the switch if it does not show continuity.</li> </ol> |

# TROUBLESHOOTING

**TABLE 8-1. BOILER TROUBLESHOOTING – Continued**

| FAULT INDICATION            | PROBABLE CAUSES   | CORRECTIVE ACTION   |
|-----------------------------|---|---|
| HIGH WATER TEMP SWITCH OPEN | <ol style="list-style-type: none"> <li>1. Faulty Water temperature switch.</li> <li>2. Incorrect PID settings.</li> <li>3. Faulty shell temperature sensor.</li> <li>4. Unit in Manual mode</li> <li>5. Unit setpoint is greater than Over Temperature Switch setpoint.</li> <li>6. Boiler Management System PID or other settings not correctly setup.</li> <li>7. No interlock to boiler or BMS to disable boiler(s) in event that system pumps have failed.</li> <li>8. System flow rate changes are occurring faster than boilers can respond.</li> </ol> | <ol style="list-style-type: none"> <li>1. Test the temperature switch to insure it trips at its actual water temperature setting.</li> <li>2. Check PID settings against Menu Default settings in the Appendix. If the settings have been changed, record the current readings then reset them to the default values.</li> <li>3. Using the resistance charts in the Appendix C, Measure the resistance of Shell sensor and BTU sensor at a known water temperature.</li> <li>4. If unit is in Manual Mode switch to Auto Mode.</li> <li>5. Check setpoint of unit and setpoint of Temperature Switch; Ensure that the temperature switch is set higher than the unit's setpoint.</li> <li>6. Check the BMS for changes to PID default values, correct as necessary.</li> <li>7. If system pump is controlled by Energy Management System other than BMS or pumps are individually controlled by boiler, check to see if there are flow switches interlocked to the BMS or boiler.</li> <li>8. If the system is a variable flow system, monitor system flow changes to ensure that the rate of flow change is not faster than what the boilers can respond to.</li> </ol> |
| HIGH WATER TEMPERATURE      | <ol style="list-style-type: none"> <li>1. See HIGH WATER TEMPERATURE SWITCH OPEN.</li> <li>2. Temp HI Limit setting is too low.</li> </ol>  | <ol style="list-style-type: none"> <li>1. See HIGH WATER TEMPERATURE SWITCH OPEN.</li> <li>2. Check Temp HI Limit setting.</li> </ol>   |
| IGN BOARD COMM FAULT        | <ol style="list-style-type: none"> <li>1. Communication fault has occurred between the PMC board and Ignition/Stepper (IGST) board</li> </ol>   | <ol style="list-style-type: none"> <li>1. Press CLEAR button and restart unit. If fault persists, contact qualified Service Personnel.</li> </ol>   |

# TROUBLESHOOTING

**TABLE 8-1. BOILER TROUBLESHOOTING – Continued**

| FAULT INDICATION                | PROBABLE CAUSES   | CORRECTIVE ACTION   |
|---------------------------------|---|---|
| IGN SWITCH CLOSED DURING PURGE  | <ol style="list-style-type: none"> <li>1. Air/Fuel Valve not rotating</li> <li>2. Defective or shorted switch</li> <li>3. Switch wired incorrectly</li> <li>4. Defective Power Supply Board or fuse</li> <li>5. Defective IGST Board</li> </ol> | <ol style="list-style-type: none"> <li>1. Start the unit. The Air/Fuel Valve should rotate to the purge (open) position. If the valve does not rotate at all or does not rotate fully open, check the Air/Fuel Valve calibration. If calibration is okay, the problem may be in the Air-Fuel Valve or the Control Box. Refer to qualified service personnel</li> <li>2. . If the Air/Fuel Valve does rotate to purge, check the ignition switch for continuity between the N.O. and COM terminals. If the switch shows continuity when not in contact with the cam replace the switch.</li> <li>3. Check to ensure that the switch is wired correctly (correct wire numbers on the normally open terminals). If the switch is wired correctly, replace the switch</li> <li>4. Check DS1 &amp; DS2 LEDs on Power Supply Board. If they are not steady ON, replace Power Supply Board.</li> <li>5. Check “Heartbeat” LED DS1 and verify it is blinking ON &amp; OFF every second. If not, replace IGST Board</li> </ol> |
| IGN SWITCH OPEN DURING IGNITION | <ol style="list-style-type: none"> <li>1. Air/Fuel Valve not rotating to ignition position.</li> <li>2. Defective ignition switch</li> <li>3. Defective Power Supply Board or fuse</li> <li>4. Defective IGST Board</li> </ol>                  | <ol style="list-style-type: none"> <li>1. Start the unit. The Air/Fuel Valve should rotate to the purge (open) position, then back to ignition position (towards closed) during the ignition cycle. If the valve does not rotate back to the ignition position, check the Air/Fuel Valve calibration. If calibration is okay, the problem may be in the Air/Fuel Valve or the Control Box. Refer fault to qualified service personnel.</li> <li>2. If the Air/Fuel Valve does rotate to the ignition position, check the ignition position switch for continuity between the N.O. and COM terminals when in contact with the cam.</li> <li>3. Check DS1 &amp; DS2 LEDs on Power Supply Board. If they are not steady ON, replace Power Supply Board.</li> <li>4. Check “Heartbeat” LED DS1 and verify it is blinking ON &amp; OFF every second. If not, replace IGST Board.</li> </ol>  |
| INTERLOCK OPEN                  | <ol style="list-style-type: none"> <li>1. Interlock jumper not installed or removed</li> <li>2. Energy Management System does not have boiler enabled.</li> <li>3. Device proving switch hooked to interlocks is not closed.</li> </ol>         | <ol style="list-style-type: none"> <li>1. Check for a jumper properly installed across the interlock terminals in the I/O box</li> <li>2. If there are two external wires on these terminals check any Energy Management system to see if they have the units disabled (a jumper may be temporarily installed to see if the interlock circuit is functioning).</li> <li>3. Check that proving switch for any device hooked to the interlock circuit is closing and that the device is operational.</li> </ol>   |

# TROUBLESHOOTING

**TABLE 8-1. BOILER TROUBLESHOOTING – Continued**

| FAULT INDICATION                    | PROBABLE CAUSES  | CORRECTIVE ACTION   |
|-------------------------------------|--|---|
| LINE VOLTAGE<br>OUT OF PHASE        | <ol style="list-style-type: none"> <li>1. Line and Neutral switched in AC Power Box.</li> <li>2. Incorrect power supply transformer wiring.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Check hot and neutral in AC Power Box to ensure they are not reversed</li> <li>2. Check transformer wiring, in AC Power Box, against the power box transformer wiring diagram to ensure it is wired correctly</li> </ol>  |
| LOW GAS<br>PRESSURE                 | <ol style="list-style-type: none"> <li>1. Incorrect supply gas pressure.</li> <li>2. Defective or incorrectly sized Gas Supply Regulator.</li> <li>3. Defective Low Pressure Gas Switch</li> </ol>   | <ol style="list-style-type: none"> <li>1. Measure gas pressure upstream of the supply gas regulator with the unit firing ensure it is 14" WC or greater.</li> <li>2. Measure gas pressure downstream of the supply regulator with unit firing and adjust the gas supply regulator to increase the outlet gas pressure; if outlet gas pressure cannot be increased, check the sizing of the Supply regulator.</li> <li>3. Measure gas pressure at the low gas pressure switch, if it is greater than 5" WC, measure continuity across the switch and replace if necessary.</li> </ol>  |
| LOW WATER<br>LEVEL                  | <ol style="list-style-type: none"> <li>1. Insufficient water level in system</li> <li>2. Defective water level circuitry.</li> <li>3. Defective water level probe.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Check system for sufficient water level.</li> <li>2. Test water level circuitry using the Control Box front panel LOW WATER TEST and RESET buttons. Replace water level circuitry if it does not respond.</li> <li>3. Check continuity of probe end to the shell, change probe if there is no continuity.</li> </ol>  |
| MODBUS COMM<br>FAULT                | <ol style="list-style-type: none"> <li>1. Boiler not seeing information from Modbus network</li> </ol>   | <ol style="list-style-type: none"> <li>1. Check network connections. If fault persists, contact qualified Service Personnel.</li> </ol>   |
| PRG SWTCH CLOSED<br>DURING IGNITION | <ol style="list-style-type: none"> <li>1. A/F Valve rotated open to purge and did not rotate to ignition position</li> <li>2. Defective or shorted switch.</li> <li>3. Switch wired incorrectly.</li> <li>4. Defective Power Supply Board or fuse</li> </ol> | <ol style="list-style-type: none"> <li>1. Start the unit. The Air/Fuel Valve should rotate to the purge (open) position, then back to ignition position (towards closed) during the ignition cycle. If the valve does not rotate back to the ignition position, check the Air/Fuel Valve calibration. If calibration is okay, the problem may be in the Air/Fuel Valve or the Control Box. Refer fault to qualified service personnel.</li> <li>2. If the Air/Fuel Valve does rotate to the ignition position, check the purge switch for continuity between the N.O. and COM terminals. If the switch shows continuity when not in contact with the cam, check to ensure that the switch is wired correctly (correct wire numbers on the normally open terminals).</li> <li>3. If the switch is wired correctly, replace the switch.</li> <li>4. Check DS1 &amp; DS2 LEDs on Power Supply Board. If they are not steady ON, replace Power Supply Board.</li> </ol> |

# TROUBLESHOOTING

**TABLE 8-1. BOILER TROUBLESHOOTING – Continued**

| FAULT INDICATION            | PROBABLE CAUSES   | CORRECTIVE ACTION  |
|-----------------------------|---|--|
| continued                   | 5. Defective IGST Board   | 5. Check “Heartbeat” LED DS1 and verify it is blinking ON & OFF every second. If not, replace IGST Board.  |
| PRG SWTCH OPEN DURING PURGE | 1. Defective purge switch.<br>2. No voltage present at switch.<br>3. Switch wired incorrectly.<br>4. Defective Power Supply Board or fuse<br>5. Defective IGST Board  | 1. If the air-fuel valve does rotate, check the purge switch for continuity when closing. Replace switch if continuity does not exist.<br>2. Measure for 24 VAC from each side of the switch to ground. If 24VAC is not present, refer fault to qualified service personnel.<br>3. Check to ensure that the switch is wired correctly (correct wire numbers on the normally open terminals).<br>4. Check DS1 & DS2 LEDs on Power Supply Board. If they are not steady ON, replace Power Supply Board.<br>5. Check “Heartbeat” LED DS1 and verify it is blinking ON & OFF every second. If not, replace IGST Board. |
| OUTDOOR TEMP SENSOR FAULT   | 1. Loose or broken wiring.<br>2. Defective Sensor.<br>3. Incorrect Sensor.  | 1. Inspect Outdoor Temperature sensor for loose or broken wiring.<br>2. Check resistance of sensor to determine if it is within specification.<br>3. Ensure that the correct sensor is installed.  |
| REMOTE SETPT SIGNAL FAULT   | 1. Remote setpoint signal not present:<br>Not yet installed.<br>Wrong polarity.<br>Signal defective at source.<br>Broken or loose wiring.<br>2. Signal is not isolated (floating) if 4 to 20 mA.<br>3. Control Box signal type selection switches not set for correct signal type (voltage or current). | 1. Check I/O Box to ensure signal is hooked up. Hook up if not installed. If installed, check polarity. Measure signal level. Check continuity of wiring between source and boiler.<br>2. Check signal at source to ensure it is isolated.<br>3. Check DIP switch on PMC board to ensure it is set correctly for the type of signal being sent. Check control signal type set in Configuration Menu.   |
| RESIDUAL FLAME              | 1. SSOV not fully closed.   | 1. Check open/close indicator window of Safety Shut-Off Valve (SSOV) and ensure that the SSOV is fully closed. If not fully closed, replace the valve and or actuator.<br><br>Close gas shut-off valve downstream of SSOV. Install a manometer or gauge in a gas test port between the SSOV and the gas shut off valve. If a gas pressure reading is observed replace the SSOV valve and or actuator.  |



# TROUBLESHOOTING

**TABLE 8-1. BOILER TROUBLESHOOTING – Continued**

| FAULT INDICATION        | PROBABLE CAUSES   | CORRECTIVE ACTION   |
|-------------------------|---|---|
| (continued)             | 2. Defective Flame Detector   | 2. Replace Flame Detector.  |
| SSOV FAULT DURING PURGE | See SSOV SWITCH OPEN  |   |
| SSOV FAULT DURING RUN   | 1. SSOV switch closed for 15 seconds during run.  | 1. Replace or adjust microswitch in SSOV actuator. If fault persists, replace actuator.   |
| SSOV RELAY FAILURE      | 1. SSOV relay failed on board.  | 1. Press CLEAR button and restart unit. If fault persists, replace Ignition/Stepper (IGST) Board.   |
| SSOV SWITCH OPEN        | 1. Actuator not allowing for full closure of gas valve<br>2. SSOV powered when it should not be<br>3. Defective Switch or Actuator<br>4. Incorrectly wired switch.  | 1. Observe operation of the Safety Shut-Off Valve (SSOV) through indicator on the Valve actuator and ensure that the valve is fully and not partially closing.<br>2. If the SSOV never closes, it may be powered continuously. Close the gas supply and remove power from the unit. Refer fault to qualified service personnel.<br>3. Remove the electrical cover from the SSOV and check switch continuity. If the switch does not show continuity with the gas valve closed, either adjust or replace the switch or actuator.<br>4. Ensure that the SSOV Proof of Closure switch is correctly wired.  |
| STEPPER MOTOR FAILURE   | 1. Air/Fuel Valve out of calibration.<br>2. Air/Fuel Valve unplugged.<br>3. Loose wiring connection to the stepper motor.<br>4. Defective Air/Fuel Valve stepper motor.<br>5. Defective Power Supply Board or fuse<br>6. Defective IGST Board | 1. Refer to GF-112 and perform Stepper Test (para. 6.3.5) to ensure stepper motor rotates properly between the 0% (fully closed) and 100% (fully open) positions. Verify that the FIRE RATE bargraph and the dial on the Air/Fuel Valve track each other to indicate proper operation. If operation is not correct, perform the Stepper Feedback Calibration (GF-112, para. 6.2.1).<br>2. Check that the Air/Fuel Valve is connected to the Control Box.<br>3. .Inspect for loose connections between the Air/Fuel Valve motor and the wiring harness.<br>4. Replace stepper motor.<br>5. Check DS1 & DS2 LEDs on Power Supply Board. If they are not steady ON, replace Power Supply Board.<br>6. Check “Heartbeat” LED DS1 and verify it is blinking ON & OFF every second. If not, replace IGST Board. |



**BOILER MENU ITEM DESCRIPTIONS**

| MENU LEVEL & OPTION          | DESCRIPTION   |
|------------------------------|---|
| <b><u>OPERATING MENU</u></b> |   |
| Active Setpoint              | This is the setpoint temperature to which the control is operating when operating in the Constant Setpoint, Remote Setpoint or Outdoor Reset Mode. When in the Constant Setpoint Mode, this value is equal to the Internal Setpoint setting in the Configuration Menu. When in the Remote Setpoint Mode, this value is the setpoint equivalent to the remote analog signal supplied to the unit. When in the Outdoor Reset Mode, this is the derived value from the charts in Appendix D. |
| Aux Temp                     | For monitoring purposes only  |
| Outdoor Temp                 | Displayed only if an outdoor sensor is installed and enabled in the Configuration Menu.   |
| Fire Rate In                 | Indicates desired input fire rate. This will normally be the same as the fire rate shown on the bar-graph (fire rate out) when the boiler is operating.   |
| Flame Strength               | Displays flame strength from 0 to 100%.   |
| Run Cycles                   | Displays the total number of run cycles from 0 to 999,999.  |
| Run Hours                    | Displays total run time of unit in hours from 0 to 999,999.   |
| Fault Log                    | Displays information on the last 9 faults.  |

## APPENDIX A

### BOILER MENU ITEM DESCRIPTIONS - Continued

| MENU LEVEL & OPTION              | DESCRIPTION  |
|----------------------------------|--|
| <b><u>SETUP MENU</u></b>         |  |
| Password                         | Allows password to be entered.<br>Once the valid password (159) is entered, options in the Setup, Configuration and Tuning Menus can be modified.                        |
| Language                         | English Only   |
| Time                             | Displays time from 12:00am to 11:59pm.   |
| Date                             | Displays dates from 01/01/00 to 12/31/99   |
| Unit of Temp                     | Permits selection of temperature displays in degrees Fahrenheit (°F) or degrees Celsius (°C). Default is °F.   |
| Comm Address                     | For RS-485 (MODBUS) communications (0 to 255). Default address is 0. RS-232 should have its own (programmable) password.   |
| Baud Rate                        | Allows communications Baud Rate to be set (2400 to 19.2K). Default is 9600.  |
| Software Version                 | Identifies the current software version of the control box.  |
| <b><u>CONFIGURATION MENU</u></b> |  |
| Internal Setpoint                | Allows internal setpoint to be set . Default is 130°F.   |
| Unit Type                        | Allows selection of Boiler or Water Heater. Default is Boiler.   |
| Unit Size                        | Sets unit size from 0.5 to 3.0 MBTUs. Default is 1.0 MBTU.   |
| Boiler Mode                      | It allows selection of: Constant Setpoint, Remote Setpoint, Direct Drive, Combination, or Outdoor Reset Mode. Default is Constant Setpoint Mode.                         |
| Remote Signal                    | Used to set the type of external signal which will be used when operating in the Remote Setpoint, Direct Drive or Combination Mode. The factory default is 4-20 mA/1-5V. |
| Bldg Ref Temp                    | Allows the building reference temperature to be set when operating a boiler in the Outdoor Reset Mode. Default is 70°F.  |

**BOILER MENU ITEM DESCRIPTIONS - Continued**

| MENU LEVEL & OPTION | DESCRIPTION  |
|---------------------|--|
| Reset Ratio         | Permits setting of Reset Ratio when operating boiler in the Outdoor Reset Mode. Reset Ratio is adjustable from 0.1 to 9.9. Default is 1.2.   |
| Outdoor Sensor      | Allows outdoor sensor function to be enabled or disabled. Default is Disabled.   |
| System Start Tmp    | If outdoor sensor is enabled in the Configuration Menu, this menu item allows the system start temperature to be set from 30°F to 100°F. Default is 60°F.  |
| Setpoint Lo Limit   | Used to set the minimum allowable setpoint (40°F to Setpoint Hi Limit). Default is 60°F  |
| Setpoint Hi Limit   | Used to set the maximum allowable setpoint (Setpoint Lo Limit to 240°F). Default is 200°F.   |
| Temp Hi Limit       | Used to set the maximum allowable outlet temperature (40°F to 240°F). Any temperature above this setting will turn off the unit. The temperature must then drop 5°F below this setting to allow the unit to run. Default Temp Hi Limit is 215°F. |
| Max Fire Rate       | Sets the maximum allowable fire rate for the unit (40% to 100%). Default is 100%.  |
| Pump Delay Timer    | Specifies the amount of time (0 to 30 min.) to keep the pump running after the unit turns off. Default is zero.  |
| Aux Start On Dly    | Specifies the amount of time to wait (0 to 120 sec.) between activating the Aux Relay (due to a demand) and checking the pre-purge string to start the boiler. Default is 0 sec.   |
| Failsafe Mode       | Allows the Failsafe mode to be set to either Constant Setpoint or Shutdown. Default is Shutdown.   |
| mA Output           | Can be set to allow this output to monitor Setpoint, Outlet Temperature, Fire Rate Out or be set to OFF. Default is OFF.   |
| Lo Fire Timer       | Specifies how long (2 to 120 sec.) to remain in the low fire position after ignition, before going to the desired output. Default is 2 sec.  |

# APPENDIX A

## BOILER MENU ITEM DESCRIPTIONS - Continued

| MENU LEVEL & OPTION       | DESCRIPTION  |
|---------------------------|--|
| Setpt Limiting            | Allows Setpoint Limiting to be enabled or disabled. Default is disabled.   |
| Setpt Limit Band          | If Setpoint Limiting is enabled, this menu item allows the Setpt Limit Band to be set from 0°F to 10°F. Default is 5°F.  |
| <b><u>TUNING MENU</u></b> |  |
| Prop Band                 | Generates a fire rate based on the error that exists between the setpoint temperature and the actual outlet temperature. If the actual error is less than the proportional band setting (1 to 120°F), the fire rate will be less than 100%. If the error is equal to or greater than the proportional band setting, the fire rate will be 100%. Default is 70°F. |
| Integral Gain             | This sets the fraction of the output, due to setpoint error, to add or subtract from the output each minute to move towards the setpoint. Gain is adjustable from 0.00 to 2.00. Default is 1.00.   |
| Derivative Time           | This value (0.0 to 2.00 min.) responds to the rate of change of the setpoint error. This is the time that this action advances the output. Default is 0.0 min.   |
| Reset Defaults?           | Allows Tuning Menu options to be reset to their Factory Default values.  |

**STARTUP, STATUS AND FAULT MESSAGES**

**STARTUP AND STATUS MESSAGES**

| <b>MESSAGE</b>                | <b>DESCRIPTION</b>   |
|-------------------------------|--|
| DISABLED<br>HH:MM pm MM/DD/YY | Displayed if ON/OFF switch is set to OFF. The display also shows the time and date that the unit was disabled.   |
| STANDBY                       | Displayed when ON/OFF switch is in the ON position, but there is no demand for heat. The time and date are also displayed.   |
| DEMAND DELAY<br>XX sec        | Displayed if Demand Delay is active.   |
| PURGING<br>XX sec             | Displayed during the purge cycle during startup. The duration of the purge cycle counts up in seconds.   |
| IGNITION TRIAL<br>XX sec      | Displayed during ignition trial of startup sequence. The duration of cycle counts up in seconds.   |
| FLAME PROVEN                  | Displayed after flame has been detected for a period of 2 seconds. Initially, the flame strength is shown in %. After 5 seconds has elapsed, the time and date are shown in place of flame strength. |
| WARMUP<br>XX sec              | Displayed for 2 minutes during the initial warmup only.  |
| WAIT                          | Prompts the operator to wait.  |

## APPENDIX B

### FAULT MESSAGES

| FAULT MESSAGE                    | FAULT DESCRIPTION  |
|----------------------------------|--|
| HIGH WATER TEMP SWITCH OPEN      | The High Water Temperature Limit Switch is open.                                       |
| LOW WATER LEVEL                  | The Water Level Control board is indicating low water level.                           |
| LOW GAS PRESSURE                 | The Low Gas Pressure Limit Switch is open.   |
| HIGH GAS PRESSURE                | The High Gas Pressure Limit Switch is open.  |
| INTERLOCK OPEN                   | The Remote Interlock is open.  |
| DELAYED INTERLOCK OPEN           | The Delayed Interlock is open.   |
| AIRFLOW FAULT DURING PURGE       | The Blower Proof Switch opened during purge.   |
| PRG SWTCH OPEN DURING PURGE      | The Purge Position Limit switch on the air/fuel valve opened during purge.             |
| IGN SWTCH OPEN DURING IGNITION   | The Ignition Position Limit switch on the air/fuel valve opened during ignition.       |
| IGN SWTCH CLOSED DURING PURGE    | The Ignition Position Limit switch on the air/fuel valve closed during purge.          |
| PRG SWTCH CLOSED DURING IGNITION | The Purge Position Limit switch on the air/fuel valve closed during ignition.          |
| AIRFLOW FAULT DURING IGN         | The Blower Proof Switch opened during ignition.  |
| AIRFLOW FAULT DURING RUN         | The Blower Proof Switch opened during run.   |
| SSOV SWITCH OPEN                 | The SSOV switch opened during standby.   |
| SSOV FAULT DURING PURGE          | The SSOV switch opened during purge.   |
| SSOV FAULT DURING IGN            | The SSOV switch closed or failed to open during ignition.                              |
| SSOV FAULT DURING RUN            | The SSOV switch closed for more than 15 seconds during run.                            |
| SSOV RELAY FAILURE               | A failure has been detected in one of the relays that control the SSOV.                |
| FLAME LOSS DURING IGN            | The Flame signal was not seen during ignition or lost within 5 seconds after ignition. |
| FLAME LOSS DURING RUN            | The Flame signal was lost during run.  |
| HIGH EXHAUST TEMPERATURE         | The High Exhaust Temperature Limit Switch is closed.                                   |
| LOSS OF POWER                    | A power loss had occurred. The time and date when power was restored is displayed.     |




**FAULT MESSAGES - Continued**

| <b>FAULT MESSAGE</b>         | <b>FAULT DESCRIPTION</b>  |
|------------------------------|---|
| RESIDUAL<br>FLAME            | The Flame signal was seen for more than 60 seconds during standby.                |
| HEAT DEMAND<br>FAILURE       | The Heat Demand Relays on the Ignition board failed to activate when commanded.   |
| IGN BOARD<br>COMM FAULT      | A communication fault has occurred between the PMC board and Ignition board.      |
| DIRECT DRIVE<br>SIGNAL FAULT | The direct drive signal is not present or is out of range.                        |
| REMOTE SETPT<br>SIGNAL FAULT | The remote setpoint signal is not present or is out of range.                     |
| OUTDOOR TEMP<br>SENSOR FAULT | The temperature measured by the Outdoor Air Sensor is out of range.               |
| OUTLET TEMP<br>SENSOR FAULT  | The temperature measured by the Outlet Sensor is out of range.                    |
| FFWD TEMP<br>SENSOR FAULT    | The temperature measured by the FFWD Sensor is out of range.                      |
| HIGH WATER<br>TEMPERATURE    | The temperature measured by the Outlet Sensor exceeded the Temp Hi Limit setting. |
| LINE VOLTAGE<br>OUT OF PHASE | The High AC voltage is out of phase from the low AC voltage.                      |
| STEPPER MOTOR<br>FAILURE     | The stepper motor failed to move the valve to the desired position.               |
| NETWORK COMM<br>FAULT        | The RS-485 network information is not present or is corrupted.                    |



## Temperature Sensor Resistance Chart (Balco)



TEMPERATURE SENSOR  
AERCO PN 123449

| TEMP.<br>°F | Res.in Ohms |  |
|-------------|-------------|--|
| -40         | 779.0       |  |
| -30         | 797.5       |  |
| -20         | 816.3       |  |
| -10         | 835.4       |  |
| 0           | 854.8       |  |
| 10          | 874.6       |  |
| 20          | 894.7       |  |
| 30          | 915.1       |  |
| 40          | 935.9       |  |
| 50          | 956.9       |  |
| 60          | 978.3       |  |
| 70          | 1000.0      |  |
| 80          | 1022.0      |  |
| 90          | 1044.4      |  |
| 100         | 1067.0      |  |
| 110         | 1090.0      |  |
| 120         | 1113.3      |  |
| 130         | 1137.0      |  |
| 140         | 1160.9      |  |
| 150         | 1185.2      |  |
| 160         | 1209.5      |  |
| 170         | 1234.7      |  |
| 180         | 1260.0      |  |
| 190         | 1285.6      |  |
| 200         | 1311.4      |  |
| 210         | 1337.7      |  |
| 220         | 1364.2      |  |
| 230         | 1391.0      |  |
| 240         | 1418.2      |  |
| 250         | 1445.7      |  |

$$R(\text{Ohms}) = .00161T^2 + 1.961T + 854.841$$

T = °F



**INDOOR/OUTDOOR RESET RATIO CHARTS*****Header Temperature for a Building Reference Temperature of 50F***

| Air Temp | RESET RATIO |     |     |     |     |     |     |     |     |     |
|----------|-------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|          | 0.6         | 0.8 | 1.0 | 1.2 | 1.4 | 1.6 | 1.8 | 2.0 | 2.2 | 2.4 |
| 50F      | 50          | 50  | 50  | 50  | 50  | 50  | 50  | 50  | 50  | 50  |
| 45F      | 53          | 54  | 55  | 56  | 57  | 58  | 59  | 60  | 60  | 62  |
| 40F      | 56          | 58  | 60  | 62  | 64  | 66  | 68  | 70  | 72  | 74  |
| 35F      | 59          | 62  | 65  | 68  | 71  | 74  | 77  | 80  | 83  | 86  |
| 30F      | 62          | 66  | 70  | 74  | 78  | 82  | 86  | 90  | 94  | 98  |
| 25F      | 65          | 70  | 75  | 80  | 85  | 90  | 95  | 100 | 105 | 110 |
| 20F      | 68          | 74  | 80  | 86  | 92  | 98  | 104 | 110 | 116 | 122 |
| 15F      | 71          | 78  | 85  | 92  | 99  | 106 | 113 | 120 | 127 | 134 |
| 10F      | 74          | 82  | 90  | 98  | 106 | 114 | 122 | 130 | 138 | 146 |
| 5F       | 77          | 86  | 95  | 104 | 113 | 122 | 131 | 140 | 149 | 158 |
| 0F       | 80          | 90  | 100 | 110 | 120 | 130 | 140 | 150 | 160 | 170 |
| -5F      | 83          | 94  | 105 | 116 | 127 | 138 | 149 | 160 | 171 | 182 |
| -10F     | 86          | 98  | 110 | 122 | 134 | 146 | 158 | 170 | 182 | 194 |
| -15F     | 89          | 102 | 115 | 128 | 141 | 154 | 167 | 180 | 193 | 206 |
| -20F     | 92          | 106 | 120 | 134 | 148 | 162 | 176 | 190 | 204 | 218 |

***Header Temperature for a Building Reference Temperature of 60F***

| Air Temp | RESET RATIO |     |     |     |     |     |     |     |     |     |
|----------|-------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|          | 0.6         | 0.8 | 1.0 | 1.2 | 1.4 | 1.6 | 1.8 | 2.0 | 2.2 | 2.4 |
| 60F      | 60          | 60  | 60  | 60  | 60  | 60  | 60  | 60  | 60  | 60  |
| 55F      | 63          | 64  | 65  | 66  | 67  | 68  | 69  | 70  | 71  | 72  |
| 50F      | 66          | 68  | 70  | 72  | 74  | 76  | 78  | 80  | 82  | 84  |
| 45F      | 69          | 72  | 75  | 78  | 81  | 84  | 87  | 90  | 93  | 96  |
| 40F      | 72          | 76  | 80  | 84  | 88  | 92  | 96  | 100 | 104 | 108 |
| 35F      | 75          | 80  | 85  | 90  | 95  | 100 | 105 | 110 | 115 | 120 |
| 30F      | 78          | 84  | 90  | 96  | 102 | 108 | 114 | 120 | 126 | 132 |
| 25F      | 81          | 88  | 95  | 102 | 109 | 116 | 123 | 130 | 137 | 144 |
| 20F      | 84          | 92  | 100 | 108 | 116 | 124 | 132 | 140 | 148 | 156 |
| 15F      | 87          | 96  | 105 | 114 | 123 | 132 | 141 | 150 | 159 | 168 |
| 10F      | 90          | 100 | 110 | 120 | 130 | 140 | 150 | 160 | 170 | 180 |
| 5F       | 93          | 104 | 115 | 126 | 137 | 148 | 159 | 170 | 181 | 192 |
| 0F       | 96          | 108 | 120 | 132 | 144 | 156 | 168 | 180 | 192 | 204 |
| -5F      | 99          | 112 | 125 | 138 | 151 | 164 | 177 | 190 | 203 | 216 |
| -10F     | 102         | 116 | 130 | 144 | 158 | 172 | 186 | 200 | 214 |     |
| -15F     | 105         | 120 | 135 | 150 | 165 | 180 | 195 | 210 |     |     |
| -20F     | 108         | 124 | 140 | 156 | 172 | 188 | 204 |     |     |     |

## APPENDIX D

### *Header Temperature for a Building Reference Temperature of 65F*

| Air Temp | RESET RATIO |     |     |     |     |     |     |     |     |     |
|----------|-------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|          | 0.6         | 0.8 | 1.0 | 1.2 | 1.4 | 1.6 | 1.8 | 2.0 | 2.2 | 2.4 |
| 65       | 65          | 65  | 65  | 65  | 65  | 65  | 65  | 65  | 65  | 65  |
| 60       | 68          | 69  | 70  | 71  | 72  | 73  | 74  | 75  | 76  | 77  |
| 55       | 71          | 73  | 75  | 77  | 79  | 81  | 83  | 85  | 87  | 89  |
| 50       | 74          | 77  | 80  | 83  | 86  | 89  | 92  | 95  | 98  | 101 |
| 45       | 77          | 81  | 85  | 89  | 93  | 97  | 101 | 105 | 109 | 113 |
| 40       | 80          | 85  | 90  | 95  | 100 | 105 | 110 | 115 | 120 | 125 |
| 35       | 83          | 89  | 95  | 101 | 107 | 113 | 119 | 125 | 131 | 137 |
| 30       | 86          | 93  | 100 | 107 | 114 | 121 | 128 | 135 | 142 | 149 |
| 25       | 89          | 97  | 105 | 113 | 121 | 129 | 137 | 145 | 153 | 161 |
| 20       | 92          | 101 | 110 | 119 | 128 | 137 | 146 | 155 | 164 | 173 |
| 15       | 95          | 105 | 115 | 125 | 135 | 145 | 155 | 165 | 175 | 185 |
| 10       | 98          | 109 | 120 | 131 | 142 | 153 | 164 | 175 | 186 | 197 |
| 5        | 101         | 113 | 125 | 137 | 149 | 161 | 173 | 185 | 197 | 209 |
| 0        | 104         | 117 | 130 | 143 | 156 | 169 | 182 | 195 | 208 |     |
| -5       | 107         | 121 | 135 | 149 | 163 | 177 | 191 | 205 | 219 |     |
| -10      | 110         | 125 | 140 | 155 | 170 | 185 | 200 | 215 |     |     |
| -15      | 113         | 129 | 145 | 161 | 177 | 193 | 209 |     |     |     |
| -20      | 116         | 133 | 150 | 167 | 201 | 218 |     |     |     |     |

### *Header Temperature for a Building Reference Temperature of 70F*

| Air Temp | RESET RATIO |     |     |     |     |     |     |     |     |     |
|----------|-------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|          | 0.6         | 0.8 | 1.0 | 1.2 | 1.4 | 1.6 | 1.8 | 2.0 | 2.2 | 2.4 |
| 70F      | 70          | 70  | 70  | 70  | 70  | 70  | 70  | 70  | 70  | 70  |
| 65F      | 73          | 74  | 75  | 76  | 77  | 78  | 79  | 80  | 81  | 82  |
| 60F      | 76          | 78  | 80  | 82  | 84  | 86  | 88  | 90  | 92  | 94  |
| 55F      | 79          | 82  | 85  | 88  | 91  | 94  | 97  | 100 | 103 | 106 |
| 50F      | 82          | 86  | 90  | 94  | 98  | 102 | 106 | 110 | 114 | 118 |
| 45F      | 85          | 90  | 95  | 100 | 105 | 110 | 115 | 120 | 125 | 130 |
| 40F      | 88          | 94  | 100 | 106 | 112 | 118 | 124 | 130 | 136 | 142 |
| 35F      | 91          | 98  | 105 | 112 | 119 | 126 | 133 | 140 | 147 | 154 |
| 30F      | 94          | 102 | 110 | 118 | 126 | 134 | 142 | 150 | 158 | 166 |
| 25F      | 97          | 106 | 115 | 124 | 133 | 142 | 151 | 160 | 169 | 178 |
| 20F      | 100         | 110 | 120 | 130 | 140 | 150 | 160 | 170 | 180 | 190 |
| 15F      | 103         | 114 | 125 | 136 | 147 | 158 | 169 | 180 | 191 | 202 |
| 10F      | 106         | 118 | 130 | 142 | 154 | 166 | 178 | 190 | 202 | 214 |
| 5F       | 109         | 122 | 135 | 148 | 161 | 174 | 187 | 200 | 213 |     |
| 0F       | 112         | 126 | 140 | 154 | 168 | 182 | 196 | 210 |     |     |
| -5F      | 115         | 130 | 145 | 160 | 175 | 190 | 205 |     |     |     |
| -10F     | 118         | 134 | 150 | 166 | 182 | 198 | 214 |     |     |     |
| -15F     | 121         | 138 | 155 | 172 | 189 | 206 |     |     |     |     |
| -20F     | 124         | 142 | 160 | 178 | 196 | 214 |     |     |     |     |

**APPENDIX D**

**Header Temperature for a Building Reference Temperature of 75F**

| Air Temp | RESET RATIO |     |     |     |     |     |     |     |     |     |
|----------|-------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|          | 0.6         | 0.8 | 1.0 | 1.2 | 1.4 | 1.6 | 1.8 | 2.0 | 2.2 | 2.4 |
| 75F      | 75          | 75  | 75  | 75  | 75  | 75  | 75  | 75  | 75  | 75  |
| 70F      | 78          | 79  | 80  | 81  | 82  | 83  | 84  | 85  | 86  | 87  |
| 65F      | 81          | 83  | 85  | 87  | 89  | 91  | 93  | 95  | 97  | 99  |
| 60F      | 84          | 87  | 90  | 93  | 96  | 99  | 102 | 105 | 108 | 111 |
| 55F      | 87          | 91  | 95  | 99  | 103 | 107 | 111 | 115 | 119 | 123 |
| 50F      | 90          | 95  | 100 | 105 | 110 | 115 | 120 | 125 | 130 | 135 |
| 45F      | 93          | 99  | 105 | 111 | 117 | 123 | 129 | 135 | 141 | 147 |
| 40F      | 96          | 103 | 110 | 117 | 124 | 131 | 138 | 145 | 152 | 159 |
| 35F      | 99          | 107 | 115 | 123 | 131 | 139 | 147 | 155 | 163 | 171 |
| 30F      | 102         | 111 | 120 | 129 | 138 | 147 | 156 | 165 | 174 | 183 |
| 25F      | 105         | 115 | 125 | 135 | 145 | 155 | 165 | 175 | 185 | 195 |
| 20F      | 108         | 119 | 130 | 141 | 152 | 163 | 174 | 185 | 196 | 207 |
| 15F      | 111         | 123 | 135 | 147 | 159 | 171 | 183 | 195 | 207 | 219 |
| 10F      | 114         | 127 | 140 | 153 | 166 | 179 | 192 | 205 | 218 |     |
| 5F       | 117         | 131 | 145 | 159 | 173 | 187 | 201 | 215 |     |     |
| 0F       | 120         | 135 | 150 | 165 | 180 | 195 | 210 |     |     |     |
| -5F      | 123         | 139 | 155 | 171 | 187 | 203 | 219 |     |     |     |
| -10F     | 126         | 143 | 160 | 177 | 194 | 211 |     |     |     |     |
| -15F     | 129         | 147 | 165 | 183 | 201 | 219 |     |     |     |     |

**Header Temperature for a Building Reference Temperature of 80F**

| Air Temp | RESET RATIO |     |     |     |     |     |     |     |     |     |
|----------|-------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|          | 0.6         | 0.8 | 1.0 | 1.2 | 1.4 | 1.6 | 1.8 | 2.0 | 2.2 | 2.4 |
| 80F      | 80          | 80  | 80  | 80  | 80  | 80  | 80  | 80  | 80  | 80  |
| 75F      | 83          | 84  | 85  | 86  | 87  | 88  | 89  | 90  | 91  | 92  |
| 70F      | 86          | 88  | 90  | 92  | 94  | 96  | 98  | 100 | 102 | 104 |
| 65F      | 89          | 92  | 95  | 98  | 101 | 104 | 107 | 110 | 113 | 116 |
| 60F      | 92          | 96  | 100 | 104 | 108 | 112 | 116 | 120 | 124 | 128 |
| 55F      | 95          | 100 | 105 | 110 | 115 | 120 | 125 | 130 | 135 | 140 |
| 50F      | 98          | 104 | 110 | 116 | 122 | 128 | 134 | 140 | 146 | 152 |
| 45F      | 101         | 108 | 115 | 122 | 129 | 136 | 143 | 150 | 157 | 164 |
| 40F      | 104         | 112 | 120 | 128 | 136 | 144 | 152 | 160 | 168 | 176 |
| 35F      | 107         | 116 | 125 | 134 | 143 | 152 | 161 | 170 | 179 | 188 |
| 30F      | 110         | 120 | 130 | 140 | 150 | 160 | 170 | 180 | 190 | 200 |
| 25F      | 113         | 124 | 135 | 146 | 157 | 168 | 174 | 190 | 201 | 212 |
| 20F      | 116         | 128 | 140 | 152 | 164 | 176 | 188 | 200 | 212 |     |
| 15F      | 119         | 132 | 145 | 158 | 171 | 184 | 197 | 210 |     |     |
| 10F      | 122         | 136 | 150 | 164 | 178 | 192 | 206 |     |     |     |
| 5F       | 125         | 140 | 155 | 170 | 185 | 200 | 215 |     |     |     |
| 0F       | 128         | 144 | 160 | 176 | 192 | 208 |     |     |     |     |
| -5F      | 131         | 148 | 165 | 182 | 199 | 216 |     |     |     |     |
| -10F     | 134         | 152 | 170 | 188 | 206 |     |     |     |     |     |

## APPENDIX D

### *Header Temperature for a Building Reference Temperature of 90F*


| Air Temp   | RESET RATIO |     |     |     |     |     |     |     |     |     |
|------------|-------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|            | 0.6         | 0.8 | 1.0 | 1.2 | 1.4 | 1.6 | 1.8 | 2.0 | 2.2 | 2.4 |
| <b>90F</b> | 90          | 90  | 90  | 90  | 90  | 90  | 90  | 90  | 90  | 90  |
| <b>85F</b> | 93          | 94  | 95  | 96  | 97  | 98  | 99  | 100 | 101 | 102 |
| <b>80F</b> | 96          | 98  | 100 | 102 | 104 | 106 | 108 | 110 | 112 | 114 |
| <b>75F</b> | 99          | 102 | 105 | 108 | 111 | 114 | 117 | 120 | 123 | 126 |
| <b>70F</b> | 102         | 106 | 110 | 114 | 118 | 122 | 126 | 130 | 134 | 138 |
| <b>65F</b> | 105         | 110 | 115 | 120 | 125 | 130 | 135 | 140 | 145 | 150 |
| <b>60F</b> | 108         | 114 | 120 | 126 | 132 | 138 | 144 | 150 | 156 | 162 |
| <b>55F</b> | 111         | 118 | 125 | 132 | 139 | 146 | 153 | 160 | 167 | 174 |
| <b>50F</b> | 114         | 122 | 130 | 138 | 146 | 154 | 162 | 170 | 178 | 186 |
| <b>45F</b> | 117         | 126 | 135 | 144 | 153 | 162 | 171 | 180 | 189 | 198 |
| <b>40F</b> | 120         | 130 | 140 | 150 | 160 | 170 | 180 | 190 | 200 | 210 |
| <b>35F</b> | 123         | 134 | 145 | 156 | 167 | 178 | 189 | 200 |     |     |
| <b>30F</b> | 126         | 138 | 150 | 162 | 174 | 186 | 198 | 210 |     |     |
| <b>25F</b> | 129         | 142 | 155 | 168 | 181 | 194 | 207 |     |     |     |
| <b>20F</b> | 132         | 146 | 160 | 174 | 188 | 202 | 216 |     |     |     |
| <b>15F</b> | 135         | 150 | 165 | 180 | 195 | 210 |     |     |     |     |
| <b>10F</b> | 138         | 154 | 170 | 186 | 202 | 218 |     |     |     |     |
| <b>5F</b>  | 141         | 158 | 175 | 192 | 209 |     |     |     |     |     |
| <b>0F</b>  | 144         | 162 | 180 | 198 | 216 |     |     |     |     |     |



BOILER DEFAULT SETTINGS

| MENU & OPTION  | FACTORY DEFAULT   |
|--|-------------------|
| <b><u>Setup Menu</u></b>   |                   |
| Password   | 0                 |
| Language   | English           |
| Unit of Temp   | Fahrenheit        |
| Comm Address   | 0                 |
| Baud Rate  | 9600              |
| <b><u>Configuration Menu</u></b>   |                   |
| Internal Setpt   | 130°F             |
| Unit Type  | Boiler            |
| Unit Size  | 1.0 MBTU          |
| Boiler Mode  | Constant Setpoint |
| Remote Signal<br>(If Mode = Remote Setpoint, Direct Drive or<br>Combination) | 4 – 20 mA /1-5V   |
| Bldg Ref Temp<br>(If Boiler Mode = Outdoor Reset)                            | 70°F              |
| Reset Ratio<br>(If Boiler Mode = Outdoor Reset)                              | 1.2               |
| Outdoor Sensor   | Disabled          |
| System Start Tmp<br>(If Outdoor Sensor = Enabled)                            | 60°F              |
| Setpt Lo Limit   | 60°F              |
| Setpt Hi Limit   | 200°F             |
| Temp Hi Limit  | 215°F             |
| Max Fire Rate  | 100%              |
| Pump Delay Timer   | 0 min             |
| Aux Start On Dly   | 0 sec             |
| Failsafe Mode  | Shutdown          |
| mA Output  | Off               |
| Lo Fire Timer  | 2 sec             |
| Setpt Limit Band (If Setpt Limiting = Enabled)                               | 5°F               |
| <b><u>Tuning Menu</u></b>  |                   |
| Prop Band  | 70°F              |
| Integral Gain  | 1.00              |
| Derivative Time  | 0.0 min           |







|   |               |
|---|---------------|
| <b>AERCO INTERNATIONAL, INC.</b><br>NORTHVALE, NJ 07847 |               |
| KC1000 1 MIL. BTU<br>GAS FIRED BOILER                   |               |
| MINIMUM SPACE REQUIREMENTS                              |               |
| DWN BY: <u>SD</u> DATE: <u>120898</u>                   | REV. <u>C</u> |
| SCALE: <u>NES</u>                                       |               |
| APPD. <u>MFC</u> DATE: <u>122288</u>                    | SD-A-427      |

NOTES:  
1) ALL DIMENSIONS SHOWN ARE IN INCHES

# APPENDIX F

| HEAT EXCHANGER DESIGN STANDARDS     |     |                    |     |
|-------------------------------------|-----|--------------------|-----|
| MAX. WORKING PRESS. (PSIG)          | 150 | MAXIMUM TEMP. (°F) | 25  |
| TEST PRESS. (PSIG)                  |     |                    | 225 |
| SHELL SIDE                          |     |                    |     |
| ASME B & PV CODE SECTION IV STAMP H |     |                    |     |



NOTES:  
 1) DRAIN VALVE AND RELIEF VALVE ARE INCLUDED SEPARATELY IN SHIPMENT  
 2) A 1/4" PER FOOT FLUE PITCH BACK TOWARDS THE HEATER MUST BE MAINTAINED TO ALLOW THE FLOW OF ANY CONDENSATE FORMED IN THE FLUE TO FLOW TO THE DRAIN  
 3) ALL DIMENSIONS SHOWN ARE IN INCHES (CENTIMETERS)

**AERCO** INTERNATIONAL INC.  
 NORTHVALE, NEW JERSEY 07647

KC SERIES GAS FIRED BOILER  
 DIMENSIONAL DRAWING

CHKD GK 2-1-95  
 APPD

REV. **A**

AP-A-816

MODEL KC

STYLE

| HEAT EXCHANGER |          |     |                      |
|----------------|----------|-----|----------------------|
| ITEM           | PART NO. | QTY | DESCRIPTION          |
| 1              | GM-20881 | 1   | HEAT EXCHANGER ASS'Y |

| EXHAUST MANIFOLD |            |     |                                   |
|------------------|------------|-----|-----------------------------------|
| ITEM             | PART NO.   | QTY | DESCRIPTION                       |
| 2                | GM-20844-2 | 1   | EXHAUST MANIFOLD                  |
| 3                | GP-20885   | 1   | EXHAUST MANIFOLD INSULATION       |
| 4                | GM-123352  | 1   | EXHAUST MANIFOLD DRAIN HOSE       |
| 5                | GP-122540  | 1   | HOSE CLAMP 13/16" - 1-3/4"Ø RANGE |
| 6                | GP-123337  | 1   | CONDENSATE CUP ASSEMBLY           |
| 7                | GP-122849  | 2   | VENT MOUNTING FLANGE              |

| GASKETS |           |     |                                      |
|---------|-----------|-----|--------------------------------------|
| ITEM    | PART NO.  | QTY | DESCRIPTION                          |
| 13      | GP-18532  | 1   | SHELL GASKET                         |
| 15      | GP-18900  | 1   | EXH. MANIFOLD TO LOWER HEAD SEAL     |
| 17      | 124839    | 1   | COMBUSTION CHAMBER LINER (LOW NOX)   |
| 18      | GP-122537 | 1   | EXH. MANIFOLD TO COMB. CHAMB. GASKET |


| GAS TRAIN |          |     |  |
|-----------|----------|-----|--|
| ITEM      | PART NO. | QTY | DESCRIPTION                                    |
| 22        | 124800-1 | 1   | GAS TRAIN ASSEMBLY (LOW NOX; FM; NATURAL GAS)  |
|           | 124800-2 |     | GAS TRAIN ASSEMBLY (LOW NOX; FM; PROPANE)      |
|           | 124801-1 |     | GAS TRAIN ASSEMBLY (LOW NOX; IRI; NATURAL GAS) |
|           | 124801-2 |     | GAS TRAIN ASSEMBLY (LOW NOX; IRI; PROPANE)     |

| BLOWER |           |     |   |
|--------|-----------|-----|---|
| ITEM   | PART NO.  | QTY | DESCRIPTION   |
| 23     | 124935    | 1   | BLOWER (INCLUDES CAPACITOR 65029)                                 |
| 24     | 65029     | 1   | BLOWER MOTOR CAPACITOR (FOR ACI BLOWERS)                          |
|        | 124936    |     | BLOWER MOTOR CAPACITOR (FOR BLOWERS WITH BALDOR MOTOR)            |
|        | GP-122553 |     | BLOWER MOTOR CAPACITOR (FOR BLOWERS WITH AMETEK/A.O. SMITH MOTOR) |
| 25     | GP-161152 | 1   | BLOWER AIR INLET SHUTTER  |
| 26     | GP-122669 | 1   | AIR INLET SCREEN  |
| 27     | GP-122835 | 2   | SPACER  |
| 28     | 85003     | 1   | DAMPER TO BLOWER INLET HOSE                                       |

| BURNER AND AIR/FUEL VALVE |           |     |   |
|---------------------------|-----------|-----|---|
| ITEM                      | PART NO.  | QTY | DESCRIPTION   |
| 29                        | GP-161146 | 1   | BLOWER TO AIR VA. INLET HOSE                            |
| 30                        | GP-18894  | 1   | GAS PRESS. CONTROL TUBE                                 |
| 31                        | 123581    | 1   | 3/8" NPT x 3/8" O.D. TUBE AL. COMP. FTG.                |
| 32                        | GP-122614 | 1   | 1/8" NPT x 3/8" O.D. TUBE AL. COMP. FTG.                |
| 33                        | 201271    | 1   | AIR/FUEL VALVE (LOW NOX)                                |
| 34                        | GP-161147 | 1   | VALVE TO BURNER AIR HOSE                                |
| 35                        | GM-20934  | 1   | GAS INLET PIPE  |
| 36                        | 201258    | 1   | BURNER ASSEMBLY (LOW NOX)                               |
| 24043                     | 24043     | 1   | KC1000 LOW NOx BURNER HEAD ONLY ASS'Y (REPLACEMENT KIT) |

| CONTROLS |           |     |                                    |
|----------|-----------|-----|------------------------------------|
| ITEM     | PART NO.  | QTY | DESCRIPTION                        |
| 37       | 161559    | 1   | POWER BOX ASSEMBLY                 |
| 38       | GP-122464 | 1   | IGNITION TRANSFORMER               |
| 39       | GP-122569 | 1   | IGNITION CABLE ASSEMBLY            |
| 40       | 161560    | 1   | INPUT/OUTPUT (I/O) BOX ASSEMBLY    |
| 41       | 181198    | 1   | CONTROL BOX ASSEMBLY               |
| 42       | 161450    | 1   | GAS TRAIN WIRING HARNESS           |
| 43       | 61002-14  | 1   | BLOWER PROOF SWITCH                |
| 44       | GP-122403 | 1   | LOW PRESSURE GAS SWITCH            |
| 45       | 123536    | 1   | 1/4" MNPT x 1/8" FNPT RED. BUSHING |
| 46       | GP-122821 | 1   | TEMPERATURE SWITCH                 |
| 47       | 123448    | 1   | SHELL SENSOR                       |
| 48       | 122843    | 1   | LOW WATER CUT-OFF                  |
| 49       | 123463    | 1   | EXHAUST TEMPERATURE SWITCH         |
| 50       | 123711    | 2   | TEMPERATURE SWITCH THERMOWELL      |
| 51       | 161569    | 1   | SHELL WIRING HARNESS               |
| 52       | 124334    | 1   | EXHAUST TEMP. SWITCH HARNESS       |
| 53       | GP-122412 | 1   | HIGH PRESS. GAS SWITCH             |
| 54       | 123863    | 1   | 1/8" NPT BALL VALVE                |
| 55       | 124867    | 1   | STAGED IGNITION ASSEMBLY           |
| 56       | 124870    | 1   | SOLENOID VALVE HARNESS             |

| OTHER PARTS |           |     |                                |
|-------------|-----------|-----|--------------------------------|
| ITEM        | PART NO.  | QTY | DESCRIPTION                    |
| 57          | GP-122406 | 3   | BURNER & AIR/FUEL VALVE O-RING |



| OTHER ACCESSORIES |           |     |                                    |
|-------------------|-----------|-----|------------------------------------|
| ITEM              | PART NO.  | QTY | DESCRIPTION                        |
| 8                 | 8-22      | 1   | 1-1/2" X 1" REDUCING BUSHING       |
| 9                 | GP-9-428  | 1   | 1" NPT X 4" LG. NIPPLE - RED BRASS |
| 10                | GP-122789 | 1   | 1" NPT 90° ELBOW - BRONZE          |
| 11                | GM-122743 | 1   | DRAIN VALVE ASSEMBLY               |
| *                 | 12        | 1   | 1" NPT PRESSURE RELIEF VALVE       |
|                   | 19        | 1   | 1" NPT CLOSE NIPPLE - RED BRASS    |
| **                | 20        | 1   | TEMP./PRESS. GAUGE                 |
| XX                | GP-123050 | 1   | EXTERNAL GAS SHUT-OFF VALVE        |



XX NOT SHOWN IN THE DRAWING  
 \* INDICATE PRESSURE RELIEF VALVE SETTING (30, 50, 75, 100, OR 150 PSI)  
 \*\* -2 (30 AND 50 PSI RELIEF VALVE SETTING)  
 -3 (75 AND 100 PSI RELIEF VALVE SETTING)  
 -4 (150 PSI RELIEF VALVE SETTING)  
 \*\*\* - INCLUDES LOWER AND UPPER BURNER GASKETS, IGNITOR, AND FLAME DETECTOR ASSEMBLY.  
 \*\*\*\* - INCLUDES LOWER AND UPPER BURNER GASKETS, AND COMBUSTION CHAMBER LINER

**AERCO INTERNATIONAL, INC.**  
 NORTHVALE, NJ 07647


LOW NOX KC1000 WATER BOILER PARTS LIST

|            |             |              |   |
|------------|-------------|--------------|---|
| DWN. BY CZ | DATE 022505 | PL-A-145     | H |
| SCALE      |             | (SH. 1 OF 2) |   |
| APPD.      | DATE        |              |   |

# APPENDIX F




|   |              |   |
|---|--------------|---|
| <i>AERCO</i> INTERNATIONAL, INC.<br>NORTHVALE, NJ 07647 |              |   |
| LOW NOX KC1000 WATER BOILER<br>PARTS LIST               |              |   |
| DWN. BY <u>CZ</u> DATE <u>022505</u>                    | PL-A-145     | H |
| SCALE _____   | (SH. 2 OF 2) |   |
| APPD. _____ DATE _____                                  |              |   |



|   |              |
|---|--------------|
| <b>AERCO</b> INTERNATIONAL, INC.<br>NORTHVALE, NJ 07647 |              |
| KC1000 LOW NOx BOILER<br>IRI GAS TRAIN                  |              |
| DWN.BY: GS<br>SCALE: NTS                                | DATE: 022305 |
| APPD: _____   | DATE: _____  |
| REV.:   | C            |
| SD-A-660  |              |

# APPENDIX F




| ITEM NO. | QTY. | PART NO. | DESCRIPTION                         |
|----------|------|----------|-------------------------------------|
| 1        | 1    | 124866   | SOLENOID VALVE, 1/4" NPT            |
| 2        | 1    | 122712   | 1/2" NPT, FLEX, GAS HOSE, 12" LONG  |
| 3        | 1    | 123314   | ELBOW, 1/4" NPT                     |
| 4        | 1    | 9-43     | REDUCER BUSHING, 1/2" TO 1/4" NPT   |
| 5        | 1    | 124933   | UNION, 1/4" NPT                     |
| 6        | 1    | 124934   | 1/4" X 1/8" REDUCING COUPLING       |
| 7        | 2    | 124088   | NIPPLE, 1/4" NPT, C.S. 2 1/2" LONG  |
| 8        | 1    | 124932   | REDUCING COUPLING, 1/2" TO 1/4" NPT |
| 9        | 1    | 124910   | NIPPLE, 1/4" NPT, CS. 9" LG         |
| 10       | 1    | 12820-1  | 1/4" NPT BALL VALVE                 |
| 11       | 1    | 124939   | 1/4" NPT ORIFICE PIPE NIPPLE        |
| 12       | 1    | 124979   | 1/8" C.S. STREET ELBOW              |
| 13       | 2    | 124891   | FEMALE FAST-ON CONNECTOR            |
| 14       | 1    | 12607-2  | CLOSE NIPPLE, 1/4" NPT SCH.40, C.S. |

## LOW NO<sub>x</sub> STAGED IGNITION ASSEMBLY – 124867



LEGEND

|  |             |
|--|-------------|
|  | CHECK VALVE |
|  | STOP VALVE  |
|  | UNION       |
|  | Y-STRAINER  |



NOTES:


- 1) THIS IS A TYPICAL INSTALLATION DRAWING. LOCAL CODES AND AUTHORITIES SHOULD BE CONSULTED.
- 2) ALL (\*) ITEMS ARE INCLUDED SEPARATELY IN SHIPMENT.
- 3) FOR ACTUAL SIZES AND LOCATIONS OF PIPING AND OTHER CONNECTIONS TO THE BOILER, SEE DIMENSIONAL DRAWING.
- 4) SHELL DRAIN VALVE AND CONDENSATE HOSE SHOULD BE ARRANGED TO PERMIT THE FLUIDS TO DRAIN FREELY, BY GRAVITY, TO A CONVENIENT FLOOR DRAIN. RELIEF VALVE SHOULD BE PIPED VERTICALLY TO A HEIGHT 18" ABOVE FLOOR.
- 5) LOCATE WATER INLET AND OUTLET FITTINGS (i.e. UNIONS, ELBOWS, ETC.) AND ALL PIPING A MINIMUM OF 6" FROM BOILER FITTINGS TO PREVENT INTERFERENCE WITH REMOVAL OF BOILER PANELS AND COVERS. LOCATE GAS PRESSURE REGULATOR A MINIMUM OF 2' FROM BOILER.
- 6) SEE PRODUCT SPECIFICATION FOR PRESSURE DROPS AT VARIOUS FLOWS.
- 7) FOR DUAL-FUEL INSTALLATION:
  - INSTALL APPROPRIATE REGULATOR FOR CURRENT FUEL IN USE.
  - INSTALLER MUST CHECK WITH LOCAL CODES REGARDING ACCEPTABLE METHOD OF DESIGNING DUAL GAS PIPING SYSTEM TO PREVENT DIRECT FLOW OF FUEL FROM ONE SYSTEM OF GAS PIPING INTO ANOTHER (FOR EXAMPLE, FROM NATURAL GAS TO PROPANE, AND VICE VERSA).

**AERCO INTERNATIONAL, INC.**  
 NORTHVALE, NJ 07647

KC1000 1 MIL. BTU LOW NOX  
 GAS FIRED BOILER  
 SINGLE UNIT INSTALLATION

|         |     |      |        |
|---------|-----|------|--------|
| DWN. BY | JK  | DATE | 012202 |
| SCALE   | NTS |      |        |
| APPD.   | CZ  | DATE | 012202 |

REV. SD-A-711 C



LEGEND

|  |                                |
|--|--------------------------------|
|  | Y-STRAINER                     |
|  | STOP VALVE                     |
|  | UNION                          |
|  | CHECK VALVE                    |
|  | COMB. BALANCING/<br>STOP VALVE |

TYPICAL LOCATION OF MAKE-UP, ELIMINATION AND EXPANSION COMPONENTS

CONNECT 5/8" I.D. HOSE TO CONDENSATE DRAIN

GAS IN - SEE GF-1030 FOR GAS PIPING INSTALLATION (FOR DUAL-FUEL INSTALLATION, SEE NOTE 8)

(NOTE 5)

1-1/4" MANUAL SHUTOFF \*

CONNECT 5/8" I.D. HOSE TO CONDENSATE DRAIN

MANDATORY GAS PRESSURE REGULATOR (SUPPLIED BY OTHERS) (FOR DUAL-FUEL INSTALLATION, SEE NOTE 8)

DIRT TRAP

BOILER WATER OUT

DIAPHRAGM TYPE EXPANSION TANK

SYSTEM PUMP

BOILER WATER IN

RELIEF VALVE \*

2'-10"

AUTOMATIC AIR VENT

AIR SEPARATOR

BACKFLOW PREVENTER

LINE SIZE BYPASS

PRESSURE REDUCING FILL VALVE

COLD WATER IN

HEADER TEMP. SENSOR

- NOTES:
- 1) THIS IS A TYPICAL INSTALLATION DRAWING. LOCAL CODES AND AUTHORITIES SHOULD BE CONSULTED.
  - 2) ALL (\*) ITEMS ARE INCLUDED SEPARATELY IN SHIPMENT.
  - 3) FOR ACTUAL SIZES AND LOCATIONS OF PIPING AND OTHER CONNECTIONS TO THE BOILER, SEE DIMENSIONAL DRAWING.
  - 4) SHELL DRAIN VALVE AND CONDENSATE HOSE SHOULD BE ARRANGED TO PERMIT THE FLUIDS TO DRAIN FREELY, BY GRAVITY, TO A CONVENIENT FLOOR DRAIN. RELIEF VALVE SHOULD BE PIPED VERTICALLY TO A HEIGHT 18" ABOVE FLOOR.
  - 5) LOCATE WATER INLET AND OUTLET FITTINGS (i.e. UNIONS, ELBOWS, ETC.) AND ALL PIPING A MINIMUM OF 6" FROM BOILER FITTINGS TO PREVENT INTERFERENCE WITH REMOVAL OF BOILER PANELS AND COVERS. LOCATE GAS PRESSURE REGULATOR A MINIMUM OF 2' FROM BOILER.
  - 6) SEE PRODUCT SPECIFICATION FOR PRESSURE DROPS AT VARIOUS FLOWS.
  - 7) BOILERS SHOULD BE PIPED REVERSE RETURN AS SHOWN OR BALANCING DEVICES ON THE OUTLETS OF THE HEATERS SHOULD BE EMPLOYED.
  - 8) FOR DUAL-FUEL INSTALLATION:
    - INSTALL APPROPRIATE REGULATOR FOR CURRENT FUEL IN USE.
    - INSTALLER MUST CHECK WITH LOCAL CODES REGARDING ACCEPTABLE METHOD OF DESIGNING DUAL GAS PIPING SYSTEM TO PREVENT DIRECT FLOW OF FUEL FROM ONE SYSTEM OF GAS PIPING INTO ANOTHER (FOR EXAMPLE, FROM NATURAL GAS TO PROPANE, AND VICE VERSA).

**AERCO INTERNATIONAL, INC.**  
NORTHVALE, NJ 07647


KC1000 1 MIL. BTU LOW NOx  
GAS FIRED BOILER  
MULTIPLE UNIT INSTALLATION

|         |     |      |        |
|---------|-----|------|--------|
| DWN. BY | JK  | DATE | 012202 |
| SCALE   | NTS |      |        |
| APPD.   | CZ  | DATE | 012202 |

REV. SD-A-712 C

LEGEND

|  |                            |
|--|----------------------------|
|  | COMB. BALANCING/STOP VALVE |
|  | STOP VALVE                 |
|  | CHECK VALVE                |
|  | UNION                      |
|  | Y STRAINER                 |



NOTES:

- 1) FOR ACTUAL SIZES AND LOCATIONS OF PIPING AND OTHER CONNECTIONS TO THE BOILER, SEE DIMENSIONAL DRAWING.
- 2) SHELL DRAIN VALVE AND CONDENSATE HOSE SHOULD BE ARRANGED TO PERMIT THE FLUIDS TO DRAIN FREELY, BY GRAVITY, TO A CONVENIENT FLOOR DRAIN. RELIEF VALVE SHOULD BE PIPED VERTICALLY TO A HEIGHT 18" ABOVE FLOOR.
- 3) ALL (\*) ITEMS ARE INCLUDED SEPARATELY IN SHIPMENT.
- 4) THIS IS A TYPICAL INSTALLATION DRAWING. LOCAL CODES AND AUTHORITIES SHOULD BE CONSULTED.
- 5) LOCATE WATER INLET AND OUTLET FITTINGS (i.e. UNIONS, ELBOWS, ETC.) AND ALL PIPING A MINIMUM OF 6" FROM BOILER FITTINGS TO PREVENT INTERFERENCE WITH REMOVAL OF BOILER PANELS AND COVERS. LOCATE GAS PRESSURE REGULATOR A MINIMUM OF 2' FROM BOILER.
- 6) SEE PRODUCT SPECIFICATION FOR PRESSURE DROPS AT VARIOUS FLOWS.
- 7) FOR DUAL-FUEL INSTALLATION:
  - INSTALL APPROPRIATE REGULATOR FOR CURRENT FUEL IN USE.
  - INSTALLER MUST CHECK WITH LOCAL CODES REGARDING ACCEPTABLE METHOD OF DESIGNING DUAL GAS PIPING SYSTEM TO PREVENT DIRECT FLOW OF FUEL FROM ONE SYSTEM OF GAS PIPING INTO ANOTHER (FOR EXAMPLE, FROM NATURAL GAS TO PROPANE, AND VICE VERSA).


**AERCO INTERNATIONAL, INC.**  
 NORTHVALE, NJ 07647

KC LOW NOx SERIES GAS FIRED  
 BOILERS COMBINATION HEATING &  
 DOMESTIC WATER BOILER PLANT

|                  |                      |               |
|------------------|----------------------|---------------|
| DWN BY <u>AK</u> | DATE <u>1-22-07</u>  | REV. <u>C</u> |
| SCALE <u>N/S</u> | SIZE <u>B</u>        |               |
| CHKD. <u>W</u>   | APPD. <u>1-22-07</u> |               |


SD-A-713






\* WATER HEATERS ONLY

|  |     |  |          |
|--|-----|--|----------|
|  |     | <b>INTERNATIONAL INC.</b><br>159 PARIS AVE. NORTHVALE, N.J.  |          |
| ORIGINAL<br>THIRD ANGLE PROJECTION                   |     | DATE: 06/30/02<br>DRAWN BY: MD<br>CHECKED BY: B  |          |
| TITLE<br><b>GAS FIRED SYSTEM SCHEMATIC (KC 1000)</b> |     | ALL DIMENSIONS ARE IN INCHES AND ALL TOLERANCES ARE AS FOLLOWS UNLESS OTHERWISE SPECIFIED<br>XX ±0.15 XXX ±.005 FRACTIONS 1/32± ANGLES ±1°<br>DIAMETERS ON A COMMON AXIS .005 TOTAL PERPENDICULARITY/PARALLELISM/FLATNESS .003 TOTAL<br>ALL DIMENSIONS ARE AFTER FINISH OR PLATING |          |
| DWG. NO.: <b>161613</b>                              |     | REV. <b>C</b>  |          |
| SHEET 1 OF 2   |     | MTL. SPEC.:  |          |
| C  | GKU | 031603   | MC       |
| B  | FYP | 100703   | JM       |
| A  | FIM | 061302   | MD       |
| REV  | ECC | DATE   | BY / CKD |




INPUT/OUTPUT BOX

|   |         |             |      |      |      |
|---|---------|-------------|------|------|------|
| REV   | ECO     | REVISIONS   | DATE | BY   | CKD  |
| SEE SHEET ONE   |         |             |      |      |      |
| THIRD ANGLE PROJECTION  |         |             |      |      |      |
| ORIGINAL DWG. SIZE  | B       | DATE        | DATE | DATE | DATE |
| DRAWN BY:   | MD      | CHECKED BY: |      |      |      |
| DATE:   | 06/30/2 |             |      |      |      |
| <p>ALL DIMENSIONS ARE IN INCHES AND ALL TOLERANCES ARE AS FOLLOWS UNLESS OTHERWISE SPECIFIED<br/>         XX ±.015 XXX ±.005 FRACTIONS 1/32± ANGLES ±1°<br/>         DIAMETERS ON A COMMON AXIS / .005 TOTAL PERPENDICULARITY/PARALLELISM/FLATNESS .003 TOTAL<br/>         ALL DIMENSIONS ARE AFTER FINISH OR PLATING</p> |         |             |      |      |      |
| <p>TITLE: GAS FIRED BOILER SYSTEM WIRING SCHEMATIC (KC 1000)</p>  |         |             |      |      |      |
| <p>MATERIAL SPEC.: DWG. NO. 161613</p>  |         |             |      |      |      |
| <p>INTERNATIONAL INC. 159 PARIS AVE. NORTHVALE, N.J.</p>  |         |             |      |      |      |
| <p>SHEET 2 OF 2</p>   |         |             |      |      |      |



KC1000 CONTROL PANEL EXPLODED VIEW

# APPENDIX I



**KC1000 CONTROL PANEL REAR VIEW**




## KC1000 LOW NO<sub>x</sub> DUAL-FUEL SWITCH-OVER INSTRUCTIONS

The KC1000 Low NO<sub>x</sub> Boiler is shipped from the factory configured for either natural gas or propane operation, as specified on the Sales Order. However, if required, the unit's operating configuration can be easily switched from natural gas to propane (or vice-versa) by performing a simple change to the spring contained in the unit's differential regulator.

The extra spring required to switch from natural gas to propane, or from propane to natural gas is included with the unit accessories (see Chapter 2, para. 2.2). Units configured for natural gas operation include a zinc-plated regulator spring, part no. 124803. Units configured for propane operation include a brown painted spring, part no. 122548.

The following instructions provide the steps necessary to convert the unit from Natural Gas to Propane operation. Proceed as follows:

1. Shut down the unit and close the external gas supply valve.
2. Remove the sheet metal covers and locate the differential regulator on the left side of the unit.
3. Refer to Figure 1 and remove the cap on the differential regulator.
4. Using a flat-blade screwdriver, remove the adjustment screw by turning it counter-clockwise. Remove the installed zinc-plated regulator spring (124803) used for Natural Gas operation. **DO NOT DISCARD THE REMOVED SPRING.**
5. Install the brown painted spring (122548) required for Propane operation.
6. Replace the regulator adjustment screw. Rotate the screw clockwise to a depth of 1-1/2 inches from the top of the regulator housing.
7. Upon completion of the spring change, perform the combustion calibration procedures in Section 4 of this Instruction Manual.



**FIGURE 1. REGULATOR SPRING REPLACEMENT**





**STANDARD WARRANTY:**  
Gas-Fired Hydronic Boiler  
Model KC-1000GWB & PWB (Propane)

---

**PRESSURE VESSEL: 10 YEARS NON-PRORATED**

The shell shall carry a non-prorated 10 year guarantee from shipment against leakage due to thermal shock, mechanical defects or workmanship. The shell **will not** be covered for waterside corrosion.

**HEAT EXCHANGER TUBES/COMBUSTION CHAMBER: 5 YEARS**

The heat exchanger/combustion chamber shall carry a 5 year, non-prorated, warranty from shipment against any condensate corrosion, thermal stress failure, mechanical defects or workmanship. Operation of the boiler using contaminated air will void the warranty. The heat exchangers combustion chamber shall not be warranted from failure due to scaling, liming, corrosion, or erosion due to water or installation conditions. **AERCO** will repair, rebuild or exchange, at its option the heat exchanger/combustion chamber for the warranted time period.

**"C-MORE" CONTROL PANEL: 2 YEARS FROM SHIPMENT**

**AERCO** labeled control panels are conditionally warranted against failure for (2) two years from shipment.

**OTHER COMPONENTS: 18 MONTHS FROM SHIPMENT**

All other components, with the exception of the ignitor and flame detector, are conditionally guaranteed against any failure for 18 months from shipment.

**AERCO** shall accept no responsibility if such item has been improperly installed, operated, or maintained or if the buyer has permitted any unauthorized modification, adjustment, and/or repairs to the item.

The warranty as set forth on the back page of the Operations & Maintenance Manual is in lieu of and not in addition to any other express or implied warranties in any documents, or under any law. No salesman or other representative of **AERCO** has any authority to expand warranties beyond the face of the said warranty and purchaser shall not rely on any oral statement except as stated in the said warranty. Any modifications to this warranty must be done in writing by an Officer of **AERCO**. **AERCO MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE OR ANY OTHER EXPRESS OR IMPLIED WARRANTIES.** **AERCO** disclaims all responsibility for any special, incidental or consequential damages. any claim relating to the product must be filed with **AERCO** not later than 14 days after the event giving rise to such claim. Any claims relating to this product shall be limited to the sale price of the product at the time of sale. The sale of the product is specifically conditioned upon acceptance of these terms.



**STANDARD WARRANTY:**  
Gas-Fired Hydronic Boiler  
Model KC-1000GWB & PWB (Propane)

---

**CONDITIONS OF WARRANTY**

Should an **AERCO** gas-fired (natural gas or propane only) water heater or hydronic boiler fail for any of the above reasons within the specified time period from the date of original shipment(s), AERCO shall at its option modify, repair or exchange the defective item. **AERCO** shall have the option of having the item returned, FOB its factory, or to make field replacements at the point of installation. **In no event shall AERCO be held liable for replacement labor charges** or for freight or handling charges.

**AERCO** shall accept no responsibility if such item has been improperly installed, operated, or maintained or if the buyer has permitted any unauthorized modification, adjustment, and/or repairs to the item. The use of replacement parts not manufactured or sold by **AERCO** will void any warranty, express or limited.

In order to process a warranty claim a formal purchase order number is required prior to shipment of any warranty item. In addition, the returned item must include a Returned Goods Authorization (RGA) label, attached to the shipping carton, which identifies the item's return address, register number and factory authorized RGA number.

Warranty coverage for all components and equipment mentioned in said warranty are not valid unless the water heater or hydronic boiler is started up by a factory certified SST (Service, Start-Up and Troubleshooting) Technician and an AERCO start-up sheet is completed.

This warranty coverage is only applicable within the United States and Canada. All other geographical areas carry a standard warranty of 18 months from date of shipment or 12 months from startup, whichever comes first.

