

Monday, January 20, 2020

Hydronic Pump Energy: Motor & VFD Efficiency – How Low Can You Go?

Monday Morning Minutes | by Norm Hall, January 20, 2020

I'm in the middle of the series of blogs on parallel pumping. We can't ignore the efficiency of variable frequency drives and motors when looking at the cost and savings of variable speed pumping applications. The title of this blog might be re-written to "How low SHOULD you go."

Many programs that select pumps and indicate the cost of operation tend to concentrate on the pump and ignore the drop in drive and motor efficiency. Let's look at that efficiency.



Motor Efficiency as a Function of Percent Speed and Load

I'll address electronically commutated motors (ECM) and permanent magnet motors later. Today we look at traditional synchronous induction pump motors provided on 99% of commercial hydronic pumps.

What happens as the load drops and the speed follows. The Bell & Gossett pumps we supply will often use any number of the major brands of motors. Each supplier has slight differences in efficiencies at full and reduced loads. I'll use a fact sheet and figures 1 and 2 from the U.S. Department of Energy, "[Determining Electric Motor Load and Efficiency](#)" as a baseline for this blog. You may read the article for all the detail, but I want to address two graphs from it.




Figure 1 Motor Part-Load Efficiency (as a Function of % Full-Load Efficiency)

Here we see that, in general, the efficiency drops significantly below 25-30% of the load. The 95% efficient full load motor may only be 50% at less than 20% load. This will play havoc with our cost savings at very low loads.




Figure 2 Motor Power Factor (as a Function of % Full-Load Amperage)

The other thing about motors is the power factor. When amperage drops below 45% of full load, the power factor takes a big hit.

VFD Efficiency as a Function of Percent Speed and Load?

Variable frequency drives have very high efficiencies at full speed and load. This efficiency drops as the speed drops. R. L. Deppmann represents Danfoss drives in Eastern Michigan and Bell & Gossett drives in most of Michigan and Northern Ohio. Both of those manufacturers can beat the average efficiencies you may specify. We would be honored to receive a request to explain to you just how much better these products are. Meanwhile, to represent the average VFD, I'll again turn to the U.S. Department of Energy "[Motor Tip Sheet #11](#)" and look at table 1.

In those systems where 100% standby is needed, you should either stick with the 100%-100% system or if parallel pumping is going to save a great deal of cost, you could go to an N+1 strategy with pumps. Use 50%-50%-50% in smaller systems or 33%-33%-33%-33% in larger systems.

Table 1. Adjustable Speed Drive Part-Load Efficiency*


Variable Drive hp Rating	Efficiency (%)						
	Load, Percent of Drive Rated Power Output						
	1.6	12.5	25	42	50	75	100
5	35	80	88	91	92	94	95
10	41	83	90	93	94	95	96
20	47	86	93	94	95	96	97
30	50	88	93	95	95	96	97
50	46	86	92	95	95	96	97
60	51	87	92	95	95	96	97
75	47	86	93	95	96	97	97
100	55	89	94	95	96	97	97
200	61	81	95	96	96	97	97

*These efficiency values may be considered representative of "typical" PWM VFD performance. There is no widely accepted test protocol that allows for efficiency comparisons between different drive models or brands. In addition, there are many ways to set up a VFD that can affect the operating efficiency. Source: *Saftronics, Inc.*

Look at this sheet. We know from the third pump affinity law that horsepower varies as the cube of flow. At 1/2 of the flow rate, the horsepower is 1/8 of the full load. This is not exact because of the [minimum control head](#) but it is close enough for this discussion. So, if a pump is operating at full load and flow at 100% speed, at 50% load, it is around 12.5%. This assumes there was no over heading or future capacity built-in which would reduce the full load speed right from the start.

Look at a 30 HP motor in the chart above. At full load, it is 97% efficient. At 1/8 load, the efficiency drops to 88%. At 1.6%, the efficiency is only 50%. You may think that operation below 12.5% of the horsepower is ridiculous but let's do the math.

Assume a pump is designed for 1000 GPM at 150 feet of head and has a control head of 10 PSIG or 23 feet. If I use the [Bell & Gossett eSP-Systemwize](#) pump selection program, I get a curve like this:



The minimum speed based on the control head is 600 RPM. The motor is rated 1750 RPM. Doing the math, the horsepower will be 4.2% of the brake horsepower.

The motor will operate at 30% and the drive will be at 60%. The combined efficiency of the electrical devices will be $(0.3 \times 0.6 =) 18\%$. How low should you go?

I do understand that this efficiency is applied to a much smaller horsepower. Given that, there are times when parallel pumping may help make a big difference in the electrical bill. That will be the subject of the next **R. L. Deppmann Monday Morning Minutes: Parallel Pumping and Cost.**

HVAC Hydronic System Series:

[Article 1: What is parallel pumping and why do it?](#)

[Article 2: Selecting parallel pumps and the curve](#)

[Article 3: Controlling parallel variable speed pumps](#)

[Article 4: Parallel pumping and standby capacity](#)

Article 5: Parallel pumping and cost (*coming soon*)

Article 6: Parallel pumping specifications (*coming soon*)